How to print these files correctly

- Make sure to have your **Rotation Distance** already calibrated see the Troubleshooting folder in the KPA-download.
- In your Slicer app, in the print settings, set the **height of the first layer** to **0.28 mm**.
- Print the test files.
 - To set the **z-offset** quickly you can use the file 100x100x0,28.
 - To verify the entire bed, use the 220 or 300 file.
- When you are happy with your z-offset, save it.
 To do so, in Mainsail you first need to click the little blue "Save" knob...



• ...and then a dialog comes up with Save Config:



The new Z-Offset has been calculated and registered. Click on "SAVE CONFIG" to save it to the printer.cfg and restart Klipper.

SAVE CONFIG LATER

How to print after calibration

For your daily printing you can now use any first layer height you wish.