## **GP HSM Operating System Support**

Updated Oct 09, 2008

Product Name	SA	SA	SA	SA	SA	SA	SA	TS	PCM /CA⁴	PCM /CA <sup>4</sup>	CA <sup>3</sup>	PCM /CA⁴	CA <sup>3</sup>	PCI-	PCI- 7000	PCI	PCI	CA3	PTK -C	PTK	PTK	PTK
									/CA	/CA		/CA		1200	7000	3000 /	3000		-0	-C		
																7000	7000					l
Product Rel v.	3.2/ 3.3	4.0	4.1	4.2	4.3	4.3.2	4.4	1.0	2.2	2.3		2.4		2.0/ 2.1	2.1	2.2	3.0	8.1	3.28	3.30	3.32	4.0
																					3.33	
Windows NT (32-bit lib)																		<b>√</b>	<b>√</b>		$\sqrt{}$	
Windows XP (32-bit lib)													$\sqrt{6}$		$\sqrt{}$			<b>√</b>	<b>√</b>			
Windows 2000 (32-bit lib)	V	√	V						√	<b>√</b>			$\sqrt{6}$	<b>√</b>	<b>√</b>			√	√			
Windows 2003 (32-bit lib)	V	√	V	V	<b>√</b>	V	<b>√</b>		√	<b>√</b>		<b>√</b>	<b>√</b>			V	<b>√</b>	√	√	<b>√</b>	<b>√</b>	V
Win 2003 (64-bit lib)			V	V	<b>√</b>	V	<b>√</b>					<b>V</b>	<b>√</b>				√9		X 4		<b>√</b>	V
Win 2008 (64-bit lib)				V'	\'\'	√ ′	<b>√</b>					V '					$\sqrt{9}$				V /	V /
Solaris 7 (32-bit lib)																		<b>√</b>	<b>√</b>			
Solaris 8 (32-bit lib)	V	<b>V</b>	<b>V</b>							√5	<b>V</b>				<b>V</b>			√	√			
Solaris 9 (32-bit lib)	V		<b>√</b>	<b>√</b>		<b>√</b>	$\checkmark$			$\sqrt{5}$					<b>√</b>	V	<b>√</b>	√	√	<b>√</b>	<b>√</b>	V
Solaris 9 (64-bit lib)	V	V	V	V	V	V	V			V	√		V			V	V		V	√	V	V
Solaris 10(32-bit lib)	√*	√	V	V	√	V				$\sqrt{5}$		√	<b>√</b>		V	V	V		X 3	√	<b>√</b>	<b>√</b>
Solaris 10(64-bit lib)	√*	X 1	V	V	<b>√</b>	V	<b>√</b>			<b>√</b>	<b>V</b>	<b>V</b>	<b>V</b>		V	V	<b>V</b>		X 3	<b>√</b>	<b>√</b>	<b>√</b>
Solaris 10 x86 (32-bit lib)				V			<b>√</b>															
Solaris 10 x86 (64-bit lib)				√			<b>√</b>															
Linux RH7.2 k 2.4 (32-bit lib)								√										<b>√</b>	<b>√</b>			
Linux RH 8 k 2.4 (32-bit lib)	V	√	V	V	√	V		<b>√</b>	√	√			<b>√</b>	√	V	V		√	√	<b>√</b>	<b>√</b>	
Linux E3 k 2.4 (32-bit lib)	V		√					$\sqrt{}$											<b>√</b>			
Linux E4 k 2.6 (32-bit lib)				V	<b>√</b>	V	<b>√</b>	<b>√</b>		<b>√</b>		<b>V</b>	<b>V</b>			V	<b>V</b>			<b>√</b>	<b>√</b>	<b>√</b>
Linux E4 k 2.6 (64-bit lib)				V	<b>√</b>	V	<b>√</b>					<b>V</b>				V	<b>V</b>			<b>√</b>	<b>√</b>	<b>√</b>
Linux E5 k 2.6 (32-bit lib)				V	<b>√</b>	V	<b>√</b>	<b>√</b>				<b>V</b>					<b>V</b>				<b>√</b>	<b>√</b>
Linux E5 k 2.6 (64-bit lib)				V	<b>√</b>	V	<b>√</b>					<b>V</b>					√8				<b>√</b>	<b>√</b>
Linux FC2 k 2.6 (32-bit lib)									√	√				√	V				√			
Linux SuSE9 k 2.6 (64-bit lib)																			X 4	<b>√</b>		
Linux SuSE10 (32-bit lib)																					<b>√</b>	V
AIX 4.3 (32-bit lib)																		√				
AIX 5.1 (32-bit lib)	V	√	<b>√</b>															V				
AIX 5.2 (32-bit lib)	V	√	<b>√</b>															√	√			
AIX 5.3 (32-bit lib)	V	V	V	V	V	V	V												V		V	<b>√</b>
AIX 5.3 (64-bit lib)		X 1	V	V	V	V	V	<b>√</b>											V		V	V
HP-UX 11 (32-bit lib)																		<b>√</b>	V			
HP-UX 11i (32-bit lib)	V	<b>V</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>V</b>												√	√		<b>√</b>	<b>√</b>
HP-UX 11i (64-bit lib)	·						<b>√</b>												V		V	V
HP ITANIUM (64 bit lib) V3					<b>V</b>	V	V															
VMware					√10	√10	?															
Debian 4.0 K2.6 (32-bit lib)					<u> </u>												√11					
Debian 4.0 K2.6 (64-bit lib)																	√11					

Releases shaded are in planning stage only – not yet confirmed/tested

<sup>\*</sup> Engineering tested only, not full Quality Assurance testing

<sup>&</sup>lt;sup>1</sup> Alpha qualified with SA 3.3

<sup>&</sup>lt;sup>3</sup> The driver for Solaris 9 will not install on Solaris 10.

<sup>&</sup>lt;sup>4</sup> Alpha

<sup>&</sup>lt;sup>5</sup> Only 64-bit driver included in this release <sup>6</sup> Only for LD on Windows – not fully supported for GA

<sup>&</sup>lt;sup>7</sup> Not tested on Win 2008, only on Longhorn Beta3
<sup>8</sup> EngTested on Linux E5.1 and E5.2 for 64-bit, E5.1 for 32-bit
<sup>9</sup> K3 is not supported on Windows 64-bit
<sup>10</sup> EngTested on 32-bit Linux Ent 5 2.6.x and Win2003
<sup>11</sup> EngTested on Intel 64-bit platform