



RFID PROGRAMMING


AND SECURITY

RADIO FREQUENCY IDENTIFICATION


Programming STM8


Microcontroller : STM8S003F3

- Upload hex file to STM8 microcontroller
- STM8 & STM32 USB



STM8 Connection





USB to TTL Connection
with MFRC522



RX to **TX**
TX to **RX**
GND to **GND**
5v to **5v**