



RFID PROGRAMMING

AND SECURITY

RADIO FREQUENCY IDENTIFICATION

Firmware Update Proxmark3

`cd proxmark3/client`

on boot loader step press button and plugin proxmark3
(make sure **green** and **red** led is on)

run command

`./flasher /dev/ttyACM0 -b ../bootrom/obj/bootrom.elf`



Firmware Update Proxmark3

then remove proxmark3 and plug it again doing same
(press button and make sure **green** and **red** led is on)

then run

```
./flasher /dev/ttyACM0 ../armsrc/obj/fullimage.elf
```

Firmware Update Proxmox3

Start Proxmox3

```
./proxmark3 /dev/ttyACM0
```

```
hw status
```

```
hw version
```

```
hw tune
```