
+++

13-3.5 Initializing soft ware of LCM


13-3.5.1 8-bit interface



8-Bit Ineterface



13-3.5.2 4-bit interface



4-Bit Ineterface