

PROGRAMMING INTERFACE




DC JACK




RESET

GND 1 4

DUAL OP-AMP




5V TO 3.3V



MICROCONTROLLER UNIT

CONNECTOR PINS



ARDUINO UNO SCHEMATIC DIAGRAM

5 U1 ✓ ATmega328PB-A GND