





- Manually plug-in the air conditioner, find the brand of the air conditioner in the "Code Table" and find the first code, for example: Haier
- Hold SET button (for about three seconds) until the conditioner brand code flashes in the window, press Temperature "▲"or "▼" buttons until the selected code flashes in the window. When the code is right, the air conditioner will start.
- 3. Press OK button and the selected code will stop flashing.

Test whether the other buttons are working correctly. If yes, setting completes. And if not, repeat steps 2-3.









- Manually plug-in the air conditioner, aim the remote control at the receiving window of the air conditioner.
- Press the code key that corresponds to your brand and hold until the air conditioner starts by giving out a sound signal. Release the key and the setting is completed.
- * this setting method only suits for partial models

BRAND SYMBOL CORRESPONDING TABLE

Ф	▲ TEMP	▼ TEMP	₩IND
GREE/Hair	MD\TOSHIBA\	SHARP\	MITSUBISHI\
	Changhong	KELONG	OTHER
M.SWING	A.SWING	TIME ON	TIME OFF
HITACHI\	SANYO\	CHIGO\	FUJITSU\
Panasonic	HISENSE	Daikin	CARRIER



- Manually plug-in the air conditioner, aim the remote control at the receiving window of the air conditioner.
- 2. Hold SET button (for about six seconds) until the conditioner type code changes in the window, indicating you have entered the high-speed code search status. press OK button to stop searching once the air conditioner automatically starts.
- Test whether the functions of remote control buttons (excluding Temperature ▲ and ▼ buttons, timing ON/OFF buttons, and SET button) are OK. If yes, the code is effectively set. If not, press SET button to search for the correct code

Test whether the other buttons are working correctly. If yes, setting completes. And if not, repeat steps 2-3.





















POLICY WARRANTY

- This product has one year warranty in all its parts from manufacturing defects and operation, as of the date of delivery.
- In order to make valid the warranty and to acquire any suppliers you should present the product with this warranty in the place where the purchase was made.
- The repair time will be within 30 days, counted from the reception of the product in anywhere of the sites where the warranty can become effective. The warranty is invalid if the product had been used in the other than normal or when the product has been altered or repaired by no authorized personnel.
- Date and seal of purchase: _