tuyaDAEMON device Smoke_Detector



Model: PA-443Y

Tuya: ywbj Mod: ljmfjahi9bbv2huq

Tuya WiFi Smoke Alarm (sheet ver.2)

Low power standby without MQTT.

Mirror device: uses 4 TRIGGERs + OpenAPI to exchange data with the

real device.

Power supply: **BAT**Broadcast: **WiFi**Capabilities:

Reference: https://ewelink.eachen.cc/product/eachen-wifi-strobe-smoke-detector-sensor-phone-

Infos: call-app-push-alarm-compatible-with-tuya-smart-life/

Sellers:

https://www.aliexpress.com/item/4000990605711.html

User defined Data Points:

| | TRGalarmON | | see note | | | |
|-----------------|--|------|----------|-----------------------------|----------------|--|
| SMOKE3003 0 | Alarm ON TRIGGER: Tuya automation event-drive, updates DP 1 DP not required: handled by core_TRIGGER flow [If 'smoke':alarm:on, Then 'tuya_bridge':countdown_1:30030] | | | | | |
| | TRGalarmOFF | | see note | | | |
| SMOKE3010 0 | Alarm OFF TRIGGER: Tuya automation event-drive, updates the full status DP not required, handled by core_TRIGGER flow [If 'smoke':alarm:off, Then 'tuya_bridge':countdown_1:30100] | | | | | |
| | TRGbattLOW | | see note | | | |
| SMOKE3017 0 | Battery LOW TRIGGER: Tuya automation event-drive, updates DP 14 DP not required, handled by core_TRIGGER flow [If 'smoke':battery:low, Then 'tuya_bridge':countdown_1:30170] | | | | | |
| | silence | WO | string | 'any' | | |
| _silenceTR G | silence ON TRIGGER, fires Tuya Automation, SET DP 16 Requires a 'share' to fire SMOKE50050 [If 'tuya_bridge':countdown_1 = 50050, Then 'tuya_bridge':countdown_1:0 + 'smoke':silence:ON] | | | | | |
| | smoke_sensor _state | SKIP | enum | 1:'Smoke alarm', 2:'normal' | | |
| 2 | more values: 'Test alarm', ? | | | | | |
| | smoke_sensor _value | SKIP | | 0100 = 0.010.0 [ppm] | BYTESMALLFLOAT | |
| | pushed only on 'Smoke alarm' change | | | | | |
| | fault | SKIP | enum | 0: ok, more err. codes? | | |
| 11 | unknown | | | | | |
| | battery_state | SKIP | string | 'low', 'middle', 'high' | | |
| 14 | by Tuya Cloud, never by device | | | | | |
| 15 | battery_perce ntage | SKIP | int | 0100 [%] | | |
| | | | _ | | | |



| | pushed on any alarm state change | | | | | | |
|-----|---|------|---------|--|--|--|--|
| 16 | muffling | SKIP | boolean | | | | |
| | SET only during alarm, returns to false at alarm end. Also HW | | | | | | |
| 101 | test | SKIP | boolean | | | | |
| | 'Test alarm' 5', only HW | | | | | | |

