Tuya device switch-1CH



Model: TYWR 7-32

Tuya: switch Tuya Mod: hryktirnvgdua5cm

WIFI Wireless Smart Home Switch with RF433 Control

Any GET sends all data (like SCHEMA), SET:null works OK, so all dp

'WW'

Can be used as tuya_bridge device

Power supply: **USB**Broadcast: **WiFi**Capabilities: **ALL**

Reference:

Infos: https://developer.tuya.com/en/docs/iot/device-development/module/wifibt-dual-mode-

Sellers: module/wb-series-module/wb3sipex-module-datasheet

https://www.aliexpress.com/item/1005001292612142.html

Known Data Points:

1	relay	WW	boolean	true false = ON OFF	BOOLEANONOFF
	Toggles when the countdown goes to 0; SET(7):0 => the switch does not change				
7	countdown	WW	int	086500 s (24H max.)	
	PUSH every (30 * k) s; GET returns last PUSHed value, not the actual count DPcapability for test: 'RW', for use: 'WW', as 'tuya_bridge': 'TRG'				
14	restart status	WW	string	'off' 'on' 'memory'	
	The initial switch status, after a reset.				
15	light mode	WW	string	'pos' 'none' 'relay'	
	no HW: can be used as trigger				
16	backlight	WW	boolean	true false	
	no HW: can be used as trigger				
17	circulate	WW	binary	array of {active: true false, day:SMTWTFS DLMMGVS, start HH:MM, end: HH:MM, on: HH:MM, off: HH:MM}	STRUCTREPEAT
	Undocumented tentative. day: skip='-', do: any char. If day:'', once. SET:[] to clear				
18	random	WW		array of {active: true false, day:SMTWTFS DLMMGVS, start HH:MM end: HH:MM}	STRUCTRAND
	Undocumented tentative. day: skip='-', do: any char. If day:'', once SET:[] to clear				
19	inching	WW	binary	{ inching: true false delay: 03660} in sec	STRUCTINCH
	The inching (temporary) counter SET:{} to clear				

