

Installation/Instructions for Use

Instructions for use

1. Normal mode: Scan the barcode to enter normal mode, and the scan results will be uploaded to the computer in time (this mode is the default mode).
2. Inventory mode: Scan the barcode to enter inventory mode, and the scan results will be stored in the internal memory (when the internal memory is occupied, the buzzer will emit a "beep beep" sound as a prompt).
3. Data lossless mode: Scan the barcode to the data lossless mode. In this mode, when there is a signal, the scan results will be uploaded to the computer in time; when the signal is weak or there is no signal, the scan results will be stored in the internal memory, and the data stored when waiting for the signal will be automatically uploaded to the computer.
4. Data upload: Scan the barcode to upload the data stored in the memory to the computer in sequence (applicable to inventory mode and data lossless mode. Please ensure that the wireless signal is normal when uploading data. If the data is uploaded successfully, the buzzer will "tick" 2 times, if the data upload fails, the buzzer will "tick" 3 times).
5. Display the total number of scans: Scanning the barcode will display the total number of stored data (applicable to inventory mode).
6. Clear data: Scanning the barcode will erase all data in the memory.

Safety Information Statement

1. Do not mix new and old batteries or different types of batteries.
2. Do not throw batteries into fire, disassemble, or short-circuit them.
3. Keep batteries out of reach of children.
4. If the battery leaks or is damaged, do not touch it and dispose of it safely in accordance with local regulations.

Instruction manual

Carry the screen wireless 2D scanner

V1.2

Dear users, thank you for choosing our products. We will serve you with high-quality products, in order to ensure that you use this product better, please read this manual carefully before use!

Description

Storage count Wireless connection Electricity

Inventory mode Bluetooth connection

Bluetooth connection

After the code scanner is powered on, open the Bluetooth search at the receiving end, find the device with the Bluetooth name "BARCODE SCANNER", click to connect, and the icon will be displayed on the display after success. (Applicable to Bluetooth version)

Bluetooth settings

Bluetooth HID

Bluetooth SPP

Bluetooth BLE

Clear the pairing information

System settings

Factory reset

Software version number

All barcodes can be read

Communication mode settings

**USB HID mode

Virtual serial port mode

Common ending character settings

** Enter

Carriage return to wrap

Tab

No terminator

Reading mode settings

** Manual reading mode

Induction mode

Continuous mode

Tone settings

**Turn on the prompt sound

Turn off the tone

** Turn on your voice

Turn off speech

** Turn on vibration

Turn off the vibration

Wireless function settings

** Normal mode

Storage mode

Data uploads

Clear data

Illustrate:

- Normal mode: Scan the barcode to enter the normal mode, in which the scanning results will be uploaded to the computer in time (this mode is the default mode).
- Inventory mode: scan the barcode to enter the inventory mode, in this mode will store the scanning results in the internal memory, and the inventory mode icon will be displayed on the screen (when the internal memory is occupied, the buzzer will "beep" as a prompt).
- Data upload: Scan the barcode to upload the data stored in the internal memory to the computer in turn (applicable in inventory mode, please ensure that the wireless signal is normal when uploading data, there will be voice prompts when data upload is successful, and there will be voice prompts when data upload fails.)
- Storage Count: The screen of the barcode scanner will display the total number of stored data.
- Clear data: Scanning the barcode will erase all the data in the internal memory.

One-click pairing function

pairing

Scan the pairing code above, the scanner will continuously send out a pairing voice prompt, insert the receiver into the USB port of the computer, the voice prompt pairing is successful, and the screen will display the icon when the connection is successful

Sleep time setting

Note: Scan the sleep time SET first, and then scan the time you want to set

Sleep time SET

30 seconds

**60 seconds

2 minutes

5 minutes

No dormancy

Language settings

** United States

France

Germany

Italy

Spain

Japanese

Reverse reading settings

Inverted color recognition is turned on

** Inverted color recognition is turned off