Reg No: 18BCE0559

**Name:** Sreenitya Mandava


Slot: L29+L30


## **ASSESSMENT-2**

## ALP for factorial of a number


Factorial of 5 =  $(120)_{10}$  =  $(78)_{16}$  i.e. 78h

```
DOSBox 0.74, Cpu speed: 3000 cycles, Frameskip 0, Program:
                                                                      - - X
 File Edit Search View Options Help
                              C:\MASM\8BCE0559.ASM |
 .model small
 .stack 64h
 .data
A DB 05h
.code
START:
MOV ax,@data
MOV ds,ax
MOV ah,00
MOV al,A
L1:
DEC A
MUL A
MOV cl,A
CMP cl,01
JNZ L1
MOV ah,4ch
INT 21h
end start
 .end
Commands for manipulating files
```






DOSBox 0.74, Cpu speed: 300	0 cycles, Frameskip 0, Program: DEBUG	
	DX=0000 SP=0064 BP=0000 SI=0000 DI=000 CS=0744 IP=0012 NV UP EI PL NZ NA PO N MOV CL,[0000]	
	DX=0000 SP=0064 BP=0000 SI=0000 DI=000 CS=0744 IP=0016 NV UP EI PL NZ NA PO N CMP CL,01	
	DX=0000 SP=0064 BP=0000 SI=0000 DI=000 CS=0744 IP=0019 NU UP EI PL NZ NA PE N	
	DX=0000 SP=0064 BP=0000 SI=0000 DI=000 CS=0744 IP=000A NU UP EI PL NZ NA PE N	
	DX=0000 SP=0064 BP=0000 SI=0000 DI=000 CS=0744 IP=000E NV UP EI PL NZ NA PE N MUL BYTE PTR [0000]	
_ AX=003C BX=0000 CX=0004 DS=0746 ES=0734 SS=0747	DX=0000 SP=0064 BP=0000 SI=0000 DI=000 CS=0744 IP=0012 NU UP EI PL NZ NA PE N	99 HC
0744:0012 8A0E0000 	MDV CL,[0000]	DS:0000=03



DOSBox 0.74, Cpu speed: 3000 cycles, Frameskip 0, Program: DEBUG	- X
- AX=0078 BX=0000 CX=0002 DX=0000 SP=0064 BP=0000 SI=0000 DI=0000 DS=0746 ES=0734 SS=0747 CS=0744 IP=0019 NV UP EI PL NZ NA PO NC 0744:0019 75EF JNZ 000A	
- AX=0078 BX=0000 CX=0002 DX=0000 SP=0064 BP=0000 SI=0000 DI=0000 DS=0746 ES=0734 SS=0747 CS=0744 IP=000A NV UP EI PL NZ NA PO NC 0744:000A FE0E0000 DEC BYTE PTR [0000] DS:00	000=0Z
	000=01
	000=01
 AX=0078 BX=0000 CX=0001 DX=0000 SP=0064 BP=0000 SI=0000 DI=0000 DS=0746 ES=0734 SS=0747 CS=0744 IP=0016 NV UP EI PL NZ NA PO NC 0744:0016 80F901 CMP CL,01	
- AX=0078 BX=0000 CX=0001 DX=0000 SP=0064 BP=0000 SI=0000 DI=0000 DS=0746 ES=0734 SS=0747 CS=0744 IP=0019 NV UP EI PL ZR NA PE NC 0744:0019 75EF JNZ 000A	



## Factorial of $4 = (24)_{10} = (18)_{16}$ i.e. 18h

```
DOSBox 0.74, Cpu speed: 3000 cycles, Frameskip 0, Program: EDIT
                                                                      - - X
 File Edit Search View Options Help
                             C:\MASM\8BCE0559.ASM
 model small
 .stack 64h
 .data
A DB 04h
 .code
START:
MOV ax,@data
MOV ds,ax
MOV ah,00
MOV al,A
L1:
DEC A
MUL A
MOV cl,A
CMP cl,01
JNZ L1
MOV ah,4ch
INT 21h
end start
 .end
Commands for manipulating files
```

```
DOSBox 0.74, Cpu speed: 3000 cycles, Frameskip 0, Program: DOSBOX
                                                                      - - X
C:\MASM>edit 8BCE0559.asm
C:\MASM>masm 8BCE0559.asm
Microsoft (R) Macro Assembler Version 5.00
Copyright (C) Microsoft Corp 1981–1985, 1987. All rights reserved.
Object filename [8BCE0559.OBJ]:
Source listing [NUL.LST]:
Cross-reference [NUL.CRF]:
  51688 + 464856 Bytes symbol space free
      0 Warning Errors
      0 Severe Errors
C:∖MASM>link 8BCE0559.obj
Microsoft 8086 Object Linker
Version 3.02 (C) Copyright Microsoft Corp 1983, 1984, 1985
Run File [8BCE0559.EXE]:
List File [NUL.MAP]:
Libraries [.LIB]:
C:\Masm>
```

DOSBox 0.74, Cpu speed: 3000 cycles, Frameskip 0, Program: DEBUG	
List File [NUL.MAP]:	
Libraries [.LIB]:	
C:\MASM>debug 8BCE0559.exe	
-t	
AX=0746 BX=0000 CX=0021 DX=0000 SP=0064 BP=0000 SI=0000 DI=0000	
DS=0734 ES=0734 SS=0747 CS=0744 IP=0003 NV UP EI PL ZR NA PE NC	
0744:0003 8ED8 MOV DS,AX	
-	
AX=0746 BX=0000 CX=0021 DX=0000 SP=0064 BP=0000 SI=0000 DI=0000	
DS=0746 ES=0734 SS=0747 CS=0744 IP=0005 NV UP EI PL ZR NA PE NC 0744:0005 B400 MDV AH.00	
0744:0005 B400 MDV AH,00 _	
AX=0046 BX=0000 CX=0021 DX=0000 SP=0064 BP=0000 SI=0000 DI=0000	
DS=0746 ES=0734 SS=0747 CS=0744 IP=0007 NV UP EI PL ZR NA PE NC	
0744:0007 A00000 MDV AL,[0000]	DS:0000=04
-	
AX=0004 BX=0000 CX=0021 DX=0000 SP=0064 BP=0000 SI=0000 DI=0000	
DS=0746 ES=0734 SS=0747 CS=0744 IP=000A NU UP EI PL ZR NA PE NC	DO: 0000-04
0744:000A FE0E0000 DEC BYTE PTR [0000]	DS:0000=04
AX=0004 BX=0000 CX=0021 DX=0000 SP=0064 BP=0000 SI=0000 DI=0000	
DS=0746 ES=0734 SS=0747 CS=0744 IP=000E NV UP EI PL NZ NA PE NC	
0744:000E F6260000 MUL BYTE PTR [0000]	DS:0000=03

DOSBox 0.74, Cpu speed: 3000 cycles, F	rameskip 0, Program: DEBUG	X
	0 SP=0064 BP=0000 SI=0000 DI=0000 4 IP=0012 NV UP EI PL NZ NA PE NC V CL,[0000]	DS:0000=03
	0 SP=0064 BP=0000 SI=0000 DI=0000 4 IP=0016 NV UP EI PL NZ NA PE NC P CL,01	
	0 SP=0064 BP=0000 SI=0000 DI=0000 4 IP=0019 NV UP EI PL NZ NA PO NC Z 000A	
	0 SP=0064 BP=0000 SI=0000 DI=0000 4 IP=000A NU UP EI PL NZ NA PO NC C BYTE PTR [0000]	DS:0000=03
	0 SP=0064 BP=0000 SI=0000 DI=0000 4 IP=000E NV UP EI PL NZ NA PO NC L BYTE PTR [0000]	DS:0000=02
	0 SP=0064 BP=0000 SI=0000 DI=0000 4 IP=0012 NU UP EI PL NZ NA PO NC U CL,[0000]	DS:0000=02

0744:0019 75EF JNZ 000A
- AX=0018 BX=0000 CX=0002 DX=0000 SP=0064 BP=0000 SI=0000 DI=0000 DS=0746 ES=0734 SS=0747 CS=0744 IP=000E NV UP EI PL NZ NA PD NC 0744:000E F6260000 MUL BYTE PTR [0000] DS:0000=0
- AX=0018 BX=0000 CX=0002 DX=0000 SP=0064 BP=0000 SI=0000 DI=0000 DS=0746 ES=0734 SS=0747 CS=0744 IP=0012 NV UP EI PL NZ NA PO NC 0744:0012 8A0E0000 MOV CL,[0000] DS:0000=0
- AX=0018 BX=0000 CX=0001 DX=0000 SP=0064 BP=0000 SI=0000 DI=0000 DS=0746 ES=0734 SS=0747 CS=0744 IP=0016 NV UP EI PL NZ NA PO NC 0744:0016 80F901 CMP CL,01

