


NOTES:

1. CLEAN AND ROUGHEN EXISTING FLOOR BEFORE POURING CONCRETE PAD.
2. FOLLOW MANUFACTURERS WRITTEN PROCEDURE FOR EPOXY GROUTING THE DOWELS INTO THE CONCRETE SLAB.
3. USE #4 REBAR IN 4 LOCATIONS, 6" FROM THE EDGE OF THE CONCRETE PAD.
4. NO HORIZONTAL REINFORCING REQUIRED.
5. DOWELS TO BE #4 REBAR. PROVIDE A 45° CHISEL POINT ON THE BOTTOM OF EACH DOWEL FOR PROPER MIXING OF EPOXY. DRILL HOLES USING HILTI CARBIDE TIPPED DRILL BITS OR DIAMOND CORE BITS. PROVIDE HOLES OF PROPER DEPTH AND DIAMETER IN ACCORDANCE WITH THE HILTI SPECIFICATION TABLES. USE HILTI HVA CAPSULE ADHESIVE ANCHORING SYSTEM.



EQUIPMENT PAD DETAIL

1  
H207



Jimmy Huntington Building  
714 Fourth Avenue, Suite 201  
Fairbanks, Alaska 99701  
Telephone (907) 455-1500  
Fax (907) 455-6788

Date: 14 FEB 2010  
Scale: NTS  
Designed By: RAH  
Drawn By: EMS  
Checked By: NEM

UTILIDOR & ACCESS VAULT SYSTEM  
EQUIPMENT INSTALLATION DETAILS  
DESIGN & CONSTRUCTION STANDARDS

Drawing No.  
UES-DD-H207