

HandiMote Demo

MSViso






Copyright (C) [2024] [MSViso]



- 1. Long Press the HandiMote PWR Key for 3 Sec
- 2. Click the PC Program
- 3. Waiting for the BLE device Scan (10 Sec~)
- 4. Input Devices Name "HandiMote" and press OK
- 5. Waiting for device data stream~



MSVison HandiMote Demo Console









Image Break Press swap



















Copyright (C) [2024] [MSViso]