KCX AUDIO EMITTER
Bluetooth 4.1

Pair

Stereo Jack IN 3.5

Bluetooth connection indicator LED

Activity

**MSX mono switch and stereo Jack IN**

The switch to the left position is for the Mono mode
The switch on the right disables the MSX audio and allows the
stereo IN jack 3.5 to be connected. Stereo mode works with all external
audio sources (MP3, Moonsound, FM PAC stereo...)

The connection is automatic. First, switch-On the Bluetooth speaker first,
then switch-On the MSX. Wait a moment until search is complete.
The connection is established when the blue LED light up.
If Not, press the button for 1/2 second and wait. The connection is saved
for the next connection.

Note: On some MSX model, the audio is less forty and noise may be
audible (beware of slot expander). This product is an home made
and has been carefully designed.
A Bluetooth headphones work very well with this module

/!\ Update 2024: Some MSX like a turbo-R has no output sound on the
cartridge. You need to use the jack on the right

Beta by MSXLegend 2023-2024