### **Zombietron Robot Controller Data Sheet**

### Command Protocol

The protocol for sending Bluetooth commands to the Android Robot Controller consist of a command character followed by a comma delimited list of two parameters and a trailing comma. Each character in the command text must be converted to its ascii byte value and sent via Bluetooth to the Android Robot Controller. Commands can be concatenated into one compound text command to send multiple commands simultaneously. The second parameter for most commands is a "do not care value" and is a dummy placeholder value that is not used except for the "a" command.

#### **Command Structure**

Command Character, parameter 1 value, parameter 2 value, (ex. e180,0,)

Multiple commands to Servos A4, D4 & D6 example: m57,0,f90,0,e45,0,

## Pin Mapping

Pin Label	Description	Command	Comments
NC	No Connection		
NC	No Connection		
A0	Analog Input Port 2	m0,0,	Returns current analog port value in the following format: A,(0 - 1024)
A2	IR LED Transmitter	00,0,	DIGITAL IR Transmitter Module output pin (such as DFRobot – DFR0095 part). Send Hex value b3e2cb07 in IR message output
A4	Servo Motor Output	g(0 - 180),0,	Servo command parameter range is 0 to 180
D2	IR Receiver sensor input		If an IR receiver such at the DFRobot Digital IR Receiver Module (DFR0094)

			or Sparkfun IR Receiver Diode (SEN-10266) is connected to this pin the IR value received is written to the Bluetooth serial output in the following format: I, (Hex value)
D4	Servo Motor Output	f(0 - 180),0,	Servo command parameter range is 0 to 180
D6	Servo Motor Output	e(0 - 180),0,	((?)
Pin Label	IR Remote Button /Description	IR Command Hex value	Comments
D6	Right Curser (Head Right)	c837d827	decrease by 10
D6 D6	`	c837d827 c837f807	decrease by 10 increase by 10
-	Right)		J
D6	Right) Left Curser (Head Left)	c837f807	increase by 10
D6 D6	Right) Left Curser (Head Left) Enter (Head Center)	c837f807 c837c8b7	increase by 10 center
D6 D6 D4	Right) Left Curser (Head Left) Enter (Head Center) Ch + (Right Arm Down)	c837f807 c837c8b7 c837c03f	increase by 10 center increase by 10
D6 D6 D4 D4	Right)  Left Curser (Head Left)  Enter (Head Center)  Ch + (Right Arm Down)  Ch - (Right Arm Down)  Up Curser (Right Arm	c837f807 c837c8b7 c837c03f c837e01f	increase by 10 center increase by 10 decrease by 10
D6 D6 D4 D4 D4	Right) Left Curser (Head Left) Enter (Head Center) Ch + (Right Arm Down) Ch - (Right Arm Down) Up Curser (Right Arm Center)	c837f807 c837c8b7 c837c03f c837e01f c837c0bf	increase by 10 center increase by 10 decrease by 10 center

# **Additional Commands**

 $z0,0, \rightarrow$  Print current software version/info to Bluetooth serial output