Siren sensor

Z-Wave Command Classes:

COMMAND_CLASS_BASIC

COMMAND_CLASS_VERSION

COMMAND_CLASS_ZWAVEPLUS_INFO

COMMAND_CLASS_MANUFACTURE_SPECIFIC

COMMAND_CLASS_DEVICE_RESET_LOCALLY

COMMAND_CLASS_POWERLEVEL

COMMAND_CLASS_ASSOCIATION

COMMAND_CLASS_ASSOCIATION_GROUPINFO

COMMAND_CLASS_SWITCH_BINARY

COMMAND_CLASS_SWITCH_ALL