
GD&T Builder Tutorial

Table of Contents

- GD&T Builder Tutorial
 - Table of Contents
 - Introduction
 - Getting Started
 - Installation
 - Interface Overview
 - Main Tab
 - Symbol Buttons
 - Text Input
 - Color Controls
 - Preview Window
 - Zoomed In Example
 - Datum Target Tab
 - Surface Finish Tab
 - Saved Configurations Tab
 - Managing Configurations
 - Theme Customization
 - Theme Categories
 - Keyboard Shortcuts
 - Global Shortcuts
 - Main Tab Shortcuts
 - Datum Target Tab Shortcuts
 - Surface Finish Tab Shortcuts
 - Saved Configurations Tab Shortcuts
 - Tips and Tricks
 - Efficient Symbol Input
 - Working with Configurations
 - Performance Optimization
 - Advanced Features
 - Symbol Shortcuts
 - Composite View
 - Import/Export
 - Macros

Introduction

GD&T Builder is a powerful application designed to create and manage Geometric Dimensioning and Tolerancing symbols and annotations. This tutorial will guide you through all features and functionality of the application.



Getting Started


Installation

- 1. Download the GD&T Builder application
- 2. Run the installer or executable file
- 3. The application will automatically install required fonts and create necessary configuration files

Interface Overview

The application consists of four main tabs:


- Main Tab: Primary GD&T symbol creation and editing
- Datum Target Tab: Specialized datum target symbol creation
- Surface Finish Tab: Surface finish symbol creation
- Saved Configurations Tab: Library of saved GD&T configurations



Main Tab

Symbol Buttons

The Main tab features a comprehensive set of GD&T symbol buttons organized in a grid layout. These can be toggled using the "Show Symbol Buttons" checkbox or Ctrl+B shortcut.




Key features:

- Click any symbol to insert it at the cursor position
- Hover over symbols to see their descriptions
- Basic and Space buttons are always available at the bottom

Text Input

The text input area supports:


- Regular text entry
- Symbol shortcuts (e.g., 'pos' for Position symbol)
- Subscript/Superscript text using the dedicated buttons
- Multi-line input




Color Controls

Color controls allow you to customize the appearance of your GD&T symbols:

- Change Color: Select custom colors for symbols
- Color Lines Only: Apply color only to symbol lines
- Color Fill: Fill symbols with selected color
- Fill Boxes: Automatically fill symbol boxes









Preview Window

The preview window shows a real-time preview of your GD&T configuration:

- Use Ctrl+Mouse Wheel to zoom in/out
- Preview updates automatically as you type
- Shows exact representation of what will be copied



Zoomed In Example




Datum Target Tab

The Datum Target tab provides specialized tools for creating datum target symbols:

- Movable/Fixed datum target options
- Text placement in multiple positions

- Color controls specific to datum targets
- Preview with zoom functionality






Surface Finish Tab

The Surface Finish tab offers tools for creating surface finish symbols:


- Three end style options (Basic, Material Removal, Material Removal Prohibited)
- Multiple text input fields for comprehensive annotations
- Lay symbols for surface characteristics
- Preview with zoom functionality



Saved Configurations Tab

The Saved Configurations tab serves as a library for your GD&T configurations:

- Save frequently used configurations
- Edit existing configurations
- Preview all saved configurations
- Search and filter capabilities
- Copy configurations as images or keymap text



Managing Configurations

- 1. Right-click to edit any configuration
- 2. Double-click to copy to clipboard
- 3. Use search box to filter configurations
- 4. Use keyboard shortcuts for quick actions






Theme Customization


GD&T Builder offers extensive theme customization:

- Multiple built-in themes
- Dark and light mode options
- Custom color schemes



Theme Categories

- Default Themes
- Dark Themes
- Professional Themes
- Custom Themes



Keyboard Shortcuts

GD&T Builder provides comprehensive keyboard shortcuts for efficient workflow:

Global Shortcuts

GUI Shortcuts		
Shortcut	Action	Tab
	Global Shortcuts	
Ctrl+1	Switch to Main tab	All
Ctrl+2	Switch to Datum Target tab	All
Ctrl+3	Switch to Surface Finish tab	All
Ctrl+4	Switch to Saved Configurations tab	All
Ctrl++	Zoom In GUI	All
Ctrl+-	Zoom Out GUI	All
Ctrl+0	Reset GUI Zoom	All

Main Tab Shortcuts

Main Tab		
Ctrl+A	Copy Image	Main
Ctrl+B	Show Symbol Buttons toggle	Main
Ctrl+S	Copy Text	Main
Ctrl+D	Change Color	Main
Ctrl+F	Save Configuration	Main
Ctrl+C	Use Composite View Main	
Ctrl+5	Color Lines Only	Main
Ctrl+T	Place Cursor Back to Input Window	Main
Ctrl+6	Color Fill Main	
Ctrl+7	Fill Boxes	Main

Datum Target Tab Shortcuts

Datum Target Tab		
Ctrl+A	Copy Image	Datum Target
Ctrl+D	Change Color	Datum Target
Ctrl+M	Moveable Target	Datum Target
Ctrl+N	No Color	Datum Target
Ctrl+8	Color Lines	Datum Target
Ctrl+9	Color Fill	Datum Target

Surface Finish Tab Shortcuts

Surface Finish Tab		
Ctrl+A	Basic End Style	Surface Finish
Ctrl+S	Material Removal End Style	Surface Finish
Ctrl+D	Material Removal Prohibited End Style Surface Finis	
Ctrl+P	Preview Toggle ►/▼	Surface Finish
Ctrl+F	Copy Image	Surface Finish
Ctrl+G	Change Color	Surface Finish
Ctrl+Z	No Color	Surface Finish
Ctrl+X	Color Lines	Surface Finish
Ctrl+C	Color Fill	Surface Finish

Saved Configurations Tab Shortcuts

Saved Configurations Tab		
Right Click	Edit	Saved Configurations
Double Click on Image	Copy Image to Clipboard	Saved Configurations
Left Click, Ctrl+C	Copy Image to Clipboard	Saved Configurations
Left Click, Ctrl+Shift+C	Copy Keymap Text	Saved Configurations
Left Click, Ctrl+L	Load Selected Config to Main Tab	Saved Configurations
Left Click, Del	Delete Selected Configuration	Saved Configurations
Ctrl+Mousewheel	Change Zoom Level	Saved Configurations
Type shortcuts (e.g., 'pos')	Insert Symbols in Search Box	Saved Configurations
Ctrl+V	Composite View	Saved Configurations
Ctrl+B	Color Lines Only	Saved Configurations
Ctrl+F	Color Fill	Saved Configurations
Ctrl+D	Change Color	Saved Configurations
Ctrl+R	Refresh Configurations List	Saved Configurations
Ctrl+S Save Changes		Saved Configurations

Tips and Tricks

Efficient Symbol Input

- Use keyboard shortcuts for common symbols
- Learn symbol shortcut patterns
- Use the symbol button grid for reference

Working with Configurations

- Save frequently used configurations
- Use search to quickly find configurations
- Organize similar configurations together

Performance Optimization


• Use appropriate zoom levels

- Manage saved configurations regularly
- Utilize keyboard shortcuts for faster workflow

Advanced Features

Symbol Shortcuts

The application supports text shortcuts for quick symbol insertion:



Input Shortcuts		
Shortcut	Name	Symbol
	Surface Profile	
pro	Profile of a Line	\cap
	Projected	©
pos	Position	Ф
per	Perpendicularity	
	Parallelism	
par	Parting Line	<u></u>
dia	Diameter	Ø
dia	Spherical Diameter	sø
cou	Countersink	
Cou	Counterbore	ш
dep	Depth	₹
bas	Basic	Basic
	Runout	1
run	Total Runout	21
ang	Angularity	_
cir	Circularity	0

str	Straightness	_
fla	Flatness	
cyl	Cylindricity	A/
sym	Symmetry	=
deg	Degree	o
	Radius	R
rad	Spherical Radius	SR
	Controlled Radius	CR
dyn	Dynamic Profile Tolerance Modifier	Δ
bet	Between Indicator	+ +
tra	Translation	D
slo	Slope	
tap	Conical Taper	\triangleright
arc	Arc Length	^
sqr	Square	
plu	Plus-Minus	±
sta	Statistical Tolerance	⑤
con	Continuous Feature	(F)
con	Concentricity	0

fre	Free State	(Ē)
ind	Independency	①
lmc	Least Material Condition	O
mmc	Maximum Material Condition	M
rfs	RFS	©
tan	Tangent Plane	Ū
uni	Unilateral	0
all	All Around	<u></u> ,⊱_
dil	All Over	₽
ori	Origin	← Φ

		-1/8 Space
		- 1/4 Space
spa	Space	- 3/4 Space
		- Single Space
		- Double Space

FLAME CUTTING
SNAGGING
SAWING
PLANING

		SHAPING
		DRILLING
		CHEMICAL MILLING
		ELECT. DISCHARGE MACH
		MILLING
		BROACHING
		REAMING
		ELECTRON BEAM
		LASER
		ELECTRO-CHEMICAL
		BORING
		TURNING
		BARREL FINISHING
sur	Surface Finish Treatments	ELECTRO GRINDING
		ROLLER BURNISHING
		GRINDING
		HONING
		ELECTRO-POLISH
		POLISHING
		21 / 37

LAPPING
SUPERFINISHING
SAND CASTING
HOT ROLLING
FORGING
PERM MOLD CASTING
INVESTMENT CASTING
EXTRUDING
COLD ROLLING
DRAWING
DIE CASTING

		Р	
	Particulate	c	
	Circular		
	Multidirectional	M	
lay	Radial	R	
	Angular	X	
	Perpendicular		
	Parallel		
		=	


Composite View


• Enables advanced symbol combinations

- Automates complex GD&T notation
- Provides professional-quality output












• Normally, enabling the "Use Composite View" would merge the rows that have a common GD&T symbol, up to 4 rows. In this case, it would be the profile of a surface symbol. But, if we need to do something to the below example, we have to change our input approach to meet this scenario.



• Enter the composite portion first in the input. Make sure you enable the "Use Composite View" button. Since there is no value placed before the decimal place, I used a 3/4 space in place of it.



- Click on the "Copy Text" button
- Clear out current Input area and paste what was copied. You now should see the image below.




• Finish the 3rd and 4th rows Input as how you would normally enter them. As a side note, any text you want to place outside the boxes needs to be enclosed by quotation marks. The input of the 3rd row would look like this: o ë.010 "4X".

```
Input

ÝóÞçë_._0_4_0__|A}
äôåçë_._0_2_0__|A}
º ë.010 "4X"
. ë.005


Subscript Superscript
```

• You should now see the picture below.




Import/Export

- Save configurations for future use
- Export as images with transparency




• Copy keymap text for CAD systems and/or other software environments (works with PTC Creo)

In the app, you would create the symbol and click on the Copy Text button. In Microsoft Word for instance, once you choose the font "Y14.5-2018", it will look like this:




In PTC Creo for instance, you would store the font file "Y14.5-2018_mod_v3.ttf" within the folder that stores the fonts for your CAD software, such as C:\Program Files\PTC\Creo11\Creo 11.0.0.0\Common Files\text\fonts


After placing the text in your drawing and picking the Y14.5-2018 font, make sure you set the line spacing to 0.875




Also, if you have subscript and/or superscript and you want to put it in your drawing, this app can support that also. It can also handle composites. If it detects a subscript and/or superscript, a message will popup


once you click on the Copy Text button. Currently, the subscript/superscript conversion is working in Creo Parametric and also within Microsoft Word/Outlook.








If you pick the Microsoft Word/Outlook option, another popup will show and give you further instructions in showing the copy text with the subscript/superscript properly.











Macros

• Position, Flatness, Profile Macros

Macros Reference					
Name	Keystroke	Input	Keymap		
	Position Macros				
position_1row	p.	; Ø1 A B C	⊕ Ø1ABC		
position_2rows	p	¿ Ø1 АВС ¿ Ø1 АВ	+ Ø1ABC + Ø1AB		
position_3rows	p	¿ Ø1 A B C ¿ Ø1 A B ¿ Ø1 A	+ Ø1ABC + Ø1AB + Ø1A		
position_4rows	p	¿ Ø1 A B C ¿ Ø1 A B ¿ Ø1 A ¿ Ø1	+ Ø1ABC + Ø1AB + Ø1A + Ø1A		
	Flatnes	s Macros			
flatness_1row	f.	, 1 A B C	Z IABC		
flatness_2rows	f	, 1 A B C , 1 A B	☑ 1ABC ☑ 1AB		
flatness_3rows	f	, 1 A B C , 1 A B , 1 A	ZIABC ZIAB ZIA		
flatness_4rows	f	, 1 A B C , 1 A B , 1 A , 1	I I A B C I I A B I I A I I A I I A		

Profile Macros			
profile_1row	s.	º 1 A B C	(A) IABC
profile_2rows	S	º 1 A B C º 1 A B	(A) IABC (A) IAB
profile_3rows	S	º 1 A B C º 1 A B º 1 A	A TABC A TAB A TA
profile_4rows	S	º 1 A B C º 1 A B º 1 A º 1	A TABC A TAB A TA A T

• Arc Length Macros

Arc Length Macros			
arc_1_number	a.	1ìî^{®}	1
arc_2_number	a	11îî^{®}	11
arc_3_number	a	111^{®î}	111
arc_4_number	a	1111^{®ì}	1111
arc_5_number	a	11111^{®îë}	11111

• Subscript and Superscript Macros

Script Macros			
subscript	min	_{{}}	X ₁
superscript	max	^{}	X ¹

This tutorial covers the core features of GD&T Builder. For additional support, questions, or requests, please contact by email or refer to the Github page.

email: mtiblow_github@proton.me

Github page: https://github.com/mtiblow/GDT-Builder

End of Tutorial

© 2024-2025 Matthew Tiblow. All rights reserved.