

PCT-AIO Compression Tool Instruction Guide

RG6, RG59 "F" and "IEC" Connectors



Lift top gate to open and insert connector.



Close top gate.



Close handle to compress.



Swing the 6/59 gate out to the side of the tool.

RG7, RG11, 320QR Connectors



Open the 7/11 top gate and insert connector



Close top gate. Then close handle to compress.

RCA, BNC, TRS-RA (Right Angle) Connectors



Remove mandrel piece from plunger.



Lift top gate to open and insert connector.



Close top gate. Then close handle to compress.

Note: When not using the tool, the mandrel should be stored in the plunger to prevent breakage of the retention chain.

