Hydro

Lettuce hydroponic system: how it works, what has been built, and how to run it

Raspberry Pi 5 · ESP32 · Sipeed MaixCAM · MQTT · Python
Version 6 · Status as of 15 October 2026 · Repository: github.com/muaz8172/hydro (private)

Contents	
1. System overview	What each part does and how data flows
2. Hardware and wiring	Pins, dividers, the two 2-channel relays, camera link
3. How it works	Sensors, pump control, logging, camera, AI model, dashboard, dataset
4. What has been done	Progress, commits and current status
5. How to run the system	First-time setup, daily use, commands
6. Calibration	EC, pH and tank level; target ranges
7. Troubleshooting	Common problems and fixes
8. Known issues and next steps	Safety items and roadmap

What's new in version 6

• **Steadier sensor readings (gap filling):** the DHT22 is read every 4 s, corrupt jumps (e.g. a reading of exactly half the real value) are dropped, and the last good temperature, humidity and water level are held for 20 s instead of going blank. Ultrasonic ghost echoes are ignored and Tank LOW needs 3 low readings in a row, so one bad echo no longer stops the pumps. Verified on the ESP32 on 15 Oct. See section 3.2.

• **pH** is now slope × V + offset from the pH 7 / pH 4 calibration, and **EC** calibration accepts this probe's buffer readings. The Air Temperature tile reads Cold / Stable / Hot.

• Version 5: **New ESP32 pin layout:** Pump In (Pump A) D18, Pump Out (Pump B) D19, Pump N (sampling pump) D21, DHT22 D4, EC D32, pH D33 (both ADC1), HC-SR04 TRIG D16 / ECHO D17 (via its divider). No strapping or flash pins are used. Pump logic, commands and JSON fields are the same. Rewire before re-flashing.

• Version 4: **Minimalist dashboard** titled Hydroponic System Monitoring, with tabs Live Monitoring, Sensor History and Calibration, and DM Sans + Fraunces fonts (stored offline). The camera frame is square and shows the same centre crop the stage model sees (the dataset is 224×224). Sensor tiles show a green dot or a short tag (LOW, HIGH, DRIFT); raw values move to hover tooltips. New Plant vision card (canopy with change vs yesterday, yellowing, green index) and an animated water tank driven by the ultrasonic level sensor. Sensor History has area charts with value tags, time-in-target rings, pump and water-level bars, and a paged table. See section 3.6.

• **Pump start delay:** after every ESP32 boot (Pi reboot or USB replug) the sampling pump waits 30 s and Pump A/B wait 60 s before auto control turns them on. See section 3.2.


• Version 3: **New plant dataset:** 88 lettuce photos, balanced across the three stages (seedling 30, vegetative 29, matured 29), all resized to 224×224 for training. Before: 41 photos with only 6 vegetative.

• **Growth-stage model retrained** (`backend/models/stage.onnx`): 86 % test accuracy, vegetative recall 79 % (target raised from 50 % to 70 %). See section 3.5.

• Version 2 changes are still in place: two 2-channel relays (section 2.1), air temperature target 25–36 °C (`temp_ok`), the three dashboard tabs, and the `frontend/`, `backend/`, `firmware/` layout.

1. System overview

The system grows lettuce in a hydroponic tank and watches it all day without internet. An **ESP32** reads the water and air sensors and switches the pumps through two 2-channel relays. A **Raspberry Pi 5** collects everything, stores it, and serves a dashboard. A **Sipeed MaixCAM** camera photographs the plants so their health, growth stage and size can be checked.



Everything talks through **MQTT** (the Mosquitto broker on the Pi). Each program publishes on its own topic, and the dashboard listens to all of them live.

MQTT topic	Sent by	Contents
`hydro/sensors`	bridge.py	One JSON reading every 2 s from the ESP32, plus `log_id` and `row` that match the CSV line
`hydro/log`	bridge.py	Text messages from the ESP32 (calibration, pump ON/OFF, tank low)
`hydro/cmd`	you / dashboard	Commands forwarded to the ESP32 (e.g. `status`, `ph7`, `pumpauto`, `sampleoff`)
`hydro/vision`	vision.py	Plant result (JSON) every 10 s: health, stage, size
`hydro/vision/image`	vision.py	The latest camera photo (JPEG, retained)
`hydro/vision/status`	vision.py	`online` or `offline: reason`
`hydro/vision/cmd`	dashboard	`snap` = save a photo to disk now

2. Hardware and wiring


Part	Pins	ESP32 / Pi	Notes
DHT22 (air temp / humidity)	DATA / VCC / GND	GPIO4 (D4) / 3.3 V / GND	10 k pull-up if the module has none
EC sensor (EC V2.1)	A0 / VCC / GND	GPIO32 (D32, ADC1) / 3.3 V / GND	T1 unconnected; EC maths built into the firmware
pH sensor (PH-4502C)	Po / V+ / G	GPIO33 (D33, ADC1) via divider / 5 V / GND	10 k / 20 k divider is required
HC-SR04 (water level)	TRIG / ECHO / VCC / GND	GPIO16 (D16) / GPIO17 (D17) via divider / 5 V / GND	1 k / 2 k divider on ECHO; mounted above the tank, facing down
Relay 1 (2-channel)	IN1 / IN2 / VCC / GND	GPIO18 (Pump In) / GPIO19 (Pump Out) / 5 V / GND	Active LOW; GND shared with the ESP32
Relay 2 (2-channel)	IN1 / IN2 / VCC / GND	GPIO21 (Pump N, sampling) / not connected / 5 V / GND	Active LOW; IN2 is a spare channel; GND shared with the ESP32
ESP32 → Pi	USB	/dev/esp32 (udev rule)	115200 baud, one JSON line every 2 s
MaixCAM → Pi	USB-C	10.122.173.1 (camera), 10.122.173.100 (Pi)	Appears as a USB network adapter; the Pi gets its address automatically

Never put more than 3.3 V on an ESP32 pin. The pH module and the HC-SR04 run on 5 V, which is why their outputs go through voltage dividers. Keep the pH and EC probes in separate containers when testing; they interfere with each other.

Safe pins only. No boot strapping pins (0, 2, 5, 12, 15) or flash pins (6–11) are used. EC and pH are on ADC1 (GPIO32/33), which keeps working if Wi-Fi is ever turned on; ADC2 pins stop reading analog while Wi-Fi is on.

2.1 Relays: two 2-channel modules

The pumps are switched by **two identical 2-channel relay modules**. The old 1-channel relay for the sampling pump has been removed. Relay 1 doses the nutrients; relay 2 runs the sampling pump and keeps one channel free.



Relay	Channel	ESP32 pin	Drives	Firmware name	JSON field
Relay 1	IN1	GPIO18	Pump In (Pump A)	`PUMP_A_PIN`	`pump_a`
Relay 1	IN2	GPIO19	Pump Out (Pump B)	`PUMP_B_PIN`	`pump_b`
Relay 2	IN1	GPIO21	Pump N (sampling pump)	`SAMPLE_PIN`	`pump_sample`
Relay 2	IN2	—	Spare, not connected	—	—

- Both modules share one setting in `Full_code.ino`: `RELAY_ACTIVE_LOW true` (LOW = relay ON). If your modules turn ON with HIGH, set it to `false`. The old separate `SAMPLE_ACTIVE_LOW` setting is gone.
- Relay VCC goes to the ESP32's 5 V, and relay GND must be shared with the ESP32 GND, otherwise the IN signals have no reference.
- At boot every relay pin is set to OFF before it becomes an output, so no pump kicks on while the ESP32 starts. The sampling pump switches on 30 s after start-up and Pump A/B auto control starts after 60 s (see 3.2).
- The spare channel (relay 2 IN2) is free for a future grow-light relay (see section 8). It is not used by the firmware yet.

> **Mains safety.** If a pump or a future grow light runs on mains voltage, keep the relay contacts and mains wiring in a closed box, away from the water, and use a fused supply.

3. How it works

3.1 Sensors (ESP32)

Every 2 seconds the ESP32 reads all sensors and prints one JSON line over USB:

```
{"temp":28.1,"hum":70.2,"ec":1.45,"ec_low":false,"ph":6.20,"level":9.8,"level_pct":72,
 "level_low":false,"ec_mv":237,"po_mv":2650,"dist_cm":10.2,
 "pump_a":true,"pump_b":true,"pump_auto":true,"pump_sample":true,"temp_ok":true}
```

Field	Meaning
`temp, hum`	Air temperature (°C) and humidity (%) from the DHT22
`ec`	Electrical conductivity (mS/cm): how much nutrient is in the water
`ec_low`	true = below the ESP32's measuring floor (about 0.6 mS/cm), e.g. plain water
`ph`	pH value of the nutrient solution
`level, level_pct`	Water height (cm) and tank level (%) from the HC-SR04, after tank calibration
`level_low`	true = tank below 20 %
`pump_a, pump_b`	Relay 1 IN1 / IN2 state (true = running)
`pump_sample`	Relay 2 IN1 state: the sampling pump (true = running)
`pump_auto`	true = automatic EC/pH control, false = manual commands
`temp_ok`	true = air temperature inside 25–36 °C, null = no DHT22 reading. Only reported; nothing heats or cools
`ec_mv, po_mv, dist_cm`	Raw sensor values, used for calibration and debugging

3.2 Pump control (ESP32)

The firmware keeps the nutrient solution inside the lettuce target: EC 1.2–1.8 mS/cm and pH 5.5–6.5.

- **Auto mode** (on at boot): Pump A and Pump B (relay 1) run together while EC or pH is outside the target, and stop when both are inside. They start again if either drifts out. `ec_low` counts as under target.
- **Sampling pump** (relay 2 IN1): runs all the time to move water past the sensors. It is not affected by EC/pH. `sampleoff` stops it (e.g. for maintenance), `sampleon` starts it again.
- **Tank-low protection**: when the tank is below 20 % (after tank calibration) all three pumps, on both relays, are forced OFF, in auto and manual, so they never run dry. `pumpaon`, `pumpbon` and `sampleon` are refused until the tank is refilled.
- **Manual**: `pumpaon`, `pumpaoff`, `pumpbon`, `pumpboff` switch to manual; `pumpauto` goes back to auto.
- A pH reading that is not a number stops Pumps A and B for safety.
- **Start delay**: after every ESP32 boot (Pi reboot, bridge restart or USB replug) the sampling pump waits 30 s (`SAMPLE_START_DELAY`) and Pump A/B wait 60 s (`PUMP_START_DELAY`) before auto turns them on. Manual commands are not delayed.

- Air temperature is only checked against 25–36 °C and reported as `temp_ok`. No relay acts on it.
- **Gap filling**: the DHT22 is read every 4 s (`DHT_INTERVAL`); a failed read or a jump over 5 °C / 15 % (a corrupt read) is dropped, and the last good temperature, humidity and water level are sent for up to 20 s (`HOLD_MS`) before they go null. Ultrasonic echoes farther than the empty tank are ghosts and are ignored, and `level_low` needs 3 low readings in a row (`LOW_CONFIRM`), so one bad echo cannot stop the pumps.

Situation	Pump A + Pump B (relay 1)	Sampling pump (relay 2)
EC or pH outside target (auto)	ON	ON
EC 1.2–1.8 and pH 5.5–6.5 (auto)	OFF (target reached)	ON
pH reading invalid (auto)	OFF (safety)	ON
Tank low (calibrated tank)	OFF, also in manual	OFF
`sampleoff` sent	unchanged	OFF until `sampleon`

3.3 Data logging (Raspberry Pi, backend/bridge.py)

`bridge.py` reads the ESP32's serial port, publishes each reading to MQTT and writes it to a CSV file. Each time the ESP32 connects (plugged in, Pi reboot, bridge restart) a new file starts:

```
data/logs/log_0007_2026-09-23_07-28-38.csv
log_id,row,time,temp,hum,ec,ec_low,ph,level,level_pct,level_low,dist_cm,
ec_mv,po_mv,pump_a,pump_b,pump_auto,pump_sample
```

True/false values are stored as 1/0 and missing values as empty cells. The files open directly in Excel or LibreOffice Calc. `temp_ok` is not a CSV column; it can be worked out from `temp`. The `data/` folder is not uploaded to GitHub.

3.4 Plant camera (MaixCAM + backend/vision.py)

The MaixCAM is a small computer with its own camera and screen. Its `hydro_cam` app starts at boot, shows a live preview (to aim the camera) and hands a fresh photo to the Pi over the USB cable.

- Every **10 s** `vision.py` takes a photo, checks it and publishes it to the dashboard.
- Every **15 min** (or with **Save photo now**) it also saves the photo to `data/vision/<date>/` and adds a row to `vision_log.csv`. Photos older than 30 days are deleted, except one per day.
- It also writes `data/vision/live/latest.jpg` so the dashboard can still show the photo if the live MQTT link is blocked.
- When a plant is in view it runs the growth-stage model (section 3.5) and adds `stage`, `stage_conf` and `size` to the result.

Health result	Rule (leaf colour check)
Healthy	Yellow/brown share of the leaf area is 8 % or less
Check leaves	Yellow/brown share above 8 %
Unhealthy	Yellow/brown share above 20 %
No plant in view	Less than 2 % of the photo is green (camera aim, focus or grow light)

```
{"ts": 1790161885, "image": "2026-09-23/07-11-25.jpg", "canopy_pct": 34.2,
 "yellow_pct": 3.1, "greenness": 0.41, "health": "healthy", "health_reasons": [],
 "stage": "vegetative", "stage_conf": 0.87, "size": "medium"}
```


3.5 Growth-stage AI model

`backend/train/train_stage.py` trains a small image model (MobileNetV3-Small, pretrained on ImageNet) on `dataset/lettuce_224/`, on the Pi 5 itself, in about 40 minutes. It compares two versions, a classifier and a regression model, with 5-fold cross-validation: the photos are split into 5 groups, and each group is tested by a model trained on the other four, so every photo is tested once by a model that never saw it. The better one is retrained on all photos and exported to `backend/models/stage.onnx`, which `vision.py` runs with ONNX Runtime from the `.venv` environment. The full report is `backend/models/stage_report.md`.

Result (88 photos, retrained 29 September 2026)	Value
Model chosen	A: classifier (B, regression, reached 76 %)
Test accuracy	86 % (always-guess-one-stage baselines: 34 % and 33 %)
Train accuracy	100 % (train–test gap 13 %: acceptable)
Mean absolute error	0.16 stage (RMSE 0.45)
Seedling / matured recall	97 % / 83 %
Vegetative recall (target 70 %)	79 % (23 of 29): target met
Old model (41 photos) on the 48 new photos it never saw	Old: 60 %, vegetative 29 %. New: 81 %, vegetative 79 %
Speed on the Pi 5	about 10 ms per photo

`stage` is seedling, vegetative, matured, or uncertain below 60 % confidence. `size` follows the stage (seedling = small, vegetative = medium, matured = large). The model only runs when the colour check finds a plant, because it knows only the three stages and would label anything as one of them.

3.6 Dashboard

A web page served by `backend/server.py` on port 8000 (page files in `frontend/`). Live values come from Mosquitto's websocket (port 9001); history comes from the session CSVs. Everything works offline (mqtt.js, uPlot and the DM Sans and Fraunces fonts are in `frontend/vendor/`).

Tab	What it shows
Live Monitoring	Header: Live dot, ESP32 and Camera shown as Connected (green) or Disconnected/Offline (red). Left: the camera photo in a square frame, the same centre crop the stage model sees, with health, growth stage, size, confidence and Save photo. Right: tiles for pH, EC, Air Temperature 25–36 °C (blue Cold / Stable / red Hot, Stable turns amber near the edges) and humidity with a meter and a green dot or LOW/HIGH/DRIFT tag, plus pump mode + tank state; pump rows; Plant vision (canopy % with change vs yesterday, yellowing % with Normal under 8 %, green index 0–1); an animated water tank filled to the ultrasonic level, with the 20 % dry-run line, an OK/LOW tag, water height and distance to the surface. A short sensor gap (under 30 s) keeps the last value greyed out, with 'Last reading N s ago' in the tooltip. Hover for details and raw values; click a tile for Sensor History
Sensor History	Four area charts (pH purple, EC teal, air magenta, humidity blue) for 1 h, 24 h or 7 days, with dot markers and a tag on the highest value; hover shows values on all four. Below: time in target as ring gauges, nutrient pump minutes per slot as bars, the average of each sensor, water level as capsule bars and plant stage over time. Table view shows every reading, newest first, one page at a time (as many rows as fit the screen); CSV downloads the range
Calibration	Step-by-step EC, pH and tank wizards. Capture buttons stay disabled until the reading is steady; the ESP32's replies show in the page; stored calibration and a hold-to-reset for pH

History API (server.py)	Returns
`/api/history?range=1h|24h|7d`	Readings on a fixed time grid (null = no data)
`/api/actuators/history?range=...`	Pump ON intervals, runs and on-time per pump
`/api/vision/history?range=...`	Rows from `data/vision/vision_log.csv`
`/api/export.csv?range=...`	Every session CSV row in the range, one file

3.7 Plant image dataset

`dataset/lettuce_growth_stages/` holds 88 lettuce photos sorted by growth stage (the folder name is the label). The originals come in different sizes and formats. `dataset/lettuce_224/` has the same photos all converted to the same size, **224×224 JPEG** (rotated upright, centre-cropped to a square, resized), with a `labels.csv` that adds the size. This copy is what the model trains on.

Stage	Folder	Photos	Size label
Seedling	`seedling/`	30	small
Vegetative	`vegetative/`	29	medium
Matured (ready to harvest)	`matured/`	29	large
Total		**88**	

The 28 September update added 48 new photos to the 40 kept from the first set, so the classes are now balanced. One photo was in the dataset twice, once as vegetative (`vegetative_012.jpg`) and once as matured (`matured_022.jpg`); both copies were removed because its stage is unclear. All photos are still from the internet: add labelled photos from the Hydro camera (`data/vision/`), then retrain.

4. What has been done

Area	Work	Status
ESP32 firmware	DHT22, EC and pH with calibration stored in EEPROM	Done
ESP32 firmware	HC-SR04 water level with tank calibration	Done
ESP32 firmware	Pump A/B auto control to EC 1.2–1.8 and pH 5.5–6.5; manual commands	Done
ESP32 firmware	Always-on sampling pump (GPIO21) and tank-low stop for all pumps	Done
ESP32 firmware	Air temperature target 25–36 °C, reported as `temp_ok`	Done
ESP32 firmware	Start delay after boot: sampling pump 30 s, Pump A/B auto 60 s	Done
ESP32 firmware	Gap filling: DHT22 jump reject, 20 s hold for temp/humidity/level, ghost echoes ignored, Tank LOW after 3 lows	Done
Hardware	1-channel relay replaced by a second 2-channel relay (sampling pump on relay 2 IN1; IN2 spare); one shared `RELAY_ACTIVE_LOW`	Done
Hardware	New pin layout: pumps D18 / D19 / D21, DHT22 D4, EC D32, pH D33, HC-SR04 TRIG D16 / ECHO D17; firmware, test sketches and docs updated	Done
Testing	Relay test sketch: relay 1 switched Pump A and Pump B correctly (old pins)	Done
Testing	Rewire to the new pins, re-flash, check every sensor and relay; re-check EC and pH against the buffers	To do
Testing	Sampling pump on relay 2: check with `sampleoff` / `sampleon`	To do
Raspberry Pi	Serial → MQTT bridge with auto-reconnect and fixed /dev/esp32 name	Done
Raspberry Pi	Bridge runs only while the ESP32 is plugged in, and resets the ESP32 when it opens the port	Done
Raspberry Pi	Mosquitto broker (local TCP + websocket for the dashboard)	Done
Data logging	CSV log per ESP32 connection, including pump columns	Done
Camera	MaixCAM app: auto-start, preview, photo server over USB	Done
Camera	vision.py: live photos, leaf colour health check, photo archive	Done
Camera AI	Growth-stage dataset: 88 photos, balanced (30 / 29 / 29), plus a 224×224 copy with size labels	Done
Camera AI	Growth-stage + size model retrained on 88 photos (86 % test accuracy, vegetative recall 79 %)	Done
Dashboard	Live Monitoring, Sensor History and Calibration tabs; history API and CSV export	Done
Repository	Reorganised into `frontend/`, `backend/`, `firmware/`	Done
Camera AI	Label photos from the Hydro camera and add them to the dataset, then retrain	To do

Area	Work	Status
Sensors	DS18B20 water temperature for EC compensation	To do
Safety	Password/ACL on MQTT; maximum run time for Pumps A/B	To do

Development history (GitHub commits)

Commit	What changed
6214b11	Initial commit: ESP32 firmware, serial bridge, README
5b9a0b8 · 97d15b4	Full README (wiring, calibration, troubleshooting); systemd, Mosquitto and udev configs
9de0bf0 · 27b1f4d	Sensor prototyping sketches, circuit diagram, relay test, HC-SR04 in the firmware
07c09f3 → 6a15904	Pump A/B relay control, tank-low stop, EC/pH target control, always-on sampling pump
bd111f6	CSV session logs with pump state
68434be	Dashboard design plan
2856219	MaixCAM plant camera with leaf colour health check
3272c0d · a066e70	First live dashboard page, with an HTTP fallback for the camera photo
02f4b24 · 8e573f3	System guide (PDF), version 1
24d1ede · 84a2ea7	Lettuce growth-stage dataset (41 photos) and its 224×224 copy with size labels
761e8d3	Growth-stage model, Graphs and Calibration tabs, history server
5094bcc · d537789	Repository reorganised into frontend/, backend/ and firmware/
ff034c4	Air temperature target 25–36 °C (`temp_ok`)
e59755a	1-channel relay replaced by a second 2-channel relay
d131785	New lettuce dataset: 90 photos (30 per stage)
f962ca6	System guide version 2
5dfbf3f	Duplicate photo removed (88 photos), growth-stage model retrained, system guide version 3
827a7ce	Out-of-range pH readings ignored in history; graph axes capped
42c3365	Minimalist dashboard: new header and tab names, square camera frame, Plant vision card, coloured sensor graphs, DM Sans + Fraunces
f90c27b	Charts leave empty time before/after the data blank
be3eed7	Sensor History: area charts with value tags, time-in-target rings, pump and water-level bars, paged table
b79f89d	Live MQTT readings fed straight into the charts (no reload lag)
ee15e07	Animated water tank on Live Monitoring; Water tile removed
989ff9d	EC read on the 11 dB ADC range (millivolts were 3x too high)
6b7d698	Calibration tab saves each EC buffer separately

Commit	What changed
b89f97e	EC conversion and calibration built into the firmware; DFRobot_EC removed (its calibration() crashed every EC save)
d63ccb6	Crash probes removed; EC calibration verified to survive a replug
27a3ecb	Docs: EC calibration is built into the firmware
f8898e1 · 4b692ae	Bridge starts when the ESP32 is plugged in and stops when it is unplugged; it resets the ESP32 on connect
aa305f1	Pump start delay after ESP32 boot (sampling 30 s, Pump A/B 60 s)
98d2714	System guide version 4
9680cb3	ESP32 pins moved: pumps D18/D19/D21, DHT22 D12, HC-SR04 TRIG D33 / ECHO D32
8e067ea · 58c1124	System guide version 5: safe pin layout (no strapping pins; EC/pH on ADC1 GPIO32/33, DHT22 GPIO4, HC-SR04 GPIO16/17)
2ee2f5d · d93383c	EC: built-in 1413 K from the measured buffer; calibration wizard recovers after an ESP32 restart
283c29b → b8dfc1d	pH as slope × V + offset from ph7/ph4, defaults from this probe, ADC-limit warning
7094e24 · bbc980e	Air Temperature tile reads Cold (blue) / Stable / Hot
c6a8947	Sensor gap filling in the firmware; dashboard greys held values
(this version)	System guide version 6

Current status

Part	State
ESP32 + bridge	Running · log #0117 (15 Oct)
Firmware	Updated · gap-filling build (c6a8947) flashed and checked on 15 Oct: temperature, humidity and level read on every row, no false Tank LOW
Mosquitto	Running
MaixCAM	Running · photos reach the Pi; aim the camera at the plants
Stage model	Updated 29 September 2026 · retrained on 88 photos; restart `hydro-vision` to load it
vision.py / dashboard	Running · services enabled, start at every boot
Air temp / humidity	OK · 23.5 °C, 56 % on 15 Oct (below the 25–36 °C band: Cold)
pH probe	OK · 6.2–6.3 and steady on 15 Oct
Water level	OK · 30 % (distance 15.9 cm) and steady on 15 Oct
EC	Check · 0.0 with `ec_low` on 15 Oct while the sampling pump was off; re-check with `sampleon`. Pumps A/B dose nonstop while it reads this

5. How to run the system

5.1 First-time setup

Upload `firmware/Full_code/Full_code.ino` to the ESP32 with the Arduino IDE (board: ESP32 Dev Module; libraries: DHT sensor library and Adafruit Unified Sensor; no EC library is needed, the EC maths and calibration are built into the sketch). Then on the Pi:

Re-flashing later: always upload the latest `Full_code.ino` from GitHub (pull first; an old copy on the upload computer looks like a flash that did not work). If you upload from the Pi, run `sudo systemctl stop hydro-bridge` first, because the bridge holds the serial port. After the upload, `journalctl -u hydro-bridge -f` should show "# Hydro ESP32 ready" and "# Start delay: sampling pump in 30 s, Pump A/B in 60 s".

```
sudo apt install mosquitto mosquitto-clients python3-serial python3-paho-mqtt python3-pil
cd ~/hydro
sudo cp backend/mosquitto/local.conf /etc/mosquitto/conf.d/
sudo cp backend/udev/99-esp32.rules /etc/udev/rules.d/
sudo udevadm control --reload-rules && sudo udevadm trigger
sudo usermod -aG dialout $USER            # then reboot
sudo systemctl restart mosquitto
```

Python environment for the growth-stage model (one time):

```
cd ~/hydro
python3 -m venv .venv
.venv/bin/pip install torch torchvision --index-url https://download.pytorch.org/whl/cpu
.venv/bin/pip install -r backend/train/requirements.txt
```

Install the camera app on the MaixCAM (one time):

```
scp -r ~/hydro/maixcam/hydro_cam root@10.122.173.1:/maixapp/apps/
ssh root@10.122.173.1 'echo hydro_cam > /maixapp/auto_start.txt && reboot'
ssh root@10.122.173.1 passwd          # change the factory password
```

5.2 Install the three services

```
cd ~/hydro
sudo cp backend/systemd/hydro-bridge.service backend/systemd/hydro-vision.service \
        backend/systemd/hydro-dashboard.service /etc/systemd/system/
sudo systemctl daemon-reload
sudo systemctl disable hydro-bridge     # drop the old start-at-boot link, if any
sudo systemctl enable --now hydro-bridge hydro-vision hydro-dashboard
```

hydro-vision and hydro-dashboard start at every boot. hydro-bridge is tied to the ESP32 (dev-esp32.device from the udev rule): plugging the ESP32 in, or booting with it attached, starts the bridge, and unplugging it stops the bridge. When the bridge opens the port it resets the ESP32, so every connect starts a new CSV log and a new pump start delay.
If vision.py or the dashboard are still running from a manual start, stop them first: `pkill -f vision.py; pkill -f server.py`

5.3 Daily use

- Power on the Pi with the ESP32 and the MaixCAM plugged in by USB. All services start by themselves.
- Open the dashboard: `http://localhost:8000` on the Pi, or `http://<pi-ip>:8000` from a phone on the same WiFi (find the IP with `hostname -I`).
- Check the header at the top right: Live, ESP32 and Camera should be green.
- Check the pump cards: Sampling should show ON (relay 2) from 30 s after start-up, unless the tank is low or `sampleoff` was sent. Pumps A/B follow EC/pH from 60 s after start-up.

- Aim the camera at the lettuce using the preview on the MaixCAM screen. Take photos under the grow light.

5.4 Useful commands

Command	What it does
`systemctl status hydro-bridge hydro-vision hydro-dashboard`	Are the services running?
`journalctl -u hydro-bridge -f`	Follow the bridge log (ESP32 messages, new CSV files)
`journalctl -u hydro-vision -f`	Follow the camera log (saved photos, health and stage results)
`mosquitto_sub -t 'hydro/#' -v`	Watch everything on MQTT (the image topic prints binary)
`mosquitto_pub -t hydro/cmd -m status`	Ask the ESP32 for its calibration, pump and sampling pump state
`mosquitto_pub -t hydro/cmd -m pumpauto`	Put Pumps A and B back in automatic mode
`mosquitto_pub -t hydro/cmd -m sampleoff`	Stop the sampling pump (relay 2); `sampleon` starts it
`mosquitto_pub -t hydro/vision/cmd -m snap`	Save a camera photo now
`~/hydro/.venv/bin/python ~/hydro/backend/vision.py --once`	Test the camera: one photo, print the result
`.venv/bin/python backend/vision.py --stage photo.jpg`	Run the stage model on a photo file
`.venv/bin/python backend/train/train_stage.py`	Retrain the stage model (about 40 min), then restart hydro-vision
`.venv/bin/python docs/guide/build_guide.py`	Rebuild this guide (PDF)
`ls -lt ~/hydro/data/logs | head`	Newest sensor CSV logs
`curl http://10.122.173.1:8080/status`	Is the camera app answering?
`sudo systemctl restart hydro-bridge`	Restart the bridge (starts a new CSV log)

6. Calibration

Use the dashboard's Calibration tab, the Arduino Serial Monitor (115200, Newline) or `mosquitto_pub -t hydro/cmd -m <command>`. All values are stored in the ESP32 and survive reboots. Check them with `status`.

Sensor	Steps	Expected
EC	`enterec` → probe in 1413 µS/cm buffer → `calec` → `exitec`, then `enterec` → 12.88 mS/cm buffer → `calec` → `exitec`. Each save prints "EC K values written to flash". With nothing saved, the firmware uses a built-in 1413 K of 0.79 (measured 285 mV at 23.5 °C); `status` shows the K in use	~230 mV in 1413 (148–311 accepted), ~2100 mV in 12.88 (1476–2755); K 0.5–1.5
pH	Probe in pH 7 buffer, wait 1–2 min → `ph7` → rinse → pH 4 buffer, wait → `ph4` (`phreset` = defaults)	Slope about 144 mV/pH (this probe)
Tank level	Tank empty → `tankempty` → fill to MAX → `tankfull` (`tankreset` = defaults)	Empty and full at least 3 cm apart; sensor at least 2 cm above MAX

The tank-low pump stop (all pumps on both relays) only works after the tank is calibrated. Before the first pH calibration, zero the module: short the BNC and turn the left potentiometer until `po_mv` ≈ 2500. After use, rinse the pH probe and put the cap back on with its storage solution; the glass bulb must never dry out.

Lettuce target ranges

Parameter	Target	Set in
EC	1.2–1.8 mS/cm (seedlings 0.5–1.0)	`EC_MIN` / `EC_MAX`: pumps act on it
pH	5.5–6.5	`PH_MIN` / `PH_MAX`: pumps act on it
Air temperature	25–36 °C	`TEMP_MIN` / `TEMP_MAX`: reported only (`temp_ok`)
Humidity	50–75 % (placeholder)	Dashboard band only
Water level	above 20 %	`LOW_LEVEL_PCT`: all pumps stop below it

The dashboard bands must match the firmware values; both are listed at the top of `Full_code.ino` and in `frontend/index.html`.

7. Troubleshooting

Problem	Fix
`/dev/esp32` missing	Check `lsusb`, re-plug the cable, reload the udev rules
No data on `hydro/sensors`	`journalctl -u hydro-bridge -f`; close the Arduino Serial Monitor (only one program can use the port)
Sampling pump does not run	Check `pump_sample` in the JSON. If it is true but the pump is off: relay 2 IN1 on GPIO21 (D21), relay 2 VCC on 5 V, GND shared with the ESP32, pump on the CH1 contacts (not CH2). If it is false: less than 30 s since the ESP32 started (start delay), tank low, or `sampleoff` was sent (send `sampleon`)
A relay is ON when it should be OFF	The module is active HIGH: set `RELAY_ACTIVE_LOW` to `false` and re-upload (it applies to both relays)
Pumps A/B never switch	Relay 1 IN1/IN2 on GPIO18/19 (D18/D19); test with `firmware/Relay_Test/`; check the tank is not low and that 60 s have passed since the ESP32 started
pH stuck (e.g. 19.71)	Probe/BNC disconnected or not calibrated; check wiring, then calibrate
`ec_low: true`	Solution below about 0.6 mS/cm (normal for plain water)
Water level empty	HC-SR04 gets no echo: check wiring, the ECHO divider, and that it faces the water
`temp_ok: null`	No DHT22 reading: check the DHT22 wiring (DATA on D4) and pull-up resistor. Blank for the first ~12 s after the ESP32 starts is normal (sensor warm-up)
Readings still blank or jumpy after a flash	The old sketch is still on the ESP32. Check the uploaded file contains `readDistanceHeld` and `LOW_CONFIRM`; with the latest code, temperature and level only go blank after 20 s without a good reading
Pumps switch to MANUAL by themselves	Something sent `pumpaoff` / `sampleoff` on `hydro/cmd`: look for `[cmd]` lines in `journalctl -u hydro-bridge`, then send `pumpauto` and `sampleon`
SD card almost full	`df -h /`. Safe to clear: Trash, Downloads, old `~/.vscode-server/cli/servers/Stable-*` (keep the newest), `sudo journalctl --vacuum-size=100M`, `sudo apt clean`, `npm cache clean --force`. Keep `~/hydro`, `.venv` and `data/logs`
Dashboard shows old data	Hard refresh (Ctrl+Shift+R). If the header says "Live link down", the browser can't reach MQTT on port 9001: restart the browser or turn off HTTPS-Only for the site. The camera photo still updates via HTTP
Stage always empty	vision.py is running without ONNX Runtime: start it from `.venv` (the service does this), and check `backend/models/stage.onnx` exists
Stage looks wrong after retraining	Restart `hydro-vision` so it loads the new model; the old one is kept as `backend/models/stage_old.onnx`
`hydro/vision/status` offline	`ping 10.122.173.1`; check the USB-C cable and that the MaixCAM shows the Hydro Cam preview
MaixCAM freezes / SSH hangs	Two programs used the camera. Reboot the MaixCAM. Never run camera scripts over SSH while its menu is running

Problem	Fix
Health says "No plant in view"	Aim the camera at the plants, check focus, switch on the grow light

8. Known issues and next steps

Safety items first

- **Pumps can dose without limit.** With a bad pH reading (such as 19.71) or a dry EC probe, the firmware sees "out of target" and runs Pumps A and B continuously. Add a maximum run time, or dose in short pulses (e.g. 2 s ON, wait 30–60 s, re-check). Until then, keep the nutrient pumps unplugged when the probes are not in solution.
- **MQTT has no password.** Anyone on the WiFi can send pump or reset commands to `hydro/cmd` (the dashboard's Calibration tab uses the same topic). Add a Mosquitto password and an access list before using the dashboard from other devices.
- **MaixCAM factory password.** Change it with `passwd` (section 5.1).
- **Relay wiring.** Keep relay contacts and any mains wiring in a closed box away from water.

Roadmap

- Confirm the sampling pump on relay 2 after re-flashing the firmware.
- Grow-light control on the spare relay channel (relay 2 IN2): pick a free GPIO, add a schedule in the firmware and a `light` field in the JSON.
- Add labelled photos from the Hydro camera (`data/vision/`) to the growth-stage dataset and retrain, so the model learns the real rack view, not only internet photos.
- DS18B20 water temperature for EC temperature compensation.
- RTC battery for correct offline time.