

BEFORE USE


- Do not press too hard against the LCD panel because it contains glass.
- Never dispose of the battery in a fire.
- Keep battery out of reach of children.
- Since this product is not waterproof, do not use it or store it where fluids, for example water, can splash onto it. Raindrops, water spray, juice, coffee, steam, perspiration, etc. will also cause malfunction.
- Please press ON/CCE if you see no indication.
- The battery is factory-installed before shipment, and may be exhausted before it reaches the service life stated in the specifications.
- This product, including accessories, may change due to upgrading without prior notice.

SHARP will not be liable nor responsible for any incidental or consequential economic or property damage caused by misuse and/or malfunctions of this product and its peripherals, unless such liability is acknowledged by law.

SPECIFICATIONS

Type:	Electronic calculator
Operating capacity:	16 digits
Power supply:	Built-in solar cell and Alkaline manganese battery (1.5V $\times$ (DC) LR44 or equivalent $\times$ 1)
Operating time: (varies according to use and other factors)	Approx. 2 years (with 1 hour of daily use, using the alkaline manganese battery only)
Automatic Power-off:	Approx. 7 min.
Operating temperature:	0°C - 40°C (32°F-104°F)
Dimensions:	158 mm(W) $\times$ 198 mm(D) $\times$ 32 mm(H)
Weight:(battery included)	Approx. 240 g
Accessories:	Alkaline manganese battery (installed), Operation manual

BATTERY REPLACEMENT



OPERATIONS

1. Before starting calculations, press CA to clear (zero-clear).
2. The position of any switch that is not specifically designated, may be set to any position.
3. For expressing calculation examples, only the symbols that are required for explanation are mentioned.
4. Example procedures are listed in following manner unless otherwise specified.

(1) Example | (2) Key operations | (3) Display

F 4 3 2 0 A
 $\text{DECIMAL POINT ASSIGNMENT SWITCH}$

- “F” position: Set the decimal point to “floating” point.
- “4,3,2,0” positions: The decimal figures can be set to the respective numbers.
- “A” position: Assigns Adding mode (sets the decimal at 2). In the case of addition/subtraction, the decimal point will be placed at 2 automatically. If is registered, or in case of non-additive/non-subtractive calculation, this function will not be applicable.

t 5/4
 ROUNDING SELECTOR

- Specifies the handling of the digit immediately below the position set by the decimal selector. (For example, if the decimal selector is set to 3, then the fourth decimal will be rounded.)
- “t” position: The answer will be rounded up.
- “5/4” position: The answer will be rounded off.
- “ t ” position: The answer will be rounded down.

* While the decimal selector is set to the “F” (i.e., floating) position, or if the decimal place cannot be determined (preliminary calculation results, for instance), the answer will always be rounded down regardless of the setting above.

MARKUP CALC.

(1)	(2)	(3)
Cost = \$350, Markup % = 30% $\rightarrow$ Selling Price ?(500), Markup ?(150)	$\text{C-CE C-CE 350 } \div 30 \text{ MU}$	500. 150.
Selling Price = \$500, Markup % = 30% $\rightarrow$ Cost ?(350)	$\text{C-CE C-CE 500 } \times 30 \text{ +/- MU}$	350.
Cost = \$350, Markup % on cost = 30% $\rightarrow$ Selling Price ?(455)	$\text{C-CE C-CE 350 } \times 30 \text{ MU}$	455.
Selling Price = \$455, Markup % on cost = 30% $\rightarrow$ Cost ?(350), Markup ?(105)	$\text{C-CE C-CE 455 } \div 30 \text{ +/- MU MU}$	350. 105.

CALCULATING TAX

- To perform a tax calculation, first it is absolutely necessary to set and check the tax rate.(The initial tax rate is 0.)
- A tax rate can be set (or changed) with a number containing up to four digits. (Decimal point is not regarded as a digit.)
- The set tax rate is retained until it is changed. However, the set tax rate may be changed or lost if the battery is consumed largely.

(1) Confirming the tax rate. (0%)

(2)	(3)
C-CE C-CE TAX	TAX RATE 0.

(1) Set a 5% tax rate.

Calculate the tax on \$800 and calculate the total Including tax.

F 4 3 2 0 A I	
(2)	(3)
C-CE C-CE	0.
DATE SET +TAX DATE SET 5 +TAX	TAX RATE = 5.
C-CE C-CE 800	800.
+TAX	+TAX 840.
+TAX	TAX 40.

(1) Perform two calculations using \$84 and \$52.5, both of which already include tax. (tax rate: 5%)

Calculate the tax on the total and the total without tax.

F 4 3 2 0 A I	
(2)	(3)
C-CE C-CE 84 + 52.5 =	= 136.5
-TAX	-TAX 130
-TAX	TAX 6.5

HOW TO PERFORM BASIC CALCULATIONS

(1)	(2)	(3)
	F 4 3 2 0 A I CA	0.
$(-24+2)\div 4=-5.5$	24 +/- + 2 ÷ 4 =	-5.5
$13\times (-4)\div 2=-26$	13 × 4 +/- ÷ 2 =	-26.
$34+57=91$	34 + 57 =	91.
$45+57=102$	45 =	102.
$38-26=12$	38 - 26 =	12.
$35-26=9$	35 =	9.
$68\times 25=1700$	68 × 25 =	1'700.
$68\times 40=2720$	68 × 40 =	2'720.
$35\div 14=2.5$	35 ÷ 14 =	2.5
$98\div 14=7$	98 =	7.
$200\times 10\%=20$	200 × 10 %	20.
$(9\div 36)\times 100=25$	9 ÷ 36 %	25.
$200+(200\times 10\%)=220$	200 + 10 %	220.
$4^0=(4^3)^2=4096$	4 × = = × =	4'096.
$1/8=0.125$	8 ÷ =	0.125
$\begin{array}{r} 25 \times 5 = 125 \\ -) 84 \div 3 = 28 \\ +) 68 + 17 = 85 \\ \hline 182 \end{array}$	CM1 25 × 5 M1+ 84 ÷ 3 M1- 68 + 17 M1+ RM1 CM1 CM2 25 × 5 M2+ 84 ÷ 3 M2- 68 + 17 M2+ RM2 CM2	M1 125. M1 28. M1 85. M1 182. M2 125. M2 28. M2 85. M2 182.
$2+3 \rightarrow 2+4=6$	2 + 3 C-CE 4 =	6.
$5\times 2 \rightarrow 5\div 2=2.5$	5 × ÷ 2 =	2.5
$123456 \rightarrow 123478$	123456 → → 78	123'478.
$\begin{array}{r} 23.5+42.3=65.8 \\ 72.4-37.32+12=47.08 \\ +) 27-19-21.61=-13.61 \\ \hline 99.27 \end{array}$	GT GT C-CE 23.5 + 42.3 = 72.4 - 37.32 + 12 = 27 - 19 - 21.61 = GT	G 65.8 G 47.08 G -13.61 G 99.27
$\begin{array}{r} 9876543120987650 \div 0.444 \\ \times 555 \\ \hline =1234.567890123456 \times 10^{16} \end{array}$	C-CE 9876543120987650 ÷ 0.444 × 555 = C-CE 555 = (1234.567890123456 × 10¹⁶ = 12345678901234560000)	E 2.224446648871092 1'234.567890123456
F 4 3 2 0 A I 1\$ 45 ¢ 45\$ 00 ¢ -7\$ 63 ¢ 38\$ 82 ¢	C-CE 145 + 4500 - 763 =	1.45 46.45 38.82

Note: was not used in the entries.