



WRMIS User Manual

FLOOD OPERATIONS

DEVELOPMENT OF WATER RESOURCES

MANAGEMENT INFORMATION SYSTEM (WRMIS)

AND DECISION SUPPORT SYSTEM (DSS)

NESPAK

Version 1.0

April 10, 2017









Revision History

Version	Date	Ву	Summary of Changes
1.0	10-04-2017	NESPAK	Initial Draft









TABLE OF CONTENTS

1.	FLOOD OPERATIONS	5
	Flood Fighting Plan	6
	Search Flood Fighting Plan	8
	Flood Inspection	11
	Independent Inspections - Protection Infrastructure	12
	Independent Inspections - Headwork/Barrage	21
	Independent Inspections - Drains	25
	Add Flood Fighting Plan	30
	Stone Deployment	37
	Division Summary	43
	Search Division Summary	43
	Add Division Summary	45
	Emergency Purchases	49
	Search Emergency Purchases:	49
	Add Emergency Purchases	52
	Onsite Monitoring	56
	Stone Position	58
	Camp Site	59
	Flood Bund Gauges	60
	Add Gauges Data	62
	Details	65
	Division Store	65
	Update	68









Issued Stock (Division store)	70
Issue New Stock	71
Items	73
Received Stock (Division store)	74
Received Stock	76
Reference Data	77
Items	77
Problem Nature	79
Tender Management (Android Application)	81
Flood inspection	83
Stone Deployment	84
Emergency Purchases	86
Onsite Monitoring	88









1. FLOOD OPERATIONS

This module consists of work flow of Irrigation department to deal the flood strategically and measure the damages and works done on flood affected areas. It contains two major part, Web Application and Mobile (Android) Application. Main working module of Flood operations are, Flood Fighting Plan, Stone Deployment, Division Store, Flood Inspections, Onsite Monitoring, Flood Fighting and Division Summary. Flood Fighting Plan is the strategy and requirements submitted by division to counter the flood on yearly basis. Stone Deployment maintains the record of Deployment of purchased stones on Specified Locations as per Flood Fighting Plan along with Attachments and Vehicle detail. Division Store is the Inventory system to maintain Division owned Items and machines. Flood Inspections deals with the Inspections of all Infrastructures within Division premises before and after the flood season. Onsite Monitoring provides interface to Monitoring Staff to inspect the arrangements done by division to counter the flood during Flood season. Flood Fighting enables XEN to systemize the record of purchases done during flood seasons on emergency basis. Division Summary is the status of Items both Infrastructures based as well as associated with Division store.

User click on 'Flood Operations' icon from main screen after login as XEN

Business User: XEN


Any other user can view "FFP" based on assigned rights from Roles and Rights (User Administration)

Pre-Requisite: It would be on its full working scenario when the system is provided with Post-Flood Data.









Flood Fighting Plan


This module provides user to Add, Edit, View, Delete and Publish Flood Fighting Plan. Flood fighting plan is the document pertaining strategy for upcoming flood season for the current season. XEN is the authorized user of FFP and seniors get the notification when the FFP gets Published from XEN's account.

How to Access: Main Menu -> Flood Operations- > Flood Fighting Plan




















Search Flood Fighting Plan



- Select Zone from the 'Zone dropdown.
- On selection of Zone, system enables Circle dropdown and populates all reaches based on selected Zone.
- Authorize User can select desired Zone.



- Select Circle from the 'Circle dropdown.
- On selection of Circle, system enables Division dropdown and populates all









reaches based on selected Circle.

Authorize User can select desired Circle

Division

Select

• User can select desired Division w.r.t the selected Circle.

Year
Select

Select Year from the 'Year dropdown.

Status

Select

- 'Status' dropdown is available only for the XEN of that specific Division.
- XEN can search 'Draft' as well as 'Published' FFP.
- Search

Search

- Click on the <Search> button.
- System displays all the records as per the search criteria given by the user.
- If there is no record against the entered search criteria, system shows the message 'No record found'
- Add New

Add New

- Click on the <Add new> button.
- System navigates to Add new FFP basic information Screen.
- Only XEN can add FFP
- System checks the unique entry on selected year basis.
- System does not allow to add new FFP for the year and division which already have FFP for selected Year











Last Year Restoration Works



For Searched Record:

- Click on the <Last year Restoration Works> Icon.
- System navigates user to new screen pertaining list of works done or ongoing for the previous year.
- List of Works appeared from <Asset and Works > Module



Stone Position



For Searched Record:

- Click on the <Stone Position> Icon.
- System navigates user to new screen pertaining list of Stone Stocks recorded during Post-Flood Inspection and also provide interface to add new stock requirement along with the R.D.



Camp Site



For Searched Record:

- Click on the <Camp Site> Icon.
- System navigates user to new screen having interface to add camp site to be utilize in Flood Season on desire location (infrastructure and RD.)
- It also consists of records of Items demanded for the camp site.



Overall Division Items



For Searched Record:

- Click on the <Overall Division Items> Icon.
- System navigates user to new screen having interface to add additional demand
 of Items and Assets (as per Item category selection) required overall for the
 division to deal with the Flood season of current year.







 System accumulates all the Items (Quantity) demanded in Campsite, Post-Flood Inspection and on same screen as additional quantity required and displayed in a separate column.



Arrangements



For Searched Record:

- Click on the <Arrangements> Icon.
- System navigates user to new screen having interface to add additional demand
 of Items and Assets (as per Item category selection) required overall for the
 division to deal with the Flood season of current year.
- System accumulates all the Items (Quantity) demanded in Campsite, Post-Flood Inspection and on same screen as additional quantity required and displayed in a separate column.



Preview



For Searched Record:

- Click on the <Preview> Icon.
- · System generates PDF of FFP.



Publish



For Searched Record:

- Click on the <Preview> Icon.
- System generates PDF of FFP.

Flood Inspection

System shows the flood inspection which further categorized into three types such as:










Independent, Departmental and Joint Inspection, each category can be of either type: Post-Flood or Pre-Flood depending upon the time line. Main actor of this module is the respective XEN is responsible for the inspections and other users such as SE, Chief, Secretary, CE (D&F Zone) etc. receive notification on every publication of XEN.

How to Access: Left Menu -> Flood Operation -> Flood Inspection

Independent Inspections - Protection Infrastructure


System shows the details of independent Inspection on Main screen of Independent Inspection.XEN can add,edit, publish or delete the independent Inspection from the screen.



Independent Inspection:



- Select zone from the 'Zone' dropdown.
- On selection of zone, relevant circles are populated in the circle dropdown.



- Select circle from the 'Circle' dropdown.
- On selection of circle, relevant divisions are populated in the division dropdown.



User selects a division into 'Division' dropdown.









• All the sub divisions associated with the above Division populated into 'Sub Division' dropdown.



Type



- Click on 'Type' dropdown.
- Select the type.



Infrastructure Type





- On Click on 'Infrastructure Type' dropdown.
- Select the Infrastructure type.



Infrastructure Name





- On Click on 'Infrastructure Name' dropdown.
- Select the Infrastructure Name.
- 7

From Date






- Click on 'From Date' dropdown.
- · Select a date from appeared calendar
- From date should be less than or equal to 'To Date'.



To Date





- Click on 'To Date' dropdown.
- · Select a date from appeared calendar
- From date should be less than or equal to Current Date.














- Click on 'Status' dropdown.
- Select a status.
- This Dropdown available for XEN of relevant division only.




- Click on 'Search 'button.
- System displayed information according to selected search criteria fields.

11

Add New

- Click on 'Add New 'button.
- System navigates user to add Inspection screen.



Add Flood Inspection:

1 Div


Division



- User selects a division into 'Division' dropdown.
- All the sub divisions associated with the above Division populated into 'Sub Division' dropdown.



Type











- 'Type' dropdown selection is dependent on current date.
- It auto selects based on date.

Infrastructure Type



- On Click on 'Infrastructure Type' dropdown.
- Select the Infrastructure type.
- On basis of 'Infrastructure Type' the parameters of Inspections gets vary.
- Infrastructure Name

Select

- On Click on 'Infrastructure Name' dropdown.
- Select the Infrastructure Name.
- Date

Click on 'To Date' dropdown.

Save

- Click on <Save> button, system verify all the required fields.
- System saves the data into the database & displays a message "Records saved successfully".
- System display error message if any of the required fields has not been entered.
- System displays newly added record into the Table.
- 7 Back









Back

Click on <Back> button discard all unsaved changes

3.3.1.1. Pre-Flood Inspections

Inspection Date	Inspection Type	Infrastructure Type	Infrastructure Name	Status	Action
27-Feb-2017	Pre Flood	Protection Infrastructure	Mianwali Bund	Published	



General Condition



- On click on 'General Condition' icon system navigates user to new screen.
- Parameters for General conditions of 'Protection infrastructure' shown.
- User enter/select the input parameters and click on 'Save' button to save in db.
- User can navigate back or cancel by click on back button.

2

R.D Wise condition



- On click on 'R.D wise Condition' icon system navigate user to new screen.
- System shows different tables consisting the ability to save the R.D wise conditions of protection infrastructure.
- To add/enter any R.D wise condition, user have to click on 'add' icon (present on each table within 'R.D wise Condition' Screen) to add new record of specific R.D wise condition.
- User can navigate back or cancel by click on back button.

3

M.B Status



- 'M.B Status' is measuring book status.
- At click on 'M.B Status' system navigate user to new screen.
- User select the Item category from 'Category' dropdown to select the specific category of items.









- User input the quantity of item available on site.
- At click on 'Save' button system save the record in DB.
- User can navigate back or cancel by click on back button.



Problems



- Click on 'Problems' icon.
- System navigate to new screen.
- User enter the entry of problems against the 'nature of problem' dropdown
- At click on 'Save' button system save the record in DB.
- User can navigate back or cancel by click on back button.



Breaching Section



- Click on 'Breaching Section' icon.
- System navigate to new screen.
- User enter the entry of condition of already entered breaching sections'.
- At click on 'Save' button system save the record in DB.
- User can navigate back or cancel by click on back button.



Publish



- On Click on 'Publish' Icon.
- System displays confirmation message
- On confirmation system publish the Flood Inspection.

7

Print



- Click on 'Print' icon.
- System show new screen.
- Printable form of Flood Inspection appeared.
- User can save or print the Flood Inspection.













- Click on 'Edit' icon.
- System navigates user to new screen pertaining basic information.
- At click on 'Save' button system update the record in DB.
- User can navigate back or cancel by click on back button



- Click on 'Delete' icon.
- System displays Confirmation message.
- System check for validation
- At confirmation system deletes the record from DB

3.3.1.2. Post-Flood Inspections







- On click on 'General Condition' icon system navigate user to new screen.
- Parameters for General conditions of 'Protection infrastructure' displayed.
- User enter/select the input parameters and click on 'Save' button to save in db.







User can navigate back or cancel by click on back button.

2

R.D Wise condition



- On click on 'R.D wise Condition' icon system navigate user to new screen.
- System shows different tables consisting the ability to save the R.D wise conditions of protection infrastructure.
- To add/enter any R.D wise condition, user have to click on 'add' icon (present on each table within 'R.D wise Condition' Screen) to add new record of specific R.D wise condition.
- User can navigate back or cancel by click on back button.

3

M.B Status



- 'M.B Status' is measuring book status.
- At click on 'M.B Status' system navigate user to new screen.
- User select the Item category from 'Category' dropdown to select the specific category of items.
- User input the quantity of item available on site along with the 'Quantity required' field.
- At click on 'Save' button system save the record in DB.
- User can navigate back or cancel by click on back button.

4

Problems



- Click on 'Problems' icon.
- System navigates to new screen.
- User enter the entry of problems against the 'nature of problem' dropdown
- At click on 'Save' button system save the record in DB.
- User can navigate back or cancel by click on back button.

5

Breaching Section



Click on 'Breaching Section' icon.









- System navigates to new screen.
- User enter the entry of condition of already entered breaching sections'.
- At click on 'Save' button system save the record in DB.
- User can navigate back or cancel by click on back button.



Stone Position



- On Click on 'Stone Position' Icon.
- System navigates user to Stone Position screen.
- User enter the records of stone against the location (R.D).
- At click on 'Save' button system save the record in DB.
- User can navigate back or cancel by click on back button.



Print



- Click on 'Print' icon.
- System show new screen.
- Printable form of Flood Inspection be shown.
- User can save or print the Flood Inspection.



Edit



- · Click on 'Edit' icon.
- System navigates user to new screen pertaining basic information.
- At click on 'Save' button system update the record in DB.
- User can navigate back or cancel by click on back button



Delete



- · Click on 'Delete' icon.
- System display Confirmation message.









- System check for validation
- At confirmation system delete the record from DB

Independent Inspections - Headwork/Barrage

Pre-Flood Inspections

Inspection Date	Inspection Type	Infrastructure Type	Infrastructure Name	Status	Action
31-Mar-2017	Pre Flood	Barrage/Headwork	Chashma barrage demo	Published	





- On click on 'General Condition' icon system navigate user to new screen.
- Parameters for General conditions of 'Headwork/Barrage' be shown.
- User enter/select the input parameters and click on 'Save' button to save in db.
- User can navigate back or cancel by click on back button.



M.B Status



- 'M.B Status' is measuring book status.
- At click on 'M.B Status' system navigate user to new screen.
- User select the Item category from 'Category' dropdown to select the specific category of items.
- User input the quantity of item available on site
- At click on 'Save' button system save the record in DB.
- User can navigate back or cancel by click on back button.



Problems



- Click on 'Problems' icon.
- System navigates to new screen.







- User enters the entry of problems against the 'nature of problem' dropdown
- At click on 'Save' button system save the record in DB.
- User can navigate back or cancel by click on back button.



Publish



- On Click on 'Publish' Icon.
- System displays confirmation message
- On confirmation system publish the Flood Inspection.



Print



- Click on 'Print' icon.
- System show new screen.
- Printable form of Flood Inspection be shown.
- User can save or print the Flood Inspection.



Edit



- · Click on 'Edit' icon.
- System navigates user to new screen pertaining basic information.
- At click on 'Save' button system update the record in DB.
- User can navigate back or cancel by click on back button



Delete



- Click on 'Delete' icon.
- System display Confirmation message.
- System check for validation
- · At confirmation system delete the record from DB









3.3.1.3. Post-Flood Inspections

Inspection Date	Inspection Type	Infrastructure Type	Infrastructure Name	Status	Action
31-Mar-2017	Pre Flood	Barrage/Headwork	Chashma barrage demo	Published	
					0 0 0 0 0



General Condition



- On click on 'General Condition' icon system navigate user to new screen.
- Parameters for General conditions of 'Headwork/Barrage' be shown.
- User enter/select the input parameters and click on 'Save' button to save in db.
- User can navigate back or cancel by click on back button.



M.B Status



- 'M.B Status' is measuring book status.
- At click on 'M.B Status' system navigate user to new screen.
- User select the Item category from 'Category' dropdown to select the specific category of items.
- User input the quantity of item available on site along with the 'Quantity required' field.
- At click on 'Save' button system save the record in DB.
- User can navigate back or cancel by click on back button.



Problems



- Click on 'Problems' icon.
- System navigate to new screen.
- User enter the entry of problems against the 'nature of problem' dropdown
- At click on 'Save' button system save the record in DB.
- User can navigate back or cancel by click on back button.











Stone Position



- On Click on 'Stone Position' Icon.
- System navigates user to Stone Position screen.
- User enters the records of stone against the location (R.D).
- At click on 'Save' button system save the record in DB.
- User can navigate back or cancel by click on back button.



Print



- Click on 'Print' icon.
- System show new screen.
- Printable form of Flood Inspection be shown.
- User can save or print the Flood Inspection.



Edit



- Click on 'Edit' icon.
- System navigates user to new screen pertaining basic information.
- At click on 'Save' button system update the record in DB.
- User can navigate back or cancel by click on back button



Delete



- Click on 'Delete' icon.
- System displays Confirmation message.
- System check for validation
- At confirmation system delete the record from DB










Independent Inspections - Drains

Pre-Flood Inspections





General Condition



- On click on 'General Condition' icon system navigate user to new screen.
- Parameters for General conditions of 'Drain' displayed.
- User enters/selects the input parameters and click on 'Save' button to save in db.
- User can navigate back or cancel by click on back button.



R.D Wise condition



- On click on 'R.D wise Condition' icon system navigate user to new screen.
- System show different tables consisting the ability to save the R.D wise conditions of protection infrastructure.
- To add/enter any R.D wise condition, user have to click on 'add' icon (present on each table within 'R.D wise Condition' Screen) to add new record of specific R.D wise condition.
- User can navigate back or cancel by click on back button.



M.B Status



- 'M.B Status' is measuring book status.
- At click on 'M.B Status' system navigate user to new screen.
- User select the Item category from 'Category' dropdown to select the specific category of items.
- User input the quantity of item available on site.







- At click on 'Save' button system save the record in DB.
- User can navigate back or cancel by click on back button.



Problems



- Click on 'Problems' icon.
- System navigates to new screen.
- User enters the entry of problems against the 'nature of problem' dropdown
- At click on 'Save' button system save the record in DB.
- User can navigate back or cancel by click on back button.



Publish



- On Click on 'Publish' Icon.
- System displays confirmation message
- On confirmation system publish the Flood Inspection.



Print



- · Click on 'Print' icon.
- System show new screen.
- Printable form of Flood Inspection get displayed.
- User can save or print the Flood Inspection.



Edit



- · Click on 'Edit' icon.
- System navigates user to new screen pertaining basic information.
- At click on 'Save' button system update the record in DB.
- User can navigate back or cancel by click on back button



Delete











- Click on 'Delete' icon.
- System displays Confirmation message.
- System check for validation
- At confirmation system delete the record from DB

3.3.1.4. Post-Flood Inspections

Inspection Date	Inspection Type	Infrastructure Type	Infrastructure Name	Status	Action
05-Oct-2015	Post Flood	Drain	Mianwali Drain	Published	
					3 4 4 9



General Condition



- On click on 'General Condition' icon system navigate user to new screen.
- Parameters for General conditions of 'Drain' displayed.
- User enters/selects the input parameters and click on 'Save' button to save in db.
- User can navigate back or cancel by click on back button.



R.D Wise condition



- On click on 'R.D wise Condition' icon system navigate user to new screen.
- System shows different tables consisting the ability to save the R.D wise conditions of protection infrastructure.
- To add/enter any R.D wise condition, user have to click on 'add' icon (present on each table within 'R.D wise Condition' Screen) to add new record of specific R.D wise condition.
- User can navigate back or cancel by click on back button.



M.B Status











- 'M.B Status' is measuring book status.
- At click on 'M.B Status' system navigate user to new screen.
- User select the Item category from 'Category' dropdown to select the specific category of items.
- User input the quantity of item available on site.
- At click on 'Save' button system save the record in DB.
- User can navigate back or cancel by click on back button.



Problems



- Click on 'Problems' icon.
- System navigates to new screen.
- User enters the entry of problems against the 'nature of problem' dropdown
- At click on 'Save' button system save the record in DB.
- User can navigate back or cancel by click on back button.



Stone Position



- On Click on 'Stone Position' Icon.
- System navigates user to Stone Position screen.
- User enters the records of stone against the location (R.D).
- At click on 'Save' button system save the record in DB.
- User can navigate back or cancel by click on back button.



Publish



- On Click on 'Publish' Icon.
- System displays confirmation message
- On confirmation system publish the Flood Inspection.



Drint



- Click on 'Print' icon.
- System show new screen.
- Printable form of Flood Inspection displayed.







User can save or print the Flood Inspection.



Edit



- Click on 'Edit' icon.
- System navigates user to new screen pertaining basic information.
- At click on 'Save' button system update the record in DB.
- User can navigate back or cancel by click on back button



Delete



- Click on 'Delete' icon.
- System displays Confirmation message.
- System check for validation
- At confirmation system delete the record from DB









Add Flood Fighting Plan

User clicks on:



System navigate user to following Screen



How to Access: Left Menu -> Flood Fighting Plan -> Add new



User can select desired Division w.r.t the selected Circle.



• Select Year from the 'Year dropdown.



- User clicks on Save Button to save the basic information of FFP.
- System navigates to main screen.
- System Displays new entry pertaining links mentioned in above mentioned screen.











• User click on Back to cancel the process of adding new FFP and navigate back to main screen.



Adding FFP:



Last Year Restoration Work



- Click on the <Last year Restoration Works> Icon.
- System navigates user to new screen pertaining list of works done or ongoing for the previous year.
- List of Works appears from <Asset and Works > Module




As user clicks on Stone Position Icon, following Screen displayed












Stone Position:



Click on <Add> button adds a new row into the table for adding a new record.



- · Click on 'Edit' image to edit the existing record.
- System opens the record into editable form.



- Click on 'Delete' image to delete the existing record.
- System display error message if any of the child entry has been entered for this specific record.
- System deletes the newly added record from the table













Back

System navigates user back to main screen.



Camp Site:



• Click on <Add> button adds a new row into the table for adding a new record.









2

Items



- At click on save icon, Item icon get enabled.
- At click on Item, System navigate user to Item screen where user add items as after the selection of item category (Dropdown)
- System display stable of items (Already entered from reference data) as per selected Item Category.
- User enters the quantity under Required Quantity column heading against the desired item.



Edit



- Click on 'Edit' image to edit the existing record.
- System opens the record into editable form.



Delete



- Click on 'Delete' image to delete the existing record.
- System display error message if any of the child entry has been entered for this specific record.
- System deletes the newly added record from the table



Overall Division Items














Overall Division Items:

1 Category

Select

- User selects the Item category from mentioned drop down.
- System displays table of Items as per selected item category.
- 2
 Additional (Quantity Required in Division)

• User input the additional quantity required excluded the quantity already entered through camp sites and the Post-Flood Inspection.



- User clicks on Save Button to save the entered information.
- System display entered data in read only mode.










• DB updated.



System navigates user back to main screen.



Arrangements:



• User enters the description against arrangement type.



- User clicks on Save Button to save the entered information.
- System displays entered data in read only mode.
- DB updated.











System navigates user back to main screen.

Stone Deployment


This section provides interface for XEN to enter the records of Stone deployment as per demanded in FFP, furthermore Stone Deployment also maintain the quantity of stone deployment along with further details such as builty number, Vehicle number, by parts quantity etc.

How to Access: Left Menu -> Flood Operations -> Stone Deployment



















Stone Deployment:





- Select zone from the 'Zone' dropdown.
- On selection of zone, relevant circles are populated in the circle dropdown.
- Circle
 Select
 - Select circle from the 'Circle' dropdown.
 - On selection of circle, relevant divisions are populated in the division dropdown.
- Division

 Select
 - User selects a division into 'Division' dropdown.
 - All the sub divisions associated with the above Division populated into 'Sub Division' dropdown.
- Year
 Select
 - User selects a year into 'year' dropdown.
- Infrastructure Type

 Select

• User selects an Infrastructure Type into 'Infrastructure Type' dropdown.














- User selects an Infrastructure Name into 'Infrastructure Name' dropdown.
- 'Infrastructure' name appeares as per selection of 'Infrastructure Type'



Search

- Click on the <Search> button.
- System displays all the records as per the search criteria given by the user.
- If there is no record against the entered search criteria, system shows the message 'No record found'

Infrastructure Type	Infrastructure Name	RD	Quantity Approved in FFP ('000 cft)	Quantity Disposed ('000 cft)	Action
Barrage/Headwork	Kalabagh/Jinnah Barrage		30	30 1	Details
Protection Infrastructure	Mianwali Bund	154+000	8	8	Details
Protection Infrastructure	Mianwali Bund	50+150	3	3	Details
Protection Infrastructure	Mianwali Bund	30+130	5	5	Details
Protection Infrastructure	Mianwali Bund	10+110	10	10	Details

Add Stone Deployment:



Details


- Click on the <Details> button.
- System navigates to details page where user enter the disposal details against the mentioned amount i.e. 'Quantity Approved in FFP ('000 cft)'.
- 'Quantity Disposed ('000 cft) gets updated with updating disposal quantity recorded in 'details'.











Add details (Stone Deployment):



- Select click on 'add' Icon.
- System display new row with input fields under shown column heading.



- · After saving the record system display attachment icon.
- At click on 'attachment' icon system navigate user to new screen.
- User can enter maximum of five attachments with single record.



- At click on edit icon system display editable fields of that specific record.
- System also shows 'Save' and 'Cancel' icons to save or cancel.











- At click on delete icon.
- System checks the child record.
- System deletes the record from db.



Back

Back

• At click on 'back' icon system navigates user to previous screen.










Division Summary

This module provides user to Add, Edit, View, Delete and Print division summary of Flood operations. XEN is the authorized user of Division summary

How to Access: Main Menu -> Flood Operations- > Division Summary



Search Division Summary



- Select Zone from the 'Zone dropdown.
- On selection of Zone, system enables Circle dropdown and populates all reaches based on selected Zone.
- Authorize User can select desired Zone.



- Select Circle from the 'Circle dropdown.
- On selection of Circle, system enables Division dropdown and populates all reaches based on selected Circle.
- Authorize User can select desired Circle











AII ▼

• User can select desired Division w.r.t the selected Circle.

Year
All

Select Year from the 'Year dropdown.

Search

Search

- Click on the <Search> button.
- System displays all the records as per the search criteria given by the user.
- If there is no record against the entered search criteria, system shows the message 'No record found'

6 Add New

Add New

- Click on the <Add new> button.
- System navigates user to Division summary basic information screen.
- Only XEN can add division summary
- 7 Infrastructure Based Items



For Searched Record:

- Click on the <Infrastructure based items> Icon.
- System navigate user to Infrastructure based items for division summary screen.

8 Division Store Items



For Searched Record:









- Click on the <Division Store items> Icon.
- System navigate user to Division Store items for division summary screen.



Stone Position



For Searched Record:

- Click on the <Stone Position> Icon.
- System navigates user to stone position for division summary screen.



Print



For Searched Record:

- Click on the <Print> Icon.
- System prints the division summary report.



Edit



For Searched Record:

- · Click on 'Edit' Icon.
- System opens the record into editable form.

12

Delete



For Searched Record:

- At click on delete icon.
- System checks the child record.
- System deletes the record from db.

Add Division Summary

User clicks on:

Add New










System navigate user to following Screen



- User click on Save Button to save the basic information of division summary.
- System navigates to main search screen.
- System Display new entry pertaining links mentioned in above mentioned screen.



 User clicks on Back to cancel the process of adding new Division and navigate back to main screen.

3.4.1.1. Infrastructure Based Items

User click on Infrastructure based items icon against Search record

System navigate user to following Screen













Click on items button, system navigate user to items screen



Click on Back button, system navigate back to main screen.

3.4.1.2. Division Store Items


- User click on Division Store items icon against Search record
- System navigate user to following Screen











Category

Category

Civil

- Select Category from dropdown.
- System show details according to selected category.

Back Back

Click on Back button, system navigate back to main screen.

3.4.1.3. Stone Position


- User click on Stone Position icon against Search record
- System navigate user to following Screen














Click on Back button, system navigate back to main screen.

Emergency Purchases

How to Access: Main Menu -> Flood Operations- > Emergency Purchases



Search Emergency Purchases:












All

- Select Zone from the 'Zone dropdown.
- On selection of Zone, system enables Circle dropdown and populates all reaches based on selected Zone.
- Authorize User can select desired Zone.



- Select Circle from the 'Circle dropdown.
- On selection of Circle, system enables Division dropdown and populates all reaches based on selected Circle.
- Authorize User can select desired Circle



Select Camp site from dropdown.

Search Search

- Click on the <Search> button.
- System displays all the records as per the search criteria given by the user.
- If there is no record against the entered search criteria, system shows the message 'No record found'











Add New

Add New

- Click on the <Add new> button.
- System navigates user to Add emergency purchases screen.
- Only XEN can add emergency purchases



Works



For Searched Record:

- Click on the <Works> Icon.
- System navigates user to Flood Fighting works screen.



Item Purchasing



For Searched Record:

- Click on the < Item Purchasing > Icon.
- System navigates user to Emergency purchases of items on infrastructure screen



Edit



For Searched Record:

- Click on 'Edit' Icon.
- System opens the record into editable form.



Delete



For Searched Record:

- At click on delete icon.
- System checks the child record.
- System deletes the record from db.










Add Emergency Purchases

User click on:

Add New

System navigate user to following Screen











RD +

Enter the value of RD

Year

Select

• Select Year from the 'Year dropdown.

Save

- User clicks on Save Button.
- System navigates to main search screen.
- System Display new entry pertaining links mentioned in above mentioned screen.

Back Back

- User click on Back Button.
- · System navigates user to search screen.

3.5.2.1. Works

- User click on Works icon against Search record
- System navigate user to following Screen













• Click on Add button, system navigate user to add work screen





• Click on Details button, system navigate user to material disposal details screen.

Edit

For Searched Record:

- Click on 'Edit' Icon.
- System opens the record into editable form.



For Searched Record:

- At click on delete icon.
- System checks the child record.
- System deletes the record from db.

Back Back

- User clicks on Back Button.
- System navigates user to search screen.

3.5.2.2. Item Purchasing


- User click on Item Purchasing icon against Search record
- System navigate user to following Screen











1 Category

Category Civil ▼

- Select Category from dropdown.
- System show details according to selected category.
- Quantity Purchased

Quantity Purchased

• Enter the value of quantity purchased.



- User clicks on Save Button.
- System navigates to main search screen.










• System Display new entry pertaining links mentioned in above mentioned screen.



 User click on Back to cancel the process of adding and navigate back to main screen.

Onsite Monitoring

How to Access: Main Menu -> Flood Operations- > Onsite Monitoring



Search Onsite Monitoring:





- Select Zone from the 'Zone dropdown.
- On selection of Zone, system enables Circle dropdown and populates all reaches based on selected Zone.

~

Authorize User can select desired Zone.












- Select Circle from the 'Circle dropdown.
- On selection of Circle, system enables Division dropdown and populates all reaches based on selected Circle.
- Authorize User can select desired Circle



Search

Search

- Click on the <Search> button.
- System displays all the records as per the search criteria given by the user.
- If there is no record against the entered search criteria, system shows the message 'No record found'











Stone Position



For Searched Record:

- Click on the <Stone Position> Icon.
- System navigates user to stone position Monitoring screen.



Camp Site



For Searched Record:

- Click on the <Camp site> Icon.
- System navigates user to View Camp sites screen

Stone Position

- User clicks on Stone Position icon against Search record
- System navigates user to following Screen

	Zone Sargodha	Circle Thal	Division Mianwali	
rastructure Name nwali Bund				1
RD	Deployed Quantity ('000 cft)	Onsite Quantity ('000 cft)	Onsite Balance Quantity ('000 cft)	
154+000	8	8	0	Ø
50+150	18	8	10	Ø
30+130	17	10	7	Ø
10+110	40	10	30	



Edit



For Searched Record:

- · Click on 'Edit' Icon.
- System opens the record into editable form.











Back

Back

- · User clicks on Back Button.
- · System navigates user to search screen.

Camp Site

- User click on Camp site icon against Search record
- System navigate user to following Screen





Details



For Searched Record:

- · Click on 'Edit' Icon.
- System redirects user to search screen.



Edit



For Searched Record:

- Click on 'Edit' Icon.
- System opens the record into editable form.












Back

Back

- User click on Back Button.
- System navigate user to search screen.

Flood Bund Gauges

How to Access: Main Menu -> Flood Operations- > Flood Bund Gauges



1

Zone



- Select Zone from the 'Zone dropdown.
- On selection of Zone, system enables Circle dropdown and populates all reaches based on selected Zone.
- Authorize User can select desired Zone.

2

Circle

Select



~

- Select Circle from the 'Circle dropdown.
- On selection of Circle, system enables Division dropdown and populates all reaches based on selected Circle.
- Authorize User can select desired Circle












• User can select desired Division w.r.t the selected Circle.



- Click on 'Structure Type' dropdown.
- · Select the type.



- Click on 'Structure Name' dropdown.
- Select the Name.



Enter RD from Dropdown



- Click on 'From Date' dropdown.
- Select a date from appeared calendar
- From date should be less than or equal to 'To Date'.












- Click on 'To Date' dropdown.
- Select a date from appeared calendar
- From date should be less than or equal to Current Date.



10 Se

Search

Search

- Click on the <Search> button.
- System displays all the records as per the search criteria given by the user.
- If there is no record against the entered search criteria, system shows the message 'No record found'



- Click on the <Add new> button.
- System navigate to Add gauges data Screen.

Add Gauges Data

User click on:

Add New


System navigate user to following Screen





















Back

Back

- User click on Back Button.
- System navigates user to search screen.










Details

User click on:



System navigate user to following Screen





- User click on Back Button.
- System navigates user to search screen.

Division Store


How to Access: Main Menu -> Flood Operations- > Division Store -> Division Store











Search Division Store:




Select



- Select Zone from the 'Zone dropdown.
- On selection of Zone, system enables Circle dropdown and populates all reaches based on selected Zone.
- Authorize User can select desired Zone.





- Select Circle from the 'Circle dropdown.
- On selection of Circle, system enables Division dropdown and populates all reaches based on selected Circle.
- Authorize User can select desired Circle











Select 💙

• User can select desired Division w.r.t the selected Circle.

4

Year

Select

Select Year from the 'Year dropdown.

5 Item Ca

Item Category

Select

- **~**
- Click on 'Item Category' dropdown.
- Select the Category.

Search

Search

- Click on the <Search> button.
- System displays all the records as per the search criteria given by the user.
- If there is no record against the entered search criteria, system shows the message 'No record found'

Details

Details

- Click on the <Details> button.
- System navigates user to details screen.

8

Update

Update

- Click on the <Update> button.
- System navigates user to update screen










Update

User clicks on:



System navigate user to following Screen







120





- Click on 'Item Name' dropdown.
- · Select the Name.



• Enter available quantity at text field

Quantity Effected

Enter Effected quantity at text field

Condition

Select

Reason

Select condition from dropdown

8

• Enter Condition at text field

9 Save

- User clicks on Save Button
- System navigate to main search screen.

Back Back

Click on Back button, system navigate back to main screen.











Issued Stock (Division store)

How to Access: Main Menu -> Flood Operations- > Division Store -> Issued Stock







Select Infrastructure Name from dropdown.











Select 💟

Select Issued Type from dropdown.

6

Search

Search

- Click on the <Search> button.
- System displays all the records as per the search criteria given by the user.
- If there is no record against the entered search criteria, system shows the message 'No record found'
- 7

Issue New Stock

Issue new Stock

- Click on the <Issue New Stock> button.
- System navigates user to issue new stock screen.
- 8

Items

Items

- Click on the < Items > button.
- System navigates user to items screen

Issue New Stock

User click on:

Issue new Stock

System navigate user to following Screen














- · Select radio option of 'item issued to'
- System shows details according to selection

On selection of Infrastructure



Click on Back button, system navigate back to main screen.











On selection of Camp site





- Click on the < Items > button.
- System navigates user to items screen



• Click on Back button, system navigate back to main screen.

Items

User click on:




System navigate user to following Screen











Click on Back button, system navigate back to main screen.

Received Stock (Division store)


How to Access: Main Menu -> Flood Operations- > Division Store -> Received Stock












1

Zone

Select



- On selection of Zone, system enables Circle dropdown and populates all reaches based on selected Zone.
- Authorize User can select desired Zone

2

Circle

Select



- Select Circle from the 'Circle dropdown.
- On selection of Circle, system enables Division dropdown and populates all reaches based on selected Circle.
- Authorize User can select desired Circle

3

Division

Select



• User can select desired Division w.r.t the selected Circle.

4

Year









Select

• Select Year from the 'Year dropdown.

Infrastructure Type

Select

Select Infrastructure Type from dropdown.

Item Category

Select

- Click on 'Item Category' dropdown.
- Select the Category.

Search

Search

- Click on the <Search> button.
- System displays all the records as per the search criteria given by the user.
- If there is no record against the entered search criteria, system shows the message 'No record found'

Received Stock

Receive Stock

- Click on the <Received Stock> button.
- System navigates user to Received Stock screen

Received Stock

User click on:

Receive Stock


System navigate user to following Screen











Click on Back button, system navigate back to main screen.

Reference Data

How to Access: Main Menu -> Flood Operations- > Reference Data

Items


- User click at items from left menu
- System navigate user to reference data screen of items











Category

Category

Civil

- Select Category from dropdown.
- System show details according to selected category.
- Add +
 - Click on Add button, system shows addable row.
- Item Name
 - Enter Item Name at text field.
- 4 Save
 - Click on Save button , system checks for the mandatory field & if any field is missing system display a message











Click on Cancel button to cancel the open grid

Problem Nature

- 1 User click at problem nature from left menu
- 2 System navigate user to reference data screen of problem Nature.





Click on Add button, system navigate user to add work screen





For Searched Record:

- Click on 'Edit' Icon.
- System opens the record into editable form.







7

Cancel

Click on Cancel button to cancel the open grid

missing system display a message









Tender Management (Android Application)

Activate Users: XEN

For "Onsite Monitoring": ADM, MA, PMIU Staff


• User selects flood operations from left panel of application as shown below













Logout

Unscheduled Inspections










Flood inspection

 User selects Flood inspection through flood operations, System navigates user to following screen.















• User selects a division into 'Division' dropdown.



Click on 'Type' dropdown.



- Select the Infrastructure type from dropdown.
- Application shows relevant results of inspection list.

Stone Deployment


 User selects Stone Deployment through flood operations, System navigates user to following screen.











Division
Select Division
Mianwali

• User selects a division into 'Division' dropdown.

Infrastructure Type










Select Infrastructure Type Barrage/Headwork

- Select the Infrastructure type from dropdown.
- · Application shows relevant results of inspection list.



Select the Infrastructure name from dropdown.



- Select year from dropdown.
- Application shows relevant results of stone deployment list.

Emergency Purchases


 User selects Emergency purchases through flood operations, System navigates user to following screen.

















Select Division

Mianwali

• User selects a division into 'Division' dropdown.



- Select the Infrastructure type from dropdown.
- Application shows relevant results of inspection list.
- Infrastructure Name
 Select Infrastructure Nam
 Kalabagh/Jinnah Bar..
 - Select the Infrastructure name from dropdown.
- Camp Site
 Camp Site
 No
 - Select Camp site from dropdown.
 - Application shows relevant results emergency purchases.

Onsite Monitoring


 User selects Onsite Monitoring through flood operations, System navigates user to following screen.











User selects a division into 'Division' dropdown.









Infrastructure Type
Select Infrastructure Type
Barrage/Headwork

- Select the Infrastructure type from dropdown.
- · Application shows relevant results of inspection list.
- Infrastructure Name
 Select Infrastructure Nam
 Kalabagh/Jinnah Bar..
 - Select the Infrastructure name from dropdown.
- Year
 Select Year
 2017
 - Select year from dropdown.
 - Application shows relevant results of Onsite Monitoring.



