Lumora Halo ANC - User Manual

Model: LA-HL-300. Document version 1.4, November 2025.

1. Controls

The right ear cup has a touch surface. Swipe up or down to change the volume, swipe forward or back to skip tracks, and double tap to play or pause. The ANC button on the left ear cup switches between ANC, Transparency and Off.

2. Battery

Up to 40 hours with ANC on and 55 hours with ANC off. A 10-minute charge gives 6 hours of playback. The headphones can be used with the included 3.5 mm cable when the battery is empty (ANC is not available in wired mode).

3. Wear detection

Music pauses when you take the headphones off and resumes when you put them back on. Wear detection can be switched off in the Lumora app.

4. Care

Ear cushions are replaceable. Clean them with a slightly damp cloth; do not use alcohol. Halo ANC has no water resistance rating: keep it away from rain and sweat-heavy workouts.

5. Specifications

Item	Value
Driver	40 mm dynamic
Bluetooth	5.3, SBC, AAC and LDAC
Weight	265 g
Multipoint	Supported (2 devices)