

NATIONAL UNIVERSITY OF SCIENCES & TECHNOLOGY

Digital Signal Processing (EE-330)

Assignment 2 Getting Familiarized with Filter Designing

Group Members

Name	CMS ID
Muhammad Ahmed Mohsin	333060
Muhammad Umer	345834

Submission Details

Submitted to: Dr. Ahmad Salman

Class: BEE-12C

Semester: 6th

Dated: 15/5/2023



1 Introduction

Filter designing is an essential aspect of signal processing, which involves the selection of a suitable filter to process a signal. In signal processing, filters are used to extract relevant information from a signal or to remove unwanted noise or interference. The process of designing a filter involves selecting the type of filter, choosing the filter parameters, and optimizing the filter design to meet the desired specifications. The purpose of this assignment is to explore and analyze the design strategies to obtain the desired response.

2 Design

1. From your textbook (as uploaded to LMS already), see examples 7.5 and 7.6. Do these exercises on paper by hand, write down the characteristic equations of Chebyshev and Elliptic lowpass filters (from literature). Find the poles/zeros and/or coefficients of the designed discrete-time filters H(z). Using coefficients, plot the magnitude response in both examples using MATLAB. The plot should be complete in title and x-axis and y-axis units.

Chebyshev Filter Design

MATLAB Code

```
% The given Specifications are
w_p = 0.4 * pi;
w_s = 0.6 * pi;
ripple = 0.01;
Ap = -log10(0.01); % at w=wp (Ripple Magnitude)
Ar = -20 * log10(0.001); % At wr=0.6pi (Rejection magnitude)
epsilion = sqrt((10 ^ (0.1 * Ap) - 1));


% Finding ratio wp/wr;
k = w_p / w_s;

% Finding d
d = epsilion / sqrt((10 ^ (0.1 * Ar) - 1));

% Finding filter order
n = floor(acosh(1 / d) / acosh(1 / k));

% Calculating y
y = (1 / n) * (asinh(1 / epsilion));
a = sinh(y);
b = cosh(y);
```





Elliptic Filter Design

and FN(w) = d(NUK, K), w= cd(UK, R)

where ad is Jacobi elliptic function

where Gp and Gre are design specifications and are 0.99 and 0.001 respectively.

[Elliptic order of first kind:] do

to give us the quarter period [K,K'] and modulus [K,K,']

As it is complex to compute by - hand, we use MATLAB's command. [ellipte as:

[K, K-prime] = ellipk (k); K=1.8097 K'=1.9042 [K, K,-prime] = ellipk (k); K, =1.5708 K'= 9.9024

We can then compute order as:



```
From the filter order, we can compute
 selectivity factor & cde(u, a)
 where cole is complex normalized Jacobi
 elliptic function, u is 21-1, where
  i = 1,2 .... 12
 Using MATLAB, we get 2:= [0.9745, 0.7572 ...
                                  0.2953]
  From &; , we can find the poles as:
  Z = ejwp/ke; = [-0.7922 ± 0.6102]
                     -0.3524 ± 0.9369j
                      0.9961 ± 0.08831j]
 Similarly, & = cde (u-jvo, k)
 From &i, we can find the poles as:
  P = 2 mp/2: = [ 0.2483 ± 0.8786 j
                    0.3701 ± 0.6318 j
                    0.5299 ± 0.2397;]
 Using the poles and zeros, we construct
 the tf as:
 H(s) = (52-1.9925+1)(52+1.5845+1)(52+0.70475+1)
         (52-1.069+0.3382)(62-0.74018 + 0.5361) ...
                       (32-0.49665+0.8335)
The coefficients [b, a] can be found from
MATLAB as zpatf (z,p,k)
```

MATLAB Code


```
% The given Specifications are
G_p = 0.99/1.01;
G_s = 0.001/1.01;
T = 1;
omega_p = 2 / T * tan(0.4 * pi / 2);
omega_s = 2 / T * tan(0.6 * pi / 2);
epsilon_p = sqrt(1 / G_p ^ 2 - 1);
epsilon_s = sqrt(1 / G_s ^ 2 - 1);

% calculate filter order
k = (omega_p * 1.6336/1.4531) / (omega_s * 1.9578/2.7528);
k1 = epsilon_p / epsilon_s;
[K, K_prime] = ellipk(k);
[K1, K1_prime] = ellipk(k1);
```



```
N = ceil((K1_prime / K1) / (K_prime / K));
k = ellipdeg(N, k1);
L = floor(N / 2);
r = mod(N, 2);
i = (1:L)';
u = (2 * i - 1) / N;
zeta_i = cde(u, k);
z_a = (omega_p * 1.6336/1.4531) * 1i ./ (k * zeta_i);
v0 = -1i * asne(1i / epsilon_p, k1) / N;
p_a = (omega_p * 1.6336/1.4531) * 1i * cde(u - 1i * v0, k);
p_a0 = (omega_p * 1.6336/1.4531) * 1i * sne(1i * v0, k);
z = cplxpair([exp(z_a); conj(exp(z_a))]);
p = cplxpair([exp(p_a); conj(exp(p_a))]);
b = [ones(L, 1), -2 * real(1 ./ z_a), abs(1 ./ z_a) .^ 2];
a = [ones(L, 1), -2 * real(1 ./ p_a), abs(1 ./ p_a) .^ 2];
    b = [G_p, 0, 0; b];
    a = [1, 0, 0; a];
    b = [1, 0, 0; b];
    a = [1, -real(1 / p_a0), 0; a];
w = linspace(0, pi, 2048);
H = freq_resp(b, a, w);
figure(1);
subplot(211)
plot(w, 20 * log10(abs(H)));
axis([-inf inf -100 0])
xticks([0 (0.2 * pi) (0.4 * pi) (0.6 * pi) (0.8 * pi) pi])
xticklabels({'0', '0.2\pi', '0.4\pi', '0.6\pi', '0.8\pi', '\pi'})
xlabel('Normalized Frequency (\times\pi rad/sample)');
ylabel('Magnitude (dB)');
title('Magnitude Response of Elliptic Filter N = 6 (dB)');
```







- 2. In MATLAB, load a clean and noisy signal (uploaded to LMS), design a filter to suppress all frequencies except 1kHz and 1.5kHz. You are only allowed to use a 2nd order Butterworth bandpass filter and a 2nd order Butterworth band stop filter. Devise a scheme to achieve your target with a combination of these two filters. The sampling frequency of the signal is 6kHz.
 - a) Plot clean and noisy signals as well as their frequency spectrums (recall labs). The x-axis and y-axis should be correctly labeled. The x-axis should be in Hz while y-axis should be spectral magnitude.
 - b) Design and plot bandpass and band stop filters and plot their magnitude and phase responses. You can use MATLAB command "butter". Apply the filters on the noisy signal and plot the output.

```
Devised Approach
 to remove unwanted frequencies, and then applying a bandpass filter
load('data.mat')
fs = 6e3; % sampling frequency
N = 2*fs; % number of samples
t = linspace(0, 1, 500);
df = fs / N;
index = -N / 2:(N / 2) - 1;
 = (df * index);
X = fftshift(fft(x, N)); % compute the DFT of x
Xn = fftshift(fft(xn, N)); % compute the DFT of xn
figure(1)
subplot(211)
plot(t, x)
title('Clean Signal in Time Domain')
xlabel('Normalized Time (s)')
ylabel('Amplitude')
subplot(212)
```




```
plot(f, abs(X))
title('Clean Signal in Frequency Domain')
xlabel('Frequency (Hz)')
ylabel('Amplitude')
```






```
% plot the noisy signal (t and F)
figure(2)
subplot(211)
plot(t, xn)
title('Noisy Signal in Time Domain')
xlabel('Normalized Time (s)')
ylabel('Amplitude')
subplot(212)
plot(f, abs(Xn))
title('Noisy Signal in Frequency Domain')
xlabel('Frequency (Hz)')
ylabel('Amplitude')
```









```
%% Devised Approach
f1 = 1e3;
f2 = 1.5e3;
[b_bs, a_bs] = butter(2, [f1 f2]/(fs/2), 'stop');
xn_bs = filter(b_bs, a_bs, xn);
Xn_bs = fftshift(fft(xn_bs, N)); % compute the DFT of xn

% Bandpass Filter
f1 = 1e3;
f2 = 1.5e3;
[b_bp, a_bp] = butter(2, [f1 f2]/(fs/2), 'bandpass');
xn_bp = filter(b_bp, a_bp, xn_bs);
Xn_bp = fftshift(fft(xn_bp, N)); % compute the DFT of xn


%% Magnitude and phase response plots
figure(3)
freqz(b_bs, a_bs)
title('Magnitude and Phase Response of Bandstop Filter')
```









```
figure(4)
freqz(b_bp, a_bp)
title('Magnitude and Phase Response of Bandpass Filter')
```






```
%% Plotting the filtered output
figure(5)
subplot(211)
plot(t, xn_bp)
title('Filtered Signal in Time Domain')
xlabel('Normalized Time (s)')
ylabel('Amplitude')
subplot(212)
plot(f, abs(Xn_bp))
title('Filtered Signal in Frequency Domain')
xlabel('Frequency (Hz)')
ylabel('Amplitude')
```







3 Conclusion

n conclusion, filter designing is an essential aspect of signal processing. There are many different types of filters available, each with its own advantages and disadvantages. The type of filter that is best suited for a particular application will depend on the specific requirements of that application. In this assignment, we explored two different methods for designing filters: Elliptic and Chebyshev. We also explored a strategy for designing a band stop filter followed by a bandpass filter. This strategy can be used to achieve a very high degree of attenuation in the stopbands, while still maintaining a good passband response. Designing filters is a complex and challenging task. However, by understanding the different types of filters and the different design strategies available, we can select the best filter for a particular application and design it to meet the desired specifications.