# Lab 6: AVR Interrupts EE222: Microprocessor Systems

## Contents

1	Administrivia						
	1.1 Learning Outcomes						
	1.2 Deliverables	2					
2	Hardware Resources	2					
3	Interrupts						
	3.1 Timer Interrupts	3					
	3.2 Understanding the merits of interrupts	3					
4	Lab Tasks	6					
	4.1 Task A	6					

## 1 Administrivia

### 1.1 Learning Outcomes

By the end of this lab you will be able to:

1. Code timer interrupts for efficient scheduling in ATmega16A.

#### 1.2 Deliverables

You are required to submit

- Appropriately commented Source Code
- Experimental observations and problems you faced

in the beginning of next lab.

## 2 Hardware Resources

- ATmega16A Microcontroller Unit
- Universal Programmer
- Seven Segment Display
- Resistances  $47\Omega$
- Switch (You may use from the trainer kit)
- Led (You may use from the trainer kit)

## 3 Interrupts

In previous labs we implemented delays by polling the timer overflow flag. Although accurate, but this still is a process that consumes all the processing time (and energy) just waiting for a flag. In this lab we are going to use interrupts. Interrupts are implemented through special block of hardware integrated inside the processing device. Whenever some specified event occurs, the hardware halts the normal execution of code and move instruction pointer to a reserved block of code called interrupt service routine and the process is called interrupting the processor. To understand how this happens and in what basic forms the technique can be exploited, we will use the timer interrupts in this lab.

#### 3.1 Timer Interrupts

There are eight interrupts associated with timers. Whenever an event from the list below occurs,

- 1. The hardware halts normal execution of code.
- 2. Pushes the address of next instruction on stack.
- 3. Jumps to Program memory location specified in the table below.
- 4. Execute the code written there.
- 5. After successful execution pops back the address of instruction and continue normal execution.

Interrupt	Program Memory Location		
Timer 2 Compare Match	8000x0		
Timer 2 Overflow	A000x0		
Timer 1 Capture Event	0x000C		
Timer 1 Compare Match A	0x000E		
Timer 1 Compare Match B	0x0010		
Timer 1 Overflow	0x0012		
Timer 0 Compare Match	0x0014		
Timer 0 Overflow	0x0016		

## 3.2 Understanding the merits of interrupts

Suppose we have to design a system such that two independant tasks are to be performed at the same time. One is to toggle an led with 4Hz frequency and other is to relay the state of a switch to another led.

If we use a delay function to produce 250ms delay, our microcontroller will get busy polling over the overflow flag (or Compare match flag if using CTC mode) and it will not be able attend the transitions in state of switch for about 250ms.

Interrupts can rescue us from such situations. Let us understand the code below,

```
1 #include <avr/io.h>
2 #include <avr/interrupt.h>
4 #define LED01 0
                        // defining led 1 location
                        // defining led 2 location
5 #define LED02
                  1
6 #define SW
                        // definig switch location
  int main()
9
10
       * Setting the pin number specified by macros
        * LED01 and LED02 of port B as output pins.
13
        * Pin specified by macro SW will naturally
        * be set as input.
16
       */
      DDRB = (1 < < LED01) | (1 < < LED02) ;
17
      PORTB = (1 < \langle LED01 \rangle); // turning on led 1
18
19
      TCNT0 = 12;
                        // initializing timer
20
                        // setting prescalar clk / 1024
      TCCR0 = 0x05;
                        // enable global interrupt
22
       sei();
      TIMSK = 0x01;
                        // enable timer 0 overflow interrupt
23
       while (1)
24
       {
25
           if ( (PINB & (1 \ll SW) ) != 0) // check if switch is high
26
27
               PORTB = (1 < LED02); // turn on led 2
28
           else
30
31
               PORTB &= \sim(1<<LED02); // turn off led 2
34
35
36
  ISR (TIMER0_OVF_vect)
37
38
      TCNT0 = 12:
                                      // reload timer
39
      PORTB = PORTB ^ (1 << LED01); // toggle led 1
40
```

We are using clock of 1MHz with 1024 prescalar,

Time for one\_tick = 
$$1024/1M = 1024\mu s = 1.024ms$$
  
Ticks for  $250ms = 250/1.024 = 244$   
Value to be loaded in  $TCNT0 = 256 - 244 = 12$ 

"sei()" function defined in "avr/interrupt.h" sets the gloabal interrupt enable bit. If this bit is not set, no interrupt will be responded to.

TIMSK (Timer Interrupt Mask) register contain bits to enable individual timer interrupts.

OCIE2	TOIE2	TICIE1	OCIE1A	OCIE1B	TOIE1	OCIEO	TOIEO

TIMSK $\mathbf{bit}$	Function
OCIE2	When 1, enables Timer 2 Compare Match interrupt
TOIE2	When 1, enables Timer 2 Overflow interrupt
TICIE1	When 1, enables Timer 1 Input Capture interrupt
OCIE1A	When 1, enables Timer 1 Compare Match A interrupt
OCIE1B	When 1, enables Timer 1 Compare Match B interrupt
TOIE1	When 1, enables Timer 1 Overflow interrupt
OCIE0	When 1, enables Timer 0 Compare Match interrupt
TOIE0	When 1, enables Timer 0 overflow interrupt

Note that the number of timer interrupts is same as the number of timers related flags in TIFR.

In while loop the switch is being polled and its state is being relayed to led 2. In parallel with this process, timer is continuously being incremented and as it overflows, the timer 0 overflow flag is set. The processor is interrupted, it stops whatever it is executing at that moment (in the main function) and jumps to "ISR(TIMER0\_OVF\_vect)", executes the code written there and then resumes from where it stopped the normal processing. All these steps are performed by hardware itself to make the life of programmer easy.

While the processor is attending an ISR (Interrupt Service Routine), the flag which was the cause of that interrupt (like TOVO in example above) is automatically cleared by the processor.

Service Routines for other timer interrupts can be written by passing following macros (vector names) defined in "avr/interrupt.h" as an argument to ISR.

Interrupt	Vector name			
Timer 2 Compare Match	TIMER2_COMP_vect			
Timer 2 Overflow	$TIMER2\_OVF\_vect$			
Timer 1 Capture Event	$TIMER1\_CAPT\_vect$			
Timer 1 Compare Match A	TIMER1_COMPA_vect			
Timer 1 Compare Match B	$TIMER1\_COMPB\_vect$			
Timer 1 Overflow	$TIMER1_OVF_vect$			
Timer 0 Compare Match	$TIMER0\_COMP\_vect$			
Timer 0 Overflow	$TIMER0\_OVF\_vect$			

More than one ISRs can be written in a program but for different interrupts (not for the same interrupt). When the processor is servicing one interrupt, it ignores other interrupts.

## 4 Lab Tasks

### 4.1 Task A

- 1. Connect a seven segment display "SSEG" with your ATmega16A.
- 2. Connect an led "LED" and a switch "SW" with your ATmega16A.
- 3. The SSEG should display continuous counting from 0-9 and then again from 0, each digit with a 1 second delay.
- 4. At the same time, the state of SW should be relayed to LED (-that is, if SW is high, LED should be on and vice versa).
- 5. Note that both of the tasks are completely independent and should be performed in parallel without lag.