## Introduction to the Arduino

March 15, 2019

## 1 Introduction



Figure 1: The Arduino Uno microprocessor.

In this lab, we will learn to use the Arduino microprocessor, which we will be using throughout the course to collect experimental data. The model we will use is the Arduino Uno. The Arduino Uno is fairly robust and inexpensive, so you should definitely be comfortable to experiment with them. However, to avoid the potential to damage the boards, you should \*NOT\* supply any external power to the Arduino (e.g. from your proto-board PB-503, bench-top power supply, or function generator.)

## 2 The Arduino

Step 1: The main Arduino website, which includes lots of supporting documentation, is located at http://arduino.cc. Acquaint yourself with this site.

Step 2: The lab PCs have the Arduino software installed, and each team will have an Arduino to work with. Follow the instructions for using the "Arduino Desktop IDE" located here: https://www.arduino.cc/en/Guide/ArduinoUno.

**Step 3:** Adjust the pattern of the LED blink example to a slower rate.

**Step 4:** The Arduino tutorials and built-in-examples are often excellent starting points for you own projects, browse the tutorials here:

https://www.arduino.cc/en/Tutorial/HomePage




Figure 2: On the proto-board shield, the push-button switch S1 shorts the point labeled "+" to ground when pressed. Use a pull-up resistor  $R_1 = 10 \text{ k}\Omega$  to set the voltage at point + to 5 V unless the push-button  $S_1$  is engaged.

**Step 5:** Read, build and upload the DigitalReadSerial example. You will need the Arduino protoshield, which includes a pushbutton and LEDs, to complete this part. Note: to use the pushbutton switch labeled S1 on the Prototype Shield v.5, note that hole labeled (+) is shorted to ground when the push button is pressed. Your protoboard shield should already have a wire soldered at this point. Use a pull-up resistor as shown if Fig. 2.

**Step 6:** Modify it to only output to the serial port after a change in value. This is the **sign-off** point for the lab.

**Step 7:** Read, build and upload the Read Analog Voltage example. You will need a potentiometer (variable resistor) for this and the following step.

Step 8: Read, build, and upload the Analog Input example.

## 3 Lab Report

There is no lab report for this lab.