



YS2R6X400E9183544 / BMS, Brake management system / E 37, ABS control unit / ABS E / V, Solenoid valves / V47, Control valve, third axle, right-hand side

C 102, Connector





From front, round sockets. Cable side, round sockets. From front, round pins. Cable side, round pins.












C 102, Connector

V 47, Control valve

- Pressure increase (Normal mode): The intake is open and venting is closed.
- Pressure drop: The intake is closed and venting is open.
- Pressure retention: The intake and venting are closed.

Control valve connection A and schematic







Connection number	Task
Pin 1	Supply to solenoid valve for venting
Pin 2	Ground
Pin 3	Supply to solenoid valve for intake
Port 1	Intake
Port 2	Outlet
Port 3	Venting

V 47, Control valve







V 47, Control valve