ARM Datapath: The Barrel Shifter



blue = Rm through the shifter **green** = Rn in / Rd out **red** = flags and carry-in