

STR: Storing a Word to Memory

Before: R1 = 0x11223344, [0x40020014] = 0x00C0FFEE



STRH: Storing a Halfword to Memory



STRB: Storing a Byte to Memory

