Control Flow, Functions and the Stack

Introduction to ARM Cortex-M Microprocessors — Chapter 7

Muním Zabidi

Faculty of Electrical Engineering, Universiti Teknologi Malaysia

Table of Contents

1. Why This Matters
2. Flags and Conditions
3. Branches and Control Structures
4. Subroutines
5. The First Limitation: Nested Calls
6. The Stack
7. The AAPCS

Why This Chapter Matters

Every `if`, `while` and function call becomes the same two things: a comparison that sets flags, and a branch that tests them. This explains why a signed and an unsigned comparison can differ on the same bits, and why a recursive function can crash a microcontroller. It also prepares you for interrupts, which are function calls made by hardware.

After this chapter, you can:

1. Explain the `S` suffix and condition codes.
2. Branch on a condition with `CMP`, `TST` and suffixes.
3. Choose signed or unsigned condition codes correctly.
4. Translate C `if/else` and loops to assembly.
5. Trace SP through `PUSH` and `POP` on a full descending stack.
6. Call with `BL`, return with `BX LR`, and explain why nested calls save LR.
7. State the AAPCS rules.

© Muním Zabidi

Table of Contents

1 Why This Matters

2 **Flags and Conditions**

3 Branches and Control Structures


4 Subroutines

5 The First Limitation: Nested Calls

6 The Stack

7 The AAPCS

Processor Status Register



Flag	Description
N	1 means result is negative
Z	1 means result is zero
C	unsigned add: 1 means result had a carry out; unsigned subtract: 0 means it had a borrow; shifts: the bit shifted out
V	signed add/subtract: 1 means the result overflowed

Setting the Flags

The S suffix

```
ADD  R0, R1, R2   ; flags unchanged

ADDS R0, R1, R2   ; updates N Z C V
```

Compare and test — no result kept

Instruction	Computes
`CMP Rn, Op2`	Rn − Op2
`CMN Rn, Op2`	Rn + Op2
`TST Rn, Op2`	Rn & Op2
`TEQ Rn, Op2`	Rn ^ Op2

Why compilers care about S

A compiler writes `SUBS` instead of `SUB` when a branch right after it needs the flags. So seeing `S` in a listing tells you a decision is coming.

`CMP` is `SUBS` that throws the answer away.

© Munim Zabidi

Condition Codes

Code	Meaning	Flags
EQ	Equal	Z=1
NE	Not equal	Z=0
MI	Negative	N=1
PL	Positive or zero	N=0
VS	Overflow	V=1
AL	Always (default)	—

Code	Meaning	Flags
HS/CS	Unsigned $\geq$	C=1
LO/CC	Unsigned $<$	C=0
HI	Unsigned $>$	C=1, Z=0
LS	Unsigned $\leq$	C=0 or Z=1
GE	Signed $\geq$	N=V
LT	Signed $<$	N$\neq$V
GT	Signed $>$	Z=0, N=V
LE	Signed $\leq$	Z=1 or N$\neq$V

Signed and unsigned comparisons are different instructions

GT and HI both mean “greater than.” But one reads N and V, and the other reads C and Z. Use a signed code for signed data: for example, $-1 > 5$ is false when signed, but true when unsigned.

Table of Contents

1 Why This Matters

2 Flags and Conditions

3 **Branches and Control Structures**

4 Subroutines

5 The First Limitation: Nested Calls

6 The Stack

7 The AAPCS

Branch Instructions

A branch writes a new value into the Program Counter. This redirects execution. Four forms matter:

Instruction	Meaning
`B label`	Unconditional branch — the basic jump
`BL label`	*Branch with link* — LR = return address, then jump: a subroutine call
`BX Rn`	*Branch and exchange* to an address in a register; `BX LR` returns

Function addresses have their low bit set

The Cortex-M4 executes only Thumb instructions. Function addresses therefore have bit 0 set to mark a valid Thumb target, and `BX`/`BLX` check it. In a debugger, this looks like an off-by-one error, until you know to expect it.

© Muním Zabidi


All Control Structures Are Just Branches

Every high-level control structure you are about to see is built from exactly the two pieces just introduced: a comparison that sets flags, and a conditional branch that tests them. Nothing new is added — only combined.

C construct	Built from
`if`	one conditional branch
`if/else`	one conditional branch + one unconditional branch
`while`	one conditional branch + one backward branch
`do/while`	one backward conditional branch, no forward branch at all

Keep this map in view through the next few slides: each worked example below is one more arrangement of the same two pieces, never a new mechanism.

The `if` Construct



"opposites"


```
if ( a == b )
    x = 1;
```

```
        CMP   R0, R1
        BNE   endif
        MOV   R2, #1
endif
```

Read the branch as the opposite of the C condition: the code tests `x > 0`. The assembly branches away with `BLE` to *skip* the body when this is not true.


© Muním Zabidi

The Two Paths Through a Plain `if`



The conditional branch tests the *opposite* condition and jumps over the if-block. On $a = b$ the branch is not taken, and execution *falls through* into the block.

The `if-else` Construct



```
if (a == b)
    x = 1;
else
    x = 2;
```

```
        CMP   R0, R1
        BNE   else_block

; if-block: a == b
        MOV   R2, #1
        B     endif


else_block
        ; Else-block: a != b
        MOV   R2, #2          ; x = 2

endif
```

Both arms fall through without `B endif`

The `true` arm must jump past the `else` arm. Without `B endif`, execution falls through and runs both arms.

The Two Paths Through an `if-else`




The conditional branch tests the *opposite* condition and jumps over the if-block; the unconditional branch jumps over the else-block. Execution reaches exactly one `MOV` — never zero, never both.

The `while` Construct

- Implements both the while and for keywords in C
- The condition is tested before the loop starts: a pre-test loop

`sum = 1+2+3+4+5`



```
sum = 0;
for (i = 1; i <= 5; i++)
    sum = sum + i;
```

```
        MOV   r0, #0
        MOV   r1, #1
loop
        CMP   r0, #5
        BGT   done
        ADD   r0, r0, r1
        ADD   r1, r1, #1
        B     loop
done
```

© Muním Zabidi

Worked Example: Popcount

- **Popcount** (population count) means counting the number of bits that are 1

This example is primarily about reusing flags generated by another instruction: LSRS shifts *and* sets flags, so one instruction does the work `while` needed anyway.

```
int x = 0x5555;   // input
int c = 0;
for (; x != 0; x >>= 1)
    if (x & 1)
        c++;
```

```
        LDR   r1, =0x5555
        MOV   r0, #0        ; count = 0
loop
        AND   r2, r1, #1    ; check bit 0
        ADD   r0, r2        ; c++
        LSRS  r1, r1, #1    ; next bit
        BNE   loop
done
```

A new principle: one instruction, two jobs


LSRS shifts *and* sets **Z** when the remaining bits reach zero, so the shift itself supplies the condition the next branch needs — no separate comparison. This is the same S-suffix idea from two slides ago, now doing useful work *and* preparing the next decision. Note: if x starts at 0, this loop still runs once.

© Muním Zabidi

The do-while Construct

The condition is tested after the loop body runs: a post-test loop.

sum = 1+2+3+4+5



```
sum = 0;
i = 1;
do {
    sum = sum + i;
    i++;
} while (i <= 5);
```

```
        MOV   r0, #0
        MOV   r1, #1
loop
        ADD   r0, r0, r1
        ADD   r1, r1, #1
        CMP   r1, #5
        BLE   loop
```

A do-while always runs its body at least once. The comparison comes after the work, not before.

Loops: Counting Down Is Cheaper

The flags are not only for comparisons — an arithmetic instruction with the `S` suffix can supply them too, exactly as `LSRS` did in **Popcount**.

Counting up

```
     MOV  r0, #0
loop
     ...          ; body
     ADD  r0, #1
     CMP  r0, #10
     BLT  loop
```

Three instructions of overhead per iteration.

Counting down

```
     MOV  r0, #10
loop
     ...          ; body
     SUBS r0, #1  ; and set flags
     BNE  loop
```

Two — the `CMP` is gone.

Why the `S` suffix saves an instruction

`SUBS` decrements *and* sets **Z** when the result reaches zero, so no separate comparison is needed. This is the most common hand-optimisation in ARM assembly, and compilers do it automatically whenever the loop order does not matter.

Worked Example: Find Maximum

- Find the biggest signed word value in a memory block, starting at a known address

```
int max = 0;
int *ptr = (int *)0x20001000;
int nwords = 64;
do {
    if (*ptr > max)
        max = *ptr;
    ptr++;
    nwords--;
} while (nwords);
```

```
        MOV     r0, #0          ; max
        LDR     r1, =0x20001000 ; ptr
        MOV     r2, #64         ; nwords
loop
        LDR     r3, [r1], #4    ; *ptr, ptr++
        CMP     r0, r3
        BGE     skip
        MOV     r0, r3          ; new max
skip    SUBS    r2, #1
        BNE     loop
```

`LDR Rn, =value` loads a number, not a variable

`ptr` and `nwords` hold a *fixed* starting address and count, known at compile time. The assembly loads those known values directly into `r1`/`r2` — there is no need to read `ptr`/`nwords` back out of memory, since nothing else in the program ever changes them.

Table of Contents

1 Why This Matters

2 Flags and Conditions

3 Branches and Control Structures

4 **Subroutines**

5 The First Limitation: Nested Calls

6 The Stack

7 The AAPCS

Why Subroutines Exist

As programs grow, the same instructions are often needed in more than one place. Rather than copying them, place them in one block and call that block whenever it is needed.

```
uint32_t read_gpioport(void) {
    return GPIOA->IDR;
}
```

A caller simply writes

```
uint32_t state = read_gpioport();
```


The same idea applies in assembly: the instructions that read the port live in one place, and the program branches there whenever the value is needed — with one new requirement. A subroutine must return to the instruction after the call.

This is how assembly actually shows up in real firmware

Almost nobody writes a whole project in assembly. The usual pattern is C code — `main()` and everything it calls — with one or two hand-tuned routines written in assembly and linked in. `read_gpioport` is exactly that: C calls it like any other function, with no idea its body is assembly.

Calling and Returning: BL and BX LR

- BL branches to a subroutine and records where execution should return.
- The target address is loaded into the PC, while the address of the instruction after BL is placed in LR.
- LR therefore holds the return address for the subroutine.
- Rather than pushing the return address onto the stack, ARM initially keeps it in the LR register.



BL calls a subroutine; BX LR returns from it.

© Muním Zabidi

Returning a Value

How does a subroutine hand a result back? By another convention: the return value goes in `R0`.

```
read_gpioport
        MOVW  R1, #0x0014   ; GPIOA_IDR low half
        MOVT  R1, #0x4002   ; GPIOA_IDR high half
        LDR   R0, [R1]      ; read GPIO input register
        BX    LR            ; return, with result in R0
```

```
        BL    read_gpioport
        ; R0 now contains the GPIO port value
```

`read_gpioport` takes no arguments, yet still returns a value — the two conventions are independent. The next slide shows `R0` used for an argument too.

Now consider a function that needs information *from* its caller:

```
uint32_t read_bit(uint32_t port, uint32_t mask) {
    return port & mask;
}
```

The first four 32-bit arguments travel in `R0`–`R3`:

- `R0` = `port`
- `R1` = `mask`
- `R0` = result, on return

```
read_bit
    AND   R0, R0, R1
    BX    LR
```

`R0` therefore plays two roles at different points in the same call: it carries a value in, as the first argument, and it carries the result out, once the function returns.

`R0`–`R1` for arguments, `R0` for the return value — this is not a rule invented for one function. It is a shared convention every function obeys. Two more leaf subroutines show it holding under slightly different conditions, before asking what happens once one subroutine calls another.

© Muním Zabidi

Worked Example: A Value That Must Survive

`read_gpioport` and `counter` share the same shape — no parameters, one result in `R0`, a leaf function — but `counter` needs something `read_gpioport` did not: a value still there the next time it is called.

```c
int counter(void) {
    static int n = 0;
    return ++n;
}
```

```
counter
     LDR   R0, =n
     LDR   R1, [R0]
     ADDS  R1, R1, #1
     STR   R1, [R0]
     MOV   R0, R1
     BX    LR
```

A register cannot hold `n`

Every register's contents are gone the moment the function returns. `n` must live in memory, at a fixed address, like any global or static variable. The register traffic here only gets that value into `R0` and back out again.

Worked Example: `x = foo(y, z)`

`read_bit` returned the result of a single `AND`. A real function body is rarely that short:

```
int foo(int a, int b) {
    return a * 2 + b;
}

x = foo(y, z);
```

```
foo
     LSLS  R0, R0, #1   ; a*2
     ADDS  R0, R0, R1   ; +b
     BX    LR

; y already in R0, z in R1
     BL    foo
     MOVS  R4, R0        ; x = result
```

Same convention, more work inside

`a*2` is the shift-instead-of-multiply trick from Chapter 6 — the calling convention changes nothing about how the body is optimised. `R0` still carries the argument in and the result out, exactly as `read_bit` showed; only the number of instructions in between has grown.

© Muním Zabidi

The Internals Can Change Without the Caller Knowing

Every example so far has had exactly one implementation. Consider a function called exactly like any other:

```
int popcount(uint32_t x);
...
int n = popcount(mask);
```

A straightforward version checks every bit, shifting right until nothing remains — the same loop as the earlier Popcount example, now wrapped as a callable function:

```
popcount
    MOV   R1, #0        ; count = 0
loop
    ANDS  R2, R0, #1    ; check bit 0
    ADD   R1, R1, R2    ; count += bit
    LSRS  R0, R0, #1    ; next bit
    BNE   loop
    MOV   R0, R1
    BX    LR
```

A Faster popcount: Same Signature

One loop iteration per bit position — 32 in the worst case. A well-known trick does better: `x & (x - 1)` clears the lowest set bit, so the loop runs once per 1 bit, not once per position.

```
popcount
    MOV   R1, #0        ; count = 0
    CMP   R0, #0
    BEQ   done
loop
    ADD   R1, R1, #1    ; count++
    SUBS  R2, R0, #1    ; R2 = x - 1
    ANDS  R0, R0, R2    ; x &= (x - 1)
    BNE   loop
done
    MOV   R0, R1
    BX    LR
```

Same signature, same calling sequence — different caller cannot tell

Argument in `R0`, result in `R0`, `BX LR` to return — identical to the first version. A function's internals can be rewritten and replaced, and every caller keeps working untouched.

Table of Contents

1 Why This Matters

2 Flags and Conditions

3 Branches and Control Structures

4 Subroutines

5 **The First Limitation: Nested Calls**

6 The Stack

7 The AAPCS


Leaf Versus Non-Leaf Subroutines

- A leaf subroutine does not call another subroutine. It executes no BL, so its LR remains unchanged.
- A non-leaf subroutine calls another subroutine. Its next BL will overwrite the value currently in LR.

This gives us an important rule:

A non-leaf subroutine must save its LR before making another call.

The stack provides a convenient place to save it.




Filled boxes are leaf subroutines. Plain boxes call another subroutine and therefore must preserve LR.

© Muním Zabidi

The Problem: A Second BL Overwrites LR

Consider this three-level call: `main` calls `foo`, and `foo` calls `bar`.



When `main` executes `BL foo`, the return address for `main` is placed in LR.

But then `foo` executes `BL bar`. This places a new return address in the same register, overwriting the original address.

Now `bar` can return to `foo`, because LR contains the correct address for that return. However, the original return address back to `main` has been lost.

Table of Contents

1 Why This Matters

2 Flags and Conditions

3 Branches and Control Structures

4 Subroutines


5 The First Limitation: Nested Calls

6 **The Stack**

7 The AAPCS

What Is a Stack?

- A stack is a region of ordinary SRAM managed using the Stack Pointer (SP, R13).
- It follows a last-in, first-out (LIFO) rule: the most recently stored item is the first one removed.
- The stack can be located anywhere in the memory map.
- It is commonly used to hold return addresses, saved registers, and local variables.
- All subroutines typically share the same stack.



- The stack is typically initialized at the top of SRAM.
- Initially, SP points to the top of the stack region.
- As items are pushed, SP moves toward lower addresses.
- The heap, when present, typically grows upward from the opposite direction.

How Does the Stack Grow?

- The stack grows and shrinks by moving the Stack Pointer (SP).
- On a 32-bit Cortex-M processor, each stack word occupies 4 bytes.

PUSH

1. Move SP down by 4 bytes:


$$SP \leftarrow SP - 4$$

2. Store the value at the new SP address.

POP


1. Read the value at the current SP address.
2. Move SP up by 4 bytes:

$$SP \leftarrow SP + 4$$



© Muním Zabidi

Why Is It Called Last-In, First-Out?



Three PUSH operations place three registers on the stack. Because each new value is placed on top of the previous one, the first POP retrieves the value pushed last.

The LIFO rule

The last value pushed is the first value popped

The Stack Must Stay Balanced

- A subroutine may use the stack temporarily to save registers or other data.
- Before returning, it must restore the stack to the state it had on entry.
- In simple terms:

Every PUSH must eventually have a matching POP.

Example

3 registers pushed $\longrightarrow$ SP moves down by $3 \times 4 = 12$ bytes $\longrightarrow$ 3 registers popped $\longrightarrow$ SP returns to its original value

The order matters too: values must be popped in the reverse order in which they were pushed.

What Happens When the Rules Are Broken?

The stack is ordinary memory. If SP moves outside the space or contents intended for the stack, the program can behave unpredictably.

Too many PUSHes

- SP keeps moving toward lower addresses.
- The stack can exceed its allocated region.
- It may collide with other memory regions.
- This is commonly called stack overflow.

Too many POPs

- SP moves beyond the valid stack contents.
- A POP may read data that was never pushed.
- The result may be incorrect data or a fault.
- This is commonly called stack underflow.

© Muním Zabidi

Table of Contents

1 Why This Matters

2 Flags and Conditions

3 Branches and Control Structures

4 Subroutines

5 The First Limitation: Nested Calls

6 The Stack

7 **The AAPCS**

Saving the Return Address

```
        BL    AddNumbers

AddNumbers
        PUSH  {LR}      ; save caller's return address
        ADD   R0, R0, R1
        POP   {PC}      ; restore and return
```

Before making another call, a non-leaf subroutine can move its return address from LR to the stack:

```
PUSH {LR}
```

This preserves the address even when a later BL overwrites LR.

At the end, `POP {PC}` restores the saved address directly into the program counter, returning execution to the caller.


The key idea

LR is convenient for a single call, but it cannot preserve multiple return addresses.

The stack turns one temporary register into persistent storage for the return address.

A leaf subroutine does not need this step: because it makes no further call, its LR remains intact and it can return with `BX LR`.

The Stack Can Save More Than LR



PUSH can save several registers in one instruction. For example, `PUSH {R4, LR}` saves both R4 and the return address on the stack.

When the subroutine finishes, the same registers can be restored with `POP {R4, PC}`.

Restoring LR into PC returns execution to the caller, while restoring R4 returns it to its original value.


Why a Call Needs More Than Registers

The examples so far passed arguments in `R0`/`R1` and returned a result in `R0`, by convention. The nested-call problem just solved — save `LR` before a second `BL` — raises the same question one level up: which registers are safe to overwrite, and which must a callee restore?

Every function you write, and every library function you call, needs the *same* answer to that question — otherwise C code and hand-written assembly could never call each other safely. That shared answer is a formal convention: the AAPCS.

How Do Two Functions Agree on Anything?

Your C code and a library compiled years ago must agree on where arguments go, where results return, and who preserves what — with no run-time negotiation.



Procedure Call Standard for the ARM Architecture (AAPCS)

The AAPCS is that agreement

It defines where arguments and return values go and which registers a function must preserve. This lets C and assembly functions call each other safely.

Registers	Rule
`R0–R3`	Arguments 1–4; `R0` also carries the return value. Caller-saved: the callee may overwrite them.
`R4–R11`	Callee-saved: the callee must restore any it uses.
`R12`	Scratch register.
`R13–R15`	SP, LR, PC.

Arguments beyond the fourth go on the stack — the same mechanism just used to save LR.

© Muním Zabidi

Do No Damage: Callee-Saved Registers

A function may use R4–R11, but it must restore them before returning. The pattern is the same as saving LR: save, use, restore.

```
foo  PUSH {R4, R5}    ; save registers this function will use
     MOV  R4, #0
     MOV  R5, #0xAB
     ADD  R4, R4, R5
     ...
     POP  {R4, R5}    ; restore their original values
     BX   LR
```

Why this matters

The caller can continue using R4 and R5 after `foo` returns, knowing their values are unchanged. No special agreement is needed at each call site.

A Function Call Viewed at Five Levels


Level	Representation
Physical hardware	SP drives the address bus; SRAM cells hold the saved LR
Register	`R0`, `R1` carry the arguments; `LR` holds the return address
C	`sum = AddNumbers(5, 10);`
Assembly (call)	`MOV R0, #5` / `MOV R1, #10` / `BL AddNumbers`
Assembly (callee)	`PUSH {LR}` ... `POP {PC}`

One call, five simultaneous descriptions

Chapters 1–7 have all built this table. The C statement reaches a hardware SRAM cell, through registers, instructions, and bytes.

© Muním Zabidi

Summary



Terminology covered

- APSR flags, condition codes
- Signed vs unsigned suffixes
- BL, BX LR
- Full descending stack
- AAPCS

Next: Chapter 8

General Purpose Input Output

The book stops being theory. A physical pin changes voltage.

© Muním Zabidi