

START

data bit

ACK

STOP

SDA

SCL

SDA falls while
SCL is HIGH

slave pulls SDA low
to acknowledge

SDA rises while
SCL is HIGH

