Add AWC Features

Thursday, August 1, 2024 12:34 PM

Step 1 :



Step 2 :



Step 3 :


Teamcenter 14
SIEMENS
Overview
TEAMCENTER
Maintenance
Configuration Mainten
Configuration Maintenance
Select the configuration upon which you would like to perform a maintenance activity such as adding, removing, or modifying a feature. You can also choose to create a new configuration. If there is no configuration in this installation, then configuration maintennance and remove options will be disabled.
Add new configuration
Perform maintenance on an existing configuration
Upgrade a configuration from another installation
Remove configuration (uninstall)
Next
Cancel

Step 4 :


Teamcenter 14
SIEMENS
Overview
TEAMCENTER
Maintenance
Configuration Mainten
Old Configuration
Old Configuration
Select an existing configuration on which to perform a feature maintenance activity.
Installation at D:\Apps\Siemens\TC14\TCROOT
TC14
Back
Next
Cancel

Step 5 :



Step 6 :



Step 7 :
Enable all the services which I have mentioned below.





Active Admin
Preference Management


Active Architect
UI Builder

Indexing Server
Active Workspace Indexing Engine
Active Workspace Indexer


Search: Active
Server Extensions
Active Workspace
Rules of Credit
Active Architect Core
Active Collaboration
Active Collaboration for Retail Solution [DEPRECATED]
Active Content Structure
Advanced PLM Services Core
Browse...


Search:
Vendor Management
Visualization Extension
Workflow
Easy Plan Graphics
Electronic Work Instructions
Finish Management


The features listed below are installed in the current configuration. Select a featu
add it to this configuration. Deselect a feature to remove it; those features which
grayed out are not removable.
Search: Workflow
Component Manufacturer Active Workspace
Active Admin
Active Admin Core
Active Workspace User Management
Preference Management
Viewer Administration
Active Architect
Aerospace and Defense
CAE Simulation Management
Integrated Program Planning & Execution (IPP&E)
Browse


Search: Workflow
Viewer Administration
Active Architect
Client Configuration
Logical Object
TC XML Import and Export
XRT Editor
Aerospace and Defense
CAE Simulation Management
Integrated Program Planning & Execution (IPP&E)
MRO
Space Required

Step 8 :



Step 9 : infodba



Step 10 :



Step 11 :



Step 12 :



Step 14 :



Step 15 ;



Step 16 :



Step 17 :



Step 18 :



Step 19 :



Step 20 :



Step 21 :



Step 22 : enter infodba



Step 23 :



Step 24 :



Step 25 :



Step 26 :



Step 27 :

Confirmation
Review the following features and configuration information then click the button to begin.
Features
Install: Active Workspace Indexing Engine
Install: Active Workspace Indexer
Install: Active Workspace Gateway
Install: Search for Active Workspace Client
Install: Active Workspace Client
Install: Preference Management
Install: UI Builder
Install: Relations Component
Install: Security
Install: Tcme AW Icons
Install: Project Assignment
Install: PS Component
Install: Active Workspace/Runtime Server
Install: Active Workspace/Active Workspace/Data Model
Install: Workflow
Install: Active Architect Core/Data Model
Install: Active Collaboration/Runtime Server
Install: Active Collaboration/Data Model
Install: Active Content Structure/Runtime Server
Install: Active Content Structure/Active Content Structure
Install: Authorization Active Workspace/Runtime Server
Install: Authorization Active Workspace/Data Model
Install: Active Admin Core/Data Model
Install: Active Content
Install: Workflow for Active Workspace
Install: Client Configuration
Install: XRT Editor
Install: Active Workspace User Management/Data Model
Install: Active Workspace User Management/Runtime Server
Install: Preference Management/Data Model
Start
Advanced...
Back
Cancel