NL-Cargo-Bike Operator Manual

Specifications

The NL-Cargo-Bike has a maximum payload of 180 kg. The battery capacity is 48 kWh.

Maintenance

The NL-Cargo-Bike must be serviced every 8000 km or every 12 months, whichever comes first.

The recommended tyre pressure is 2.2 bar. Check tyre pressure before every shift.

Safety

Operators must hold a valid licence for the NL-Cargo-Bike class and complete a pre-use inspection. Any defect must be reported to the workshop before the vehicle is used.