NL-Courier-L Operator Manual

Specifications

The NL-Courier-L has a maximum payload of 1200 kg. The battery capacity is 96 kWh.

Maintenance

The NL-Courier-L must be serviced every 8000 km or every 12 months, whichever comes first.

The recommended tyre pressure is 8.3 bar. Check tyre pressure before every shift.

Safety

Operators must hold a valid licence for the NL-Courier-L class and complete a pre-use inspection. Any defect must be reported to the workshop before the vehicle is used.