NL-Forklift-E2 Operator Manual

Specifications

The NL-Forklift-E2 has a maximum payload of 12000 kg. The battery capacity is 96 kWh.

Maintenance

The NL-Forklift-E2 must be serviced every 10000 km or every 12 months, whichever comes first.

The recommended tyre pressure is 8.3 bar. Check tyre pressure before every shift.

Safety

Operators must hold a valid licence for the NL-Forklift-E2 class and complete a pre-use inspection. Any defect must be reported to the workshop before the vehicle is used.