NL-Hauler-18 Operator Manual

Specifications

The NL-Hauler-18 has a maximum payload of 650 kg. The battery capacity is 72 kWh.

Maintenance

The NL-Hauler-18 must be serviced every 15000 km or every 12 months, whichever comes first.

The recommended tyre pressure is 2.2 bar. Check tyre pressure before every shift.

Safety

Operators must hold a valid licence for the NL-Hauler-18 class and complete a pre-use inspection. Any defect must be reported to the workshop before the vehicle is used.