# 1/8" Notch Style for Plywood or Acrylic

cut (minus-front)                    slot nudged

To nudge, set your keyboard units to ~0.018"
( go to A.I. Preferences/General/Keyboard units)