

1. Configuration steps for FernTel IP phones :

Below are the steps for configuring FernTel IP phones

Step 1 - Power up the phones using Net gear POE plus switch

Step 2 - Open [Grand stream webpage](#) after powering all the devices

Step 3 – Go to **Extension/Trunk** and click on **VOIP Trunks**

Step 4 – Click on **+Add SIP Trunk**

Step 5 - Select Register SIP trunk in the **Type** menu

Step 6 – Enter the **Provider name** as Grandstream and **hostname** as SIP.myprovider.com

Step 7 – Enter **Caller ID** name as MyTest, **User name** as 5001

Step 8 – Select UDP in the **transport menu** and click on save

Step 9 – VOIP trunk has been created successfully

Step 10 – Now Go to **Extensions** and Select Extension **Type** as SIP Extension

Step 11 – Provide any 4 digit numbers for instance 1012 which does not exist in the previously created extension and select internal in **Permission**

Step 12 – Copy the SIP/IAX Password to clipboard and click on Save

Step 13 – Open the new tab in your browser

Step 14– Now enter the IP Address of the phone 1 (192.168.101.53) in your browser

Step 15 – Enter the credentials admin as **Username** and ip160 as **password**

Step 16 – Navigate to **Phone** menu

Step 17 – Select SIP/UDP in the **Enable Protocol**

Step 18 – Enter the **User ID** 1012 and enter the IP address of **Proxy** 192.168.101.1

Step 19 – Paste the copied SIP/IAX Password in the **Authorization** menu and Click OK

Step 20 - Check the status of the created extensions page

Step 21 - If the status is updated to Idle state then the SIP extension creation is successful

Step 22 – Check whether the created user ID 1012 popped up on the Phone's display

Step 23 – Similarly repeat the steps from 1 to 22 to configure another phone with different User ID as 1013

Step 24 – Now try to call from any of the Phone with the created user ID