

ELEC2134 Lecture Notes

Oskar Meszaros (z5636164)

September 2026

Contents

I	Transform Methods	3
1	Topic 1: Periodic Signals and Fourier Series	3
1.1	Waveforms and Periodic Functions	3
1.1.1	Waveform Fundamentals	3
1.1.2	Sinusoid waveforms	3
1.1.3	Other Types of Waveforms	4
1.1.4	Harmonic Components	4
1.2	Fourier Series	4
1.2.1	Frequency Domain Representation	4
1.2.2	Fourier Series	4
1.2.3	Reconstructing a Waveform	5
1.3	Alternative Trigonometric Form	5
1.4	Complex Form of the Fourier Series	6
1.5	Effect of Shifting	6
1.6	Half-Wave Symmetry	6
1.6.1	Odd Half-Wave Symmetry	6
1.6.2	Even Half-Wave Symmetry	7
1.7	Examples	7
1.7.1	Waveforms	7
2	Topic 2: Aperiodic Signals and Fourier Transforms	7
2.1	Periodic and Aperiodic Signals	7
2.1.1	Fourier Series to Fourier Transform	8
2.2	Fourier Transform Properties	8
2.2.1	Basic Properties	8
2.2.2	Differentiation	9
2.2.3	Convolution	9
2.2.4	Modulation	9
3	Topic 3: Laplace Transforms of Signals and Circuits	9
3.1	Introduction to Laplace Transform	9
3.2	Laplace Transform Properties	10
3.2.1	Basic Properties	10
3.2.2	Initial and Final Value Theorem	11
3.3	Inverse Laplace Transform	11
3.3.1	Partial Fraction Decomposition	11
3.4	Laplace-Domain Circuit Models	12
3.4.1	Resistor	12
3.4.2	Inductors	12

3.4.3	Capacitors	12
3.4.4	Initial Conditions	13
3.5	Transfer Functions	13
3.5.1	Unit Impulse Response	13
3.6	Examples	13
II	Appendix	16
A	Filters	16
A.1	Types of Filters	16
B	Useful Integrals	16
B.1	Integrals	16
B.2	Integration by Parts	17
B.2.1	Key Formula	17
B.2.2	Cosine	17
B.2.3	Sine	17
B.2.4	Definite Integration by Parts	17
B.3	Definite Integrals	17
C	Trigonometric Identities	18
D	Common Fourier Transform Pairs and Properties	19
E	Common Laplace Transform Pairs and Properties	20

Part I

Transform Methods

1 Topic 1: Periodic Signals and Fourier Series

1.1 Waveforms and Periodic Functions

1.1.1 Waveform Fundamentals

Definition 1.1.

- A waveform describes the shape of a signal as a function of time.
- A signal is a function that varies with time.
- A unit step signal stays at 0 until a certain time, then instantly becomes 1.
- A ramp signal increases linearly with time, starting from 0.

The period (T) is the time taken for a waveform to complete one full cycle and start repeating

$$\text{frequency } f = \frac{1}{T} \text{Hertz (Hz)}.$$

Hertz is cycles per second. The units of period is time.

Example 1.2. Some common frequencies.

Frequency (f)	Period ($f = \frac{1}{T}$)
1 kHz	$1 \times 10^{-3} s = 1ms$
1 MHz	$1 \times 10^{-6} s = 1\mu s$
1 GHz	$1 \times 10^{-9} s = 1ns$
1 THz	$1 \times 10^{-12} s = 1ps$

The peak amplitude of a wave is the distance between the x axis and the highest point of the wave. The peak-to-peak amplitude is two times this amplitude.

Periodic Waveforms (or Functions) 1.3.

A periodic waveform or function is any waveform or function that satisfies

$$x(t) = x(t + T),$$

where t is the time variable, and T is the period. In general,

$$x(t) = x(t + nT), \forall n \in \mathbb{Z}.$$

1.1.2 Sinusoid waveforms

A sinusoidal waveform is a type of period waveform, and can be described using the following equation

$$x(t) = A \sin(2\pi ft),$$

where $x(t)$ is the instantaneous amplitude, A is the peak amplitude, and f is the frequency in Hz. It can also be described in terms of period with

$$x(t) = A \sin\left(\frac{2\pi}{T}t\right),$$

where T is the period. This can be simplified in terms of angular frequency $\omega = 2\pi f = \frac{2\pi}{T}$ radians/sec as

$$x(t) = A \sin(\omega t).$$

1.1.3 Other Types of Waveforms

Square Waveform

A square waveform is used mostly in digital electronic circuits for clock and timing control signals. It has very steep vertical transitions and flat top and bottoms.

It has pulse width $\tau = \frac{T}{2}$ and frequency $f = \frac{1}{T}$.

Rectangular Waveform

A rectangular waveform is similar to a square wave, however the duration of the high level (pulse width) is shorter than half the period. This is described by the duty cycle, which is the amount of time a signal is ON compared to the total time of one cycle.

Triangular Waveform

A triangular waveform is a non-sinusoidal waveform that linearly oscillates between a positive and negative peak. They are usually comprised of many sine or cosine waves with different frequencies and amplitudes.

Sawtooth Waveform

A sawtooth waveform is a periodic waveform whose shape resembles the teeth of a sawblade. It is similar to a triangular waveform, however the decay is more similar to a square wave's.

1.1.4 Harmonic Components

A harmonic is a multiple of the fundamental angular frequency of a waveform. The fundamental frequency is the frequency as defined above, giving the harmonics to be

$$\omega_0 = 2\pi f_0 = \frac{2\pi}{T} \Rightarrow w_n = nw_0, f_n = nf_0,$$

where n is a positive integer.

The average value of a waveform is the mean level of the signal over one complete cycle. This is the overall DC component of the waveform. For a periodic waveform $x(t)$ with period T , this is

$$V_{avg} = \frac{1}{T} \int_0^T x(t) dt.$$

1.2 Fourier Series

1.2.1 Frequency Domain Representation

The frequency domain representation of a waveform shows how a time-domain (i.e. amplitude as a function of time) signal is distributed across different frequencies, effectively decomposing a signal into its component frequencies.

Example 1.1. What does the phase-domain of the sinusoid $v(t)$ below look like?

$$v(t) = \frac{4}{\pi} \sin(\omega_0 t) + \frac{4}{3\pi} \sin(3\omega_0 t) + \frac{4}{5\pi} \sin(5\omega_0 t).$$

Answer: This would be a plot with three peaks; one at ω_0 , one at $3\omega_0$, and one at $5\omega_0$. The first one has a height of $4/\pi$, the second $4/3\pi$, and the last $4/5\pi$.

1.2.2 Fourier Series

This process of breaking down a signal is called Fourier decomposition, resulting in a Fourier series. This is a sum of sinusoidal components with different frequencies and amplitudes. The main application of a Fourier series is to determine the harmonic components that are present in a complex periodic waveform.

Any periodic waveform with a period of T seconds can be represented by an infinite series of harmonically related sinusoids. The representation is known as the trigonometric Fourier series.

$$x(t) = A_0 + \sum_{n=1}^{\infty} A_n \cos(n\omega_0 t) + B_n \sin(n\omega_0 t).$$

The fundamental frequency of $x(t)$ is $\omega_0 = 2\pi f_0 = \frac{2\pi}{T}$ radians/sec. The integer multiples of ω_0 are known as harmonic frequencies of $x(t)$. The Fourier coefficients A_0 , A_n and B_n are calculated directly from the signal $x(t)$ using the following equations

$$\begin{aligned} A_0 &= \frac{1}{T} \int_{-T/2}^{T/2} x(t) dt \\ \omega_0 &= 2\pi f_0 = \frac{2\pi}{T} \text{ radians/sec} \\ A_n &= \frac{2}{T} \int_{-T/2}^{T/2} x(t) \cos(n\omega_0 t) dt \\ B_n &= \frac{2}{T} \int_{-T/2}^{T/2} x(t) \sin(n\omega_0 t) dt. \end{aligned}$$

Fourier Series of an Even Periodic Function

A function is defined as even if $x(t) = x(-t)$. For these functions/waveforms, the expressions for the Fourier coefficients reduce to

$$A_0 = \frac{2}{T} \int_0^{T/2} x(t) dt, \quad A_n = \frac{4}{T} \int_0^{T/2} x(t) \cos(n\omega_0 t) dt, \quad B_n = 0.$$

The reason that the B coefficients disappear is because the periodic waveform is even, so there are no terms from the odd sine function.

Fourier Series of an Odd Periodic Function

A function is defined as odd if $x(t) = -x(-t)$. For these function/waveforms, the expressions reduce to

$$A_0 = A_n = 0 \text{ for } n > 0, \quad B_n = \frac{4}{T} \int_0^{T/2} x(t) \sin(n\omega_0 t) dt$$

1.2.3 Reconstructing a Waveform

To reconstruct (or synthesise) a waveform/function from a set of Fourier coefficients, simply plug them back into the above expression for Fourier series along with their index.

1.3 Alternative Trigonometric Form

In the frequency domain, the amplitude of each frequency component is determined by A_n and B_n , with contributions from both the sine and cosine terms. We would now like to express the signal in an alternative form in which the amplitude of each frequency components is obtained using a single cosine function with a phase angle

$$x(t) = K_0 + \sum_{n=1}^{\infty} K_n \cos(n\omega_0 t + \phi_n).$$

This is the amplitude-phase representation. We are able to find the phase angle ϕ_n with

$$\phi_n = \tan^{-1} \left(-\frac{B_n}{A_n} \right) = -\tan^{-1} \left(\frac{B_n}{A_n} \right).$$

With this phase angle, we are also able to express the Fourier series using a complex number with $K_n \angle \phi_n = A_n - jB_n$.

1.4 Complex Form of the Fourier Series

The cosine-sine and amplitude-phase Fourier series from above are all trigonometric Fourier series. Another alternative Fourier series representations uses exponential functions instead of trigonometric functions. This form is therefore called the complex form of the (or exponential) Fourier series, and is given by

$$x(t) = \sum_{n=-\infty}^{\infty} C_n e^{jn\omega_0 t}, \quad C_n = \frac{1}{T} \int_0^T x(t) e^{-jn\omega_0 t} dt,$$

where $\omega_0 = \frac{2\pi}{T}$. The DC component is then given by C_0 , and C_n can be found with

$$C_n = \frac{1}{2}(A_n - jB_n), \quad |C_{-n}| = |C_n| = \frac{1}{2}\sqrt{A_n^2 + B_n^2}.$$

- For even symmetry: $C_n = \frac{2}{T} \int_0^{T/2} x(t) \cos(n\omega_0 t) dt$
- For odd symmetry: $C_n = -\frac{2j}{T} \int_0^{T/2} x(t) \sin(n\omega_0 t) dt$

1.5 Effect of Shifting

Shifting a periodic function along either the vertical or the horizontal axis will generally affect its Fourier coefficients. These are also affected by the presence of certain types of functional symmetries in $f(t)$, particularly even-, odd-, and half-wave symmetry because some coefficient sets vanish altogether.

Shifting a periodic function $f(t)$ along either the vertical or the horizontal axis affects its amplitude-phase Fourier series. It is apparent that shifting $f(t)$ up or down the vertical axis changes only the average value K_0 , leaving the amplitude K_n and phase angle ϕ_n of each harmonics component unaffected.

1.6 Half-Wave Symmetry

An important type of symmetry is the half-wave symmetry. A periodic function is half-wave symmetric if

$$x(t) = -x\left(t - \frac{T}{2}\right).$$

Shifting a half-wave symmetric wave or function by half a period then inverting it yields the original function. If a function has half-wave symmetric, then both A_n and B_n are 0 for even values of n .

1.6.1 Odd Half-Wave Symmetry

A periodic signal has odd half-wave symmetry if both of the following are true:

$$x(t) = -x\left(t - \frac{T}{2}\right), \quad \text{and} \quad x(t) = -x(-t).$$

For a function with odd half-wave symmetry, the coefficients are given by

$$A_n = \begin{cases} \frac{4}{T} \int_0^{T/2} x(t) \cos(n\omega_0 t) dt & \text{for } n \text{ odd} \\ 0 & \text{for } n \text{ even} \end{cases}$$

$$B_n = \begin{cases} \frac{4}{T} \int_0^{T/2} x(t) \sin(n\omega_0 t) dt & \text{for } n \text{ odd} \\ 0 & \text{for } n \text{ even} \end{cases}$$

For odd half-wave symmetry

- All cosine terms are 0 $A_n = 0$.
- All even harmonics are 0.
- Only odd sine harmonics appear in the Fourier series.

1.6.2 Even Half-Wave Symmetry

A periodic signal has even half-wave symmetry if both of the following are true:

$$x(t) = -x\left(t - \frac{T}{2}\right), \quad \text{and} \quad x(t) = x(-t).$$

For a function with even half-wave symmetry, the coefficients are given by

$$A_n = \begin{cases} \frac{4}{T} \int_0^{T/2} x(t) \cos(n\omega_0 t) dt & \text{for } n \text{ odd} \\ 0 & \text{for } n \text{ even} \end{cases}$$
$$B_n = \begin{cases} \frac{4}{T} \int_0^{T/2} x(t) \sin(n\omega_0 t) dt & \text{for } n \text{ odd} \\ 0 & \text{for } n \text{ even} \end{cases}$$

For even half-wave symmetry

- All sine terms are 0 $B_n = 0$.
- All sine harmonics are 0.
- Only odd cosine harmonics appear in the Fourier series.

1.7 Examples

1.7.1 Waveforms

Example 1.1. Sum these two sine waves

$$f(t) = 10 \sin(200t)$$
$$g(t) = 8 \sin(200t)$$

Answer: These sine waves have the same period $2\pi f = 200$, $f = \frac{200}{2\pi} \text{ Hz} = 31.83 \text{ Hz}$.

2 Topic 2: Aperiodic Signals and Fourier Transforms

2.1 Periodic and Aperiodic Signals

A periodic signal repeats itself after some period T , and can be represented by

$$x(t) = x(t + nT), \quad \forall n \in \mathbb{Z}.$$

The frequency components of a periodic signal are analysed using a Fourier series. An aperiodic signal has no repeating pattern, and we assume its period is infinite. Most practical signals are aperiodic. Since the fundamental frequency is inversely proportionate to the period, so as the period increases indefinitely the individual spectral components merge into a continuous spectrum and the fundamental frequency becomes vanishingly small.

As a consequence, the frequency $n\omega_0$ of each harmonic component becomes the continuous frequency variable ω , the line spacing ω_0 becomes the infinitesimal $d\omega$, and the operation of summation becomes the operation of integration.

Consider the exponential Fourier series. We have

$$x(t) = \sum_{n=-\infty}^{\infty} C_n e^{jn\omega_0 t}, \quad C_n = \frac{1}{T} \int_{-T/2}^{T/2} x(t) e^{-jn\omega_0 t} dt.$$

This then gives the full expression for $x(t)$ to be

$$x(t) = \sum_{n=-\infty}^{\infty} \left\{ \frac{1}{T} \int_{-T/2}^{T/2} x(t) e^{-jn\omega_0 t} dt \right\} e^{jn\omega_0 t},$$

and the inverse to be

$$f(t) = \sum_{n=-\infty}^{\infty} \left\{ \frac{1}{2\pi} \int_{-T/2}^{T/2} x(t) e^{-jn\omega_0 t} dt \right\} e^{jn\omega_0 t} \omega_0.$$

We can turn this Fourier series into a Fourier transform by taking the limit of $T \rightarrow \infty$, replacing the frequency with the continuous frequency, the line spacing with $d\omega$, and integrating instead of summing. This gives the Fourier transform (FT) of $x(t)$ (denote $X(\omega)$ or $X(j\omega)$) to be

$$X(\omega) = \int_{-\infty}^{\infty} x(t) e^{-j\omega t} dt,$$

and the inverse Fourier transform (IFT) to be

$$x(t) = \frac{1}{2\pi} \int_{-\infty}^{\infty} X(\omega) e^{j\omega t} d\omega.$$

Note that $X(\omega)$ is a complex-valued function, and $x(t)$ is normally a real valued signal.

2.1.1 Fourier Series to Fourier Transform

- For small T , the signal repeats frequently in time and its frequency spectrum consists of discrete spectral lines that are widely spread. As T increases and approaches ∞ , the pulses move further apart in time, the fundamental frequency decreases, and the spacing between spectral lines becomes smaller
- As a consequence, more frequency components appear within a given frequency range, and the discrete spectrum begins to resemble a continuous one
- In the limit, the periodic signal becomes an aperiodic single pulse, the spectral lines merge into a continuous spectrum, and the Fourier series representation naturally transitions to the Fourier transform.

2.2 Fourier Transform Properties

Let $f(x)$ and $h(x)$ represent integrable functions satisfying

$$\int_{-\infty}^{\infty} |f(x)| dx < \infty.$$

We denote the Fourier transforms of these functions as $F(\xi)$ and $H(\xi)$, respectively.

2.2.1 Basic Properties

The Fourier transform has the following basic properties

- **Linearity:** $af(x) + bh(x) \xLeftrightarrow{\mathcal{F}} aF(\xi) + bH(\xi), \quad a, b \in \mathbb{C}$
- **Time shifting:** $f(x - x_0) \xLeftrightarrow{\mathcal{F}} e^{-i2\pi x_0 \xi} F(\xi), \quad x_0 \in \mathbb{R}.$
- **Frequency shifting:** $e^{i2\pi \xi_0 x} f(x) \xLeftrightarrow{\mathcal{F}} F(\xi - \xi_0), \quad \xi_0 \in \mathbb{R}$
- **Time scaling:** $f(ax) \xLeftrightarrow{\mathcal{F}} \frac{1}{|a|} F\left(\frac{\xi}{a}\right), \quad a \neq 0.$ Note: the case $a = -1$ leads to the time-reversal property: $f(-x) \xLeftrightarrow{\mathcal{F}} F(-\xi)$

2.2.2 Differentiation

Suppose $f(x)$ is differentiable almost everywhere, and both f and its derivative f' are integrable. The Fourier transform is then given by

$$F'(\xi) = \mathcal{F} \left\{ \frac{d}{dx} f(x) \right\} = i2\pi\xi F(\xi).$$

We also have differentiation in time to be

$$\frac{d}{dt} f(x) \xleftrightarrow{\mathcal{F}} j\xi F(\xi),$$

which is multiplying the frequency by $j\xi$. Similarly, taking the integrate w.r.t time gives

$$\int_{-\infty}^t f(x) dx \xleftrightarrow{\mathcal{F}} \frac{F(\xi)}{j\xi}.$$

And for frequency we have

$$-jtf(x) \xleftrightarrow{\mathcal{F}} \frac{d}{d\xi} F(\xi),$$

which is effectively multiplication in time by jt .

2.2.3 Convolution

Convolution describes how the output of a system depends on the input signal and the system's impulse response. Taking the same functions $f(x)$, $g(x)$ from before (along with their transforms), we get an output signal $y(x)$ given by

$$y(x) = f(x) * g(x) = \int_{-\infty}^{\infty} f(\tau)g(x - \tau)d\tau,$$

where $*$ denotes the convolution operation, then

$$Y(\xi) = F(\xi)G(\xi).$$

Convolution in the time domain corresponds to multiplication in the frequency domain. Note that when the input is an impulse $f(x) = \delta(x)$, then

$$Y(\xi) = G(\xi),$$

since $X(\xi) = 1$.

2.2.4 Modulation

Amplitude modulation is the process of varying the amplitude of a sinusoidal carrier. If the modulating signal is denoted $x(t)$, the modulated carrier becomes

$$y(t) = x(t) \cos(\omega_0 t).$$

The amplitude spectrum of this carrier is one-half the amplitude spectrum of $x(t)$ shifted to be centred at $\pm\omega_0$

$$\mathcal{F} \{x(t) \cos(\omega_0 t)\} = \frac{1}{2}X(\omega - \omega_0) + \frac{1}{2}X(\omega + \omega_0).$$

3 Topic 3: Laplace Transforms of Signals and Circuits

3.1 Introduction to Laplace Transform

A Laplace transform can be thought of as a generalisation of Fourier transforms that transforms differential equations into algebraic equations. It is also able to handle initial conditions, transients, and steady-states responses.

It is an integral transformation that maps a function $f(t)$ from the time domain to the s -domain. It is defined as

$$\mathcal{L}\{f(t)\} = F(s) = \int_0^{\infty} f(t)e^{-st}dt,$$

where s is a complex variable and is given by $s = \sigma + j\omega$, σ is the exponential damping factor, and ω is the frequency. Note that the Fourier transform is a special case when $\sigma = 0$,

- $s = j\omega$ - sinusoidal AC signals (Fourier/frequency axis)
- $s = \sigma$ - for exponential signals
- $s = \sigma + j\omega$ - for exponential sinusoidal signals.

3.2 Laplace Transform Properties

Let $f(t)$ and $g(t)$ be two functions with respective Laplace transforms $F(s)$ and $G(s)$

$$f(t) = \mathcal{L}^{-1}\{F(s)\}, \quad g(t) = \mathcal{L}^{-1}\{G(s)\}.$$

3.2.1 Basic Properties

The Laplace transform has the following basic properties (note: the $u(t-a)$ function is present to ensure the function doesn't include negative time):

- **Linearity:** $af(t) + bg(t) \xLeftrightarrow{\mathcal{L}} aF(s) + bG(s)$
- **Time scaling:** $f(at) \xLeftrightarrow{\mathcal{L}} \frac{1}{a}F\left(\frac{s}{a}\right)$
- **Time shifting:** $f(t-a)u(t-a) \xLeftrightarrow{\mathcal{L}} e^{-as}F(s)$
- **Frequency shifting:** $e^{-as}f(t)u(t) \xLeftrightarrow{\mathcal{L}} F(s+a)$
- **First time derivative:** $\frac{df(t)}{dt} \xLeftrightarrow{\mathcal{L}} sF(s) - f(0^-)$
- **Second time derivative:** $\frac{d^2f(t)}{dt^2} \xLeftrightarrow{\mathcal{L}} s^2F(s) - sf(0^-) - f'(0^-)$
- **General time derivative:** $\frac{d^n f(t)}{dt^n} \xLeftrightarrow{\mathcal{L}} s^n F(s) + \sum_{i=1}^n [-s^{n-i} f^{(i)}(0^-)]$
- **Time integration:** $\int_0^t f(\tau)d\tau \xLeftrightarrow{\mathcal{L}} \frac{1}{s}F(s)$
- **Differentiation in s-domain:** $tf(t) \xLeftrightarrow{\mathcal{L}} -\frac{dF(s)}{ds}$
- **Differentiation in s-domain (general):** $t^n f(t) \xLeftrightarrow{\mathcal{L}} (-1)^n F^{(n)}(s)$
- **Frequency Integration:** $\frac{f(t)}{t} \xLeftrightarrow{\mathcal{L}} \int_s^{\infty} F(s)ds$

3.2.2 Initial and Final Value Theorem

The initial and final values of a function can be directly found from its Laplace transform. We have the initial value to be

$$f(0) = \lim_{s \rightarrow \infty} sF(s),$$

and final value as

$$f(\infty) = \lim_{s \rightarrow 0} sF(s).$$

Note that the final value theorem is only applicable when the system has a definite final value. For rational $F(s)$, the poles of $sF(s)$ must lie in the open left-half place (aside from the simple origin case).

Example 3.1. Find the final value of the function

$$f(t) = e^{-2t} \sin(5t)u(t).$$

Answer: First, we find the Laplace transform of this function to be

$$F(s) = \mathcal{L}\{f(t)\} = \frac{5}{(s+2)^2 + 4s^2 9}.$$

Taking the limit gives

$$\begin{aligned} f(\infty) &= \lim_{s \rightarrow 0} sF(s) \\ &= \lim_{s \rightarrow 0} \frac{5s}{s^2 + 4s + 29} \\ &= 0. \end{aligned}$$

3.3 Inverse Laplace Transform

The inverse Laplace transform is very similar to the formula for the inverse Fourier transform. We have

$$f(t) = \mathcal{L}^{-1}\{F(s)\}(t) = \frac{1}{2\pi i} \lim_{T \rightarrow \infty} \int_{\gamma-iT}^{\gamma+iT} e^{st} F(s) ds,$$

where $\gamma = \Re(s)$, such that γ is greater than the real part of all singularities (discontinuities) of F and F is bounded on the line. In the special case where all singularities lie in the open left half-place, or F is an entire function (such as a polynomial, exponential, finite sum, etc), then γ can be set to 0 and the above integral is identical to the inverse Fourier transform.

The typical way to find the inverse Laplace transform is to simply using the properties from above, along with a table of basic/common Laplace transform pairs, to find the inverse. This usually also requires decomposing $F(s)$ into partial fractions

3.3.1 Partial Fraction Decomposition

The partial fraction decomposition of a rational fraction of the form

$$\frac{f(x)}{g(x)},$$

where $f(x)$, $g(x)$ are polynomials and $g(x) \neq 0$, is the expression of the rational fractions as

$$\frac{f(x)}{g(x)} = p(x) + \sum_k \frac{f_j(x)}{g_j(x)},$$

where $p(x)$ is a polynomial, and for each j , the denominator $g_j(x)$ is a power of an irreducible polynomial (i.e. not factorisable into polynomials of positive degrees), and the numerator $f_j(x)$ is a polynomial of a

smaller degree than the degree of the irreducible polynomial. Note that when doing this by hand, we just consider "square-free" polynomials rather than irreducible polynomials.

There are two methods for finding partial fractions:

- **Residue Method:** "Cover" the factor $(x - p)$, then evaluate the rest at $x = p$. See Example 3.6 for an example of this.
- **Algebraic Method:** Equate $f(x)$ to a coefficient corresponding to one of the factors multiplied by the rest of $g(x)$. Then, the coefficients can be found by solving for each of them. See Example 3.6 for an example of this.

3.4 Laplace-Domain Circuit Models

Laplace transform is particularly useful for circuit analysis by converting to the s -domain of circuit elements. Circuit elements can be transformed into impedances, which is similar to phasor impedances from ELEC1111.

3.4.1 Resistor

For resistors, all values remain the same in both the time domain and the s -domain.

$$v(t) = Ri(t) \xLeftrightarrow{\mathcal{L}} V(s) = RI(s).$$

3.4.2 Inductors

In the time-domain, we have voltage to be inductances multiplied by the change in current, and the current to be the total change in voltage divided by the inductance,

$$v(t) = L \frac{di(t)}{dt}, \quad i(t) = \frac{1}{L} \int_0^t v(\tau) d\tau + i(0),$$

where $i(0)$ is the current at $t = 0$. Taking the Laplace transform of this, we get

$$\begin{aligned} v(t) &= L \frac{di(t)}{dt} \xLeftrightarrow{\mathcal{L}} V(s) = sLI(s) - Li(0) \\ i(t) &= \frac{1}{L} \int_0^t v(\tau) d\tau + i(0) \xLeftrightarrow{\mathcal{L}} I(s) = \frac{V(s)}{sL} + \frac{i(0)}{s}. \end{aligned}$$

3.4.3 Capacitors

In the time-domain, the voltage is given by the total change in current divided by the capacitance, and the current to be the capacitance multiplied by the change in voltage.

$$v(t) = \frac{1}{C} \int_0^t i(\tau) d\tau + v(0), \quad i(t) = C \frac{dv(t)}{dt}.$$

Taking the Laplace transform of this, we get

$$\begin{aligned} v(t) &= \frac{1}{C} \int_0^t i(\tau) d\tau + v(0) \xLeftrightarrow{\mathcal{L}} V(s) = \frac{I(s)}{sC} + \frac{v(0)}{s} \\ i(t) &= C \frac{dv(t)}{dt} \xLeftrightarrow{\mathcal{L}} I(s) = sCV(s) - Cv(0). \end{aligned}$$

3.4.4 Initial Conditions

In the above equations, the initial conditions represented a voltage or current source on the circuit, indicating the circuit started with a certain current/voltage. If we assume no initial conditions, we get

Table 1: Zero initial conditions in Laplace-domain circuit models		
Voltage/Current Relation	Impedance	Admittance
$V(s) = RI(s)$	$Z(s) = \frac{V(s)}{I(s)} = R$	$Y(s) = \frac{I(s)}{V(s)} = \frac{1}{R}$
$V(s) = sLI(s)$	$Z(s) = \frac{V(s)}{I(s)} = sL$	$Y(s) = \frac{I(s)}{V(s)} = \frac{1}{sL}$
$V(s) = \frac{I(s)}{sC}$	$Z(s) = \frac{V(s)}{I(s)} = \frac{1}{sC}$	$Y(s) = \frac{I(s)}{V(s)} = sC$

3.5 Transfer Functions

A transfer function describes how a signal is changed whilst passing through a system. The transfer function $H(s)$ is defined as the ratio of the output response $Y(s)$ to input excitation $X(s)$, assuming all initial conditions are zero

$$H(s) = \frac{Y(s)}{X(s)}, \quad Y(s) = H(s) \cdot X(s),$$

where $H(s)$ is the transfer function, and $X(s)$ and $Y(s)$ are the input and output, respectively. If both $X(s)$ and $Y(s)$ are voltages, then it represents a voltage gain. If both variables are currents, it represents a current gain. This gives four common types of transfer function

- **Voltage Gain:** $H(s) = \frac{V_o(s)}{V_i(s)}$
- **Current Gain:** $H(s) = \frac{I_o(s)}{I_i(s)}$
- **Impedance:** $H(s) = \frac{V(s)}{I(s)}$
- **Admittance:** $H(s) = \frac{I(s)}{V(s)}$

A single circuit may have several possible transfer function, depending on the chosen input and output variables. Note that gain is dimensionless, whereas impedance and admittance have units.

3.5.1 Unit Impulse Response

To determine the transfer function $H(s)$ of a system, both in the input and output functions must be known. If the input $X(s)$ and the transfer function are known, the output is obtained as

$$Y(s) = H(s) \cdot X(s).$$

Taking the inverse Laplace transform,

$$y(t) = \mathcal{L}^{-1} \{Y(s)\}.$$

If the input is a unit response, $x(t) = \delta(t)$, then

$$X(s) = 1,$$

and therefore $Y(s) = H(s)$, which also means

$$y(t) = h(t),$$

where

$$h(t) = \mathcal{L}^{-1} \{H(s)\}.$$

The function $h(t)$ is called the unit impulse response. It represents the time-domain response of the system to a unit impulse input. Therefore, the transfer function $H(s)$ is the Laplace transform of the unit impulse response of the system.

3.6 Examples

Example 3.1. Find the inverse Laplace transform of

$$F(s) = \frac{s^2 + 12}{s(s+2)(s+3)}$$

using both the Residue method and the algebraic method for partial fraction decomposition.

Answer: First, we need to find the partial fractions

$$\frac{s^2 + 12}{s(s+2)(s+3)} = \frac{A}{s} + \frac{B}{s+2} + \frac{C}{s+3}.$$

Algebraic Method: Multiplying both sides by the denominator, we get

$$s^2 + 12 = A(s^2 + 5s + 6) + B(s^2 + 3s) + C(s^2 + 2s).$$

Equating the coefficients of like powers, we get

$$\begin{array}{lll} \text{Constant :} & 12 = 6A & \Rightarrow A = 2 \\ s : & 0 = 5A + 3B + 2C & \Rightarrow 3B + 2C = -10 \\ s^2 : & 1 = A + B + C & \Rightarrow B + C = -1 \\ & \therefore A = 2, B = -8, C = 7. \end{array}$$

Residual Method: To find each coefficient, we just multiply the denominator of the respective fraction by $F(s)$. This gives the following set of equations

$$A = sF(s) \Big|_{s=0} \tag{1}$$

$$B = (s+2)F(s) \Big|_{s=-2} \tag{2}$$

$$C = (s+3)F(s) \Big|_{s=-3}. \tag{3}$$

Evaluating these gives

$$\begin{aligned} (1) \quad A &= \frac{s^2 + 12}{(s+2)(s+3)} \Big|_{s=0} \\ &= \frac{12}{2 \times 3} = 2 \end{aligned}$$

$$\begin{aligned} (2) \quad B &= \frac{s^2 + 12}{s(s+3)} \Big|_{s=-2} \\ &= \frac{12}{-2 \times 1} = -8 \end{aligned}$$

$$\begin{aligned} (3) \quad C &= \frac{s^2 + 12}{s(s+2)} \\ &= \frac{12}{-3 \times -1} = 7. \end{aligned}$$

We can see that these give the same result, however the second method was easier. We now have our function to be in the form

$$F(s) = \frac{2}{s} - \frac{8}{s+2} + \frac{7}{s+3},$$

which we can find the inverse of using linearity and a table of common pairs to get

$$\begin{aligned} f(t) &= \mathcal{L}^{-1} \left(\frac{2}{s} \right) - \mathcal{L}^{-1} \left(\frac{8}{s+2} \right) + \mathcal{L}^{-1} \left(\frac{7}{s+3} \right) \\ &= 2u(t) - 8e^{-2t} + 7e^{-3t}, \quad t \geq 0 \end{aligned}$$

Example 3.2. Use the Laplace transform to solve the following differential equation

$$\frac{d^2v(t)}{dt^2} + 6\frac{dv(t)}{dt} + 8v(t) = 2u(t),$$

given $v(0) = 1$, $v'(0) = -2$.

Answer:

Taking the Laplace transform of each term gives

$$[s^2V(s) - sv(0) - v'(0)] + 6[sV(s) - v(0)] + 8V(s) = \frac{2}{s}.$$

Substituting $v(0) = 1$ and $v'(0) = -2$, we obtain

$$\begin{aligned}(s^2 + 6s + 8)V(s) &= s + 4 + \frac{2}{s} \\ &= \frac{s^2 + 4s + 2}{s} \Rightarrow V(s) = \frac{1/4}{s} + \frac{1/2}{s+2} + \frac{1/4}{s+4}.\end{aligned}$$

Taking the inverse Laplace transform, we obtain

$$v(t) = \frac{1}{4}(1 + 2e^{-2t} + e^{-4t})u(t).$$

Example 3.3. Use the Laplace transform to solve the following differential equation

$$\frac{dy}{dt} + 5y(t) + 6 \int_0^t y(\tau) d\tau = u(t),$$

given $y(0) = 2$.

Answer:

Taking the Laplace transform of each term in the given differential equation yields

$$[sY(s) - y(0)] + 5Y(s) + \frac{6}{s}Y(s) = \frac{1}{s}.$$

Substituting $y(0) = 2$, we obtain

$$\begin{aligned}Y(s)(s^2 + 5s + 6) &= 1 + 2s \\ Y(s) &= \frac{2s + 1}{(s+2)(s+3)} \\ &= -\frac{3}{s+2} + \frac{5}{s+3}.\end{aligned}$$

Taking the inverse Laplace transform, we get

$$y(t) = (-3e^{-2t} + 5e^{-3t})u(t).$$

Part II

Appendix

A Filters

A.1 Types of Filters

The following are idealised specifications for the most common filter functions

Ideal Low-Pass Filter

Passes low frequencies, blocks high frequencies.

$$|H(j\omega)| = \begin{cases} 1, & 0 \leq \omega \leq \omega_c \\ 0, & \omega > \omega_c \end{cases}$$

Passband: $0 \leq \omega < \omega_c$, stopband: $\omega_c < \omega \leq \infty$.

Ideal High-Pass Filter

Passes high frequencies, blocks low frequencies.

$$|H(j\omega)| = \begin{cases} 0, & 0 \leq \omega < \omega_c \\ 1, & \omega > \omega_c \end{cases}$$

Passband: $\omega_c < \omega \leq \infty$, stopband: $0 \leq \omega < \omega_c$.

Ideal Band-Pass Filter

Passes only frequencies between ω_L and ω_H .

$$|H(j\omega)| = \begin{cases} 1, & \omega_L \leq \omega \leq \omega_H \\ 0, & \text{otherwise} \end{cases}$$

Passband: $\omega_L \leq \omega \leq \omega_H$, stopbands: $\omega < \omega_L$ and $\omega > \omega_H$.

Ideal Band-Stop (Band-Reject) Filter

Rejects frequencies between ω_L and ω_H .

$$|H(j\omega)| = \begin{cases} 0, & \omega_L \leq \omega_H \\ 1, & \text{otherwise} \end{cases}$$

Passbands: $\omega < \omega_L$ and $\omega > \omega_H$, stopband: $\omega_L < \omega < \omega_H$.

B Useful Integrals

B.1 Integrals

For integer $n \neq 0$

$$\begin{aligned} \int \sin(ax) dx &= -\frac{1}{a} \cos(ax) \\ \int \cos(ax) dx &= \frac{1}{a} \sin(ax) \\ \int_0^T \sin(n\omega_0 t) dt &= 0 \\ \int_0^T \cos(n\omega_0 t) dt &= 0 \end{aligned}$$

B.2 Integration by Parts

B.2.1 Key Formula

Key formula:

$$\int u dv = uv - \int v du.$$

$$\begin{aligned}\int x e^{ax} dx &= \frac{e^{ax}}{a^2} (ax - 1) \\ \int x^2 e^{ax} dx &= \frac{e^{ax}}{a^3} (a^2 x^2 - 2ax + 2)\end{aligned}$$

B.2.2 Cosine

Key formula:

$$\int t \cos(n\omega_0 t) dt.$$

Let $u = t \Rightarrow dt, dv = \cos(n\omega_0 t) dt \Rightarrow v = \frac{1}{n\omega_0} \sin(n\omega_0 t)$

$$\int t \cos(n\omega_0 t) dt = \frac{1}{n\omega_0} \sin(n\omega_0 t) - \frac{1}{(n\omega_0)^2} \cos(n\omega_0 t) + G$$

B.2.3 Sine

Key formula:

$$\int t \sin(n\omega_0 t) dt.$$

Let $u = t \Rightarrow du = dt, dv = \sin(n\omega_0 t) dt \Rightarrow v = -\frac{1}{n\omega_0} \cos(n\omega_0 t)$

$$\int t \sin(n\omega_0 t) dt = -\frac{t}{n\omega_0} \cos(n\omega_0 t) + \frac{1}{(n\omega_0)^2} \sin(n\omega_0 t) + G$$

B.2.4 Definite Integration by Parts

For $0 \leq t \leq T$ and integer n

$$\int_0^T t \sin(n\omega_0 t) dt = \left[\frac{T}{n\omega_0} \right] \quad \text{and} \quad \int_0^T t \cos(n\omega_0 t) dt = \boxed{0}.$$

B.3 Definite Integrals

x^2 and trigonometric function:

$$\begin{aligned}\int_0^T x^2 \cos(nx) dx &= \left[\frac{x^2}{n} \sin(nx) + \frac{2x}{n^2} \cos(nx) - \frac{2}{n^3} \sin(nx) \right]_0^T \\ \int_0^T x^2 \sin(nx) dx &= \left[-\frac{x^2}{n} \cos(nx) + \frac{2x}{n^2} \sin(nx) + \frac{2}{n^3} \cos(nx) \right]_0^T.\end{aligned}$$

x and trigonometric function:

$$\begin{aligned}\int_0^T x \cos(nx) dx &= \left[\frac{x}{n} \sin(nx) + \frac{1}{n^2} \cos(nx) \right]_0^T \\ \int_0^T x \sin(nx) dx &= \left[-\frac{x}{n} \cos(nx) + \frac{1}{n^2} \sin(nx) \right]_0^T.\end{aligned}$$

Miscellaneous:

$$\begin{aligned}\int_0^T \cos(m\omega_0 t) \sin(n\omega_0 t) dt &= 0 \quad \text{for all } m \text{ and } n \\ \int_0^T \sin(m\omega_0 t) \sin(n\omega_0 t) dt &= \begin{cases} 0 & \text{for all } m \neq n \\ \frac{T}{2} & \text{for } m = n \end{cases} \\ \int_0^T \cos(m\omega_0 t) \cos(n\omega_0 t) dt &= \begin{cases} 0 & \text{for all } m \neq n \\ \frac{T}{2} & \text{for } m = n \end{cases}.\end{aligned}$$

C Trigonometric Identities

$$\sin(\alpha \pm \beta) = \sin \alpha \cos \beta \pm \cos \alpha \sin \beta$$

$$\cos(\alpha \pm \beta) = \cos \alpha \cos \beta \mp \sin \alpha \sin \beta$$

$$\cos(\alpha \pm 90^\circ) = \mp \sin \alpha$$

$$\sin(\alpha \pm 90^\circ) = \pm \cos \alpha$$

$$\cos \alpha \cos \beta = \frac{1}{2} \cos(\alpha + \beta) + \frac{1}{2} \cos(\alpha - \beta)$$

$$\sin \alpha \sin \beta = \frac{1}{2} \cos(\alpha - \beta) - \frac{1}{2} \cos(\alpha + \beta)$$

$$\sin \alpha \cos \beta = \frac{1}{2} \sin(\alpha + \beta) + \frac{1}{2} \sin(\alpha - \beta)$$

$$\sin 2\alpha = 2 \sin \alpha \cos \alpha.$$

$$\cos 2\alpha = 2 \cos^2 \alpha - 1$$

$$= 1 - 2 \sin^2 \alpha$$

$$= \cos^2 \alpha - \sin^2 \alpha$$

$$\sin^2 \alpha = \frac{1}{2}(1 - \cos 2\alpha)$$

$$\cos^2 \alpha = \frac{1}{2}(1 + \cos 2\alpha)$$

$$\sin \alpha = \frac{e^{j\alpha} - e^{-j\alpha}}{2j}$$

$$\cos \alpha = \frac{e^{j\alpha} + e^{-j\alpha}}{2}$$

$$e^{\pm j\alpha} = \cos \alpha \pm j \sin \alpha$$

$$A \cos \alpha + B \sin \alpha = \sqrt{A^2 + B^2} \cos \left(\alpha + \tan^{-1} \left(\frac{B}{A} \right) \right).$$

D Common Fourier Transform Pairs and Properties

Table 2: Common Signals and Their Fourier Transforms

Type	$f(t)$	$F(\omega)$
Impulse	$\delta(t)$	1
Constant	A	$2\pi A\delta(\omega)$
Signum	$\text{sgn}(t)$	$\frac{2}{j\omega}$
Step (Heaviside)	$u(t)$	$\pi\delta(\omega) + \frac{1}{j\omega}$
Positive-time exponential	$e^{-at}u(t), a > 0$	$\frac{1}{a+j\omega}, a > 0$
Negative-time exponential	$e^{at}u(-t), a > 0$	$\frac{1}{a-j\omega}, a > 0$
Positive & negative exponential	$e^{-a t }$	$\frac{2a}{a^2 + \omega^2}$
Complex exponential	$e^{j\omega_0 t}$	$2\pi\delta(\omega - \omega_0)$
Cosine	$\cos \omega_0 t$	$\pi [\delta(\omega - \omega_0) + \delta(\omega + \omega_0)]$
Sine	$\sin \omega_0 t$	$j\pi [\delta(\omega + \omega_0) - \delta(\omega - \omega_0)]$

Table 3: Fourier Transform Properties

Name of Property	Function of Time	Fourier Transform
Definition	$f(t)$	$\mathcal{F}(\omega)$
Multiplication by constant	$Af(t)$	$A\mathcal{F}(\omega)$
Linearity	$af_1(t) + bf_2(t)$	$a\mathcal{F}_1(\omega) + b\mathcal{F}_2(\omega)$
Time shift	$f(t - t_0)$	$e^{-j\omega t_0}\mathcal{F}(\omega)$
Time scaling ($a > 0$)	$f(at)$	$\frac{1}{a}\mathcal{F}\left(\frac{\omega}{a}\right)$
Modulation (frequency shift)	$e^{j\omega_0 t}f(t)$	$\mathcal{F}(\omega - \omega_0)$
Differentiation (time)	$\frac{d^n f(t)}{dt^n}$	$(j\omega)^n \mathcal{F}(\omega)$
Convolution (time)	$\int_{-\infty}^{\infty} f_1(t)f_2(t-x)dx$	$\mathcal{F}_1(\omega)\mathcal{F}_2(\omega)$
Time multiplication	$t^n f(t)$	$(j)^n \frac{d^n \mathcal{F}(\omega)}{d\omega^n}$
Time reversal	$f(-t)$	$\mathcal{F}(-\omega)$
Integration	$\int_{-\infty}^t f(\tau)d\tau$	$\frac{\mathcal{F}(\omega)}{j\omega} + \pi\mathcal{F}(0)\delta(\omega)$

E Common Laplace Transform Pairs and Properties

Table 4: Basic Laplace Transforms

Type	Time-Domain	s-domain	Region of Convergence
Unit impulse	$\delta(t)$	1	all s
Delayed impulse	$\delta(t - \tau)$	$e^{-\tau s}$	all s
Unit step (Heaviside)	$u(t)$	$\frac{1}{s}$	$\Re(s) > 0$
Delayed unit step	$u(t - \tau)$	$\frac{1}{s} e^{-\tau s}$	$\Re(s) > 0$
Delayed function and step	$f(t - \tau)u(t - \tau)$	$e^{s-\tau} \mathcal{L}\{f(t)\}$	
Rectangular impulse	$u(t) - u(t - \tau)$	$\frac{1}{s} (1 - e^{-\tau s})$	$\Re(s) > 0$
Ramp	$tu(t)$	$\frac{1}{s^2}$	$\Re(s) > 0$
n th power ($n \in \mathbb{R}$)	$t^n u(t)$	$\frac{n!}{s^{n+1}}$	$\Re(s) > 0, n > -1$
n th polynomial	$\frac{t^{n-1}}{(n-1)!} u(t)$	$\frac{1}{s^n}$	$\Re(s) > 0, n > 1$
Exponential decay	$e^{-\alpha t} u(t)$	$\frac{1}{s+\alpha}$	$\Re(s) > -\alpha$
n th power using frequency shift	$t^n e^{-\alpha t}$	$\frac{n!}{(s+\alpha)^{n+1}}$	
Sine	$\sin(\omega t) u(t)$	$\frac{\omega}{s^2 + \omega^2}$	$\Re(s) > 0$
Cosine	$\cos(\omega t) u(t)$	$\frac{s}{s^2 + \omega^2}$	$\Re(s) > 0$
Exponentially decaying sine wave	$e^{-\alpha t} \sin(\omega t) u(t)$	$\frac{\omega}{(s+\alpha)^2 + \omega^2}$	$\Re(s) > -\alpha$
Exponentially decaying cosine wave	$e^{-\alpha t} \cos(\omega t) u(t)$	$\frac{s+\alpha}{(s+\alpha)^2 + \omega^2}$	$\Re(s) > -\alpha$