

# CSCE 560 Introduction to Computer Networking







# Chapter 7 Outline

#### 7.1 Introduction

#### Wireless

- 7.2 Wireless links, characteristics
  - \* CDMA
- 7.3 IEEE 802.11 wireless LANs ("Wi-Fi")
- 7.4 Cellular Internet Access
  - \* Architecture
  - Standards (e.g., GSM)




#### Mobility

- 7.5 Principles: addressing and routing to mobile users
- 7.6 Mobile IP
- 7.7 Managing mobility in cellular networks
- 7.8 Wireless and Mobility: Impact on higher-layer protocols

Another great source:

802.11 Wireless Networks - The
Definitive Guide by Matthew Gast




**CSCE 660** 

# Abridged Wireless History


- □ 1867 Maxwell predicts existence of electromagnetic (EM) waves
- □ 1887 Hertz proves existence of EM waves
  - First spark transmitter generates a spark in a receiver several meters away
- □ 1896 Marconi demos wireless telegraph to English telegraph office
- □ 1898 First commercial radio data service
- □ 1914 First voice over radio transmission
- □ 1920s Mobile receivers installed in police cars in Detroit
- □ 1946 First interconnection of mobile users to public switched telephone
  - St. Louis using Push-to-talk
- □ 1962 First communication satellite, Telstar, launched into orbit
- □ 1970 First Cellular Phone Service:
  - Chicago using cells, handoff, and roaming
- □ 1971 First Wireless Data Network:
  - Aloha at University of Hawaii
- □ 1990 First Commercial Wireless LAN Product
  - AT&T WaveLAN
- □ 1997 First Wireless LAN Standard IEEE 802.11
  - 2 Mbps
- 2016 about 15 billion Wi-Fi devices sold
- 2018 More than half the Internet traffic traverses Wi-Fi networks




# Characteristics of Selected Wireless Links




#### Wireless Hosts




#### Base Station




#### Wireless Link



#### Infrastructure Mode



### Ad Hoc Mode



#### Ad Hoc mode -

- No base stations
- Nodes can only transmit to other nodes within link coverage
- Nodes organize themselves into a network: route among themselves

# Chapter 7 Outline

#### 7.1 Introduction

#### Wireless

- 7.2 Wireless links, characteristics
  - \* CDMA
- 7.3 IEEE 802.11 wireless LANs ("Wi-Fi")
- 7.4 Cellular Internet Access
  - \* Architecture
  - \* Standards (e.g., GSM)

#### Mobility

- 7.5 Principles: addressing and routing to mobile users
- 7.6 Mobile IP
- 7.7 Managing mobility in cellular networks
- 7.8 Wireless and Mobility: Impact on higher-layer protocols

#### Wireless Link Characteristics

Differences from wired link ...

- Decreased signal strength: radio signal attenuates significantly as it propagates (path loss)
- \* Interference from other sources: standardized wireless network frequencies (e.g., 2.4 GHz) shared by other devices (e.g., cordless phones); devices (motors) generate EM noise
- Multipath propagation: radio signal reflects off objects, ground arriving at destination at slightly different times
- ... make communication across (even a point to point) wireless link much more "difficult" and ...
- ... increases the bit error rate forcing the use of link-level ARQ protocols

# Signal Loss

- Even when line-of-sight exists, signal attenuates with distance
- □ Path loss: attenuation undergone by electromagnetic wave in transit between transmitter and receiver
- Roughly proportional to 1/d²

Loss at 2.45 GHz

Distance (m)	Loss (dB)
100	80.2
200	86.2
500	94.2
1000	100.2






FIGURE 1. ESTIMATED INDOOR PROPAGATION LOSSES AT 2.4GHz

#### Interference from Other Sources

- Generally nodes use the same frequency
- □ Transmission range
  - Communication possible
  - Low error rate
- Detection (carrier sensing) range
  - Signal detection possible
  - \* No comm possible
  - Triggers carrier sense detection at receiver
- Interference range
  - Signal may not be detected
  - Signal adds to background noise



# Standards Bodies Responsibilities



IETF – Internet Engineering Task Force

IEEE – Institute of Electrical and Electronics Engineers

FCC – Federal Communications Commission

#### Wi-Fi Alliance



- Wi-Fi → Wireless Fidelity
- Certifies interoperability of 802.11-based products
  - Non-profit organization founded in 1999
  - Over 600 member organizations
  - Develop universal specifications and follow through with rigorous testing and Wi-Fi certification of wireless devices
  - \* Certified the interoperability of more than 40,000 products


#### FCC Rules



- Although the FCC does not require a license to operate in the ISM bands, you must still abide by certain limitations
  - Part 47 Code of Federal Regulations (CFR), Chapter 1, Section 15.247
    - TITLE 47—TELECOMMUNICATION
    - CHAPTER I--FEDERAL COMMUNICATIONS COMMISSION
    - PART 15--RADIO FREQUENCY DEVICES--Table of Contents
    - Subpart C--Intentional Radiators
    - Sec. 15.247 Operation within the bands
      - 902-928 MHz.
      - 2400-2483.5 MHz
      - 5725-5850 MHz
- Point-to-Multipoint (PtMP) communications (primarily indoor)
  - Maximum EIRP for indoor applications < 1 watt (30 dBm)</li>
- Point-to-Point (PtP) systems (primarily outdoor)
  - Maximum EIRP for outdoor applications < 4 watts (36 dBm)</li>

#### Intentional Radiator and EIRP

- Intentional Radiator
  - Device that intentionally generates and emits RF energy
  - Includes radio, cables, and connectors
  - Does not include antenna
- □ Equivalent Isotropically Radiated Power (EIRP)
  - Power that is radiated into free space
    - · Output of Intentional Radiator plus antenna



# dB (One Tenth of a Bel)



- decibels (dB) are measured as the ratio of two power levels
  - \* Based on a logarithmic scale

$$N_{dB} = 10 \log_{10} \frac{P_1}{P_2}$$

- Power and gain are measured in dB
- Units of measure for wireless systems
  - Watts basic unit of power
  - Milliwatt (mW) absolute standard of measurement
  - \* dBm decibel milliwatt
    - Power relative to 1 milliwatt (i.e., 0 dBm = 1 mW)
- dBi decibel isotropic
  - Used for antennas
  - Power relative to an isotropic radiator (gain = 1)

#### dB Math

$$N_{dB} = 10 \log_{10} \frac{Pout}{Pin}$$

□ -3 dB = half power

$$10\log_{10}\frac{50mW}{100mW} = 10\log_{10}0.5 = 10*(-0.301) = -3dB$$

□ +3 dB = double power

$$10 \log_{10} \frac{100 \, mW}{50 \, mW} = 10 \log_{10} 2 = 10 * (0.301) = 3 \, dB$$

□ -10 dB = one tenth power

$$10 \log_{10} \frac{10 \, mW}{100 \, mW} = 10 \log_{10} 0.1 = 10 * (-1) = -10 \, dB$$

□ +10 dB = ten times power

$$10 \log_{10} \frac{100 \, mW}{10 \, mW} = 10 \log_{10} 10 = 10 * (1) = 10 \, dB$$

### dB Math

$$N_{dB} = 10 \log_{10} \frac{Pout}{Pin}$$

dBm	mW	dBm	mW
0 dBm	1 mW	0 dBm	1 mW
1 dBm	1.25 mW	-1 dBm	0.8 mW
3 dBm	2 mW	-3 dBm	0.5 mW
6 dBm	4 mW	-6 dBm	0.25 mW
7 dBm	5 mW	-7 dBm	0.20 mW
10 dBm	10 mW	-10 dBm	0.10 mW
12 dBm	16 mW	-12 dBm	0.06 mW
13 dBm	20 mW	-13 dBm	0.05 mW
15 dBm	32 mW	-15 dBm	0.03 mW
17 dBm	50 mW	-17 dBm	0.02 mW
20 dBm	100 mW	-20 dBm	0.01 mW
30 dBm	1000 mW (1 W)	-30 dBm	0.001 mW
40 dBm	10,000 mW (10 W)	-40 dBm	0.0001 mW

Increase	Factor	Decrease	Factor
0 dB	1 x (same)	0 dB	1 x (same)
1 dB	1.25 x	-1 dB	0.8 x
3 dB	2 x	-3 dB	0.5 x
6 dB	4 x	-6 dB	0.25 x
10 dB	10 x	-10 dB	0.10 x
12 dB	16 x	-12 dB	0.06 x
20 dB	100 x	-20 dB	0.01 x
30 dB	1000 x	-30 dB	0.001 x
40 dB	10,000 x	-40 dB	0.0001 x

$$10^{\frac{dB}{10}} = mW$$

$$10^{\frac{dB}{10}} = factor$$

# dB Math Examples

$$N_{dB} = 10 \log_{10} \frac{Pout}{Pin}$$

- We will transmit the following power from an intentional radiator through an antenna or cable
  - Calculate the EIRP
- □ 20 mW thru a -3 dB cable
  - ❖ 20 mW \* 0.5 = 10 mW
- 20 mW thru a +3 dBi antenna
  - ❖ 20 mW \* 2 = 40 mW
- □ 13 dBm thru a -10 dB cable
  - ◆ 20 mW \* 0.1 = 2 mW OR 13 dBm 10 dB = 3 dBm = 2 mW
- □ 13 dBm thru a +10 dBi antenna
  - ◆ 20 mW \* 10 = 200 mW OR 13 dBm + 10 dB = 23 dBm = 200 mW


# dB Math - You Try

$$N_{dB} = 10 \log_{10} \frac{Pout}{Pin}$$

- 20 dBm radio + 3 dBi antenna
- 16 dBm radio + 9 dBi antenna
- □ 16 dBm radio + 8 dBi antenna + 2 cable connectors
  - Each connector experiences 1 dB loss
- □ 300 mW radio + 10 dBi antenna
- 20 dBm radio + 23 dBi antenna


#### Antennas

- An antenna is a passive device that focuses radiation energy by virtue of its shape
  - Antenna does not condition or amplify the signal
  - It simply redistributes energy in some directions better than others
- Amount of gain depends on type of antenna




#### Antennas

- Think of an adjustable flashlight
  - A wider beam does not project as much light at a distance as does a narrow, focused beam
- □ Beamwidth is the measure of beam focus
  - Omni-directional antenna = 360 degrees
    - Antenna on the left is an example
  - Antenna to the right is highly focused




# Omni-directional Antennas (Dipole)


- Most common type of WLAN antenna
- Radiates equally well in all directions horizontally
- Useful for large coverage areas




#### Semi-directional Antennas

- Concentrate energy in one direction
- Yagi, Panel
- Useful for point-to-point connections








8 dBi Uni (Panel)

# Highly-directional Antennas

Useful for point-to-point communication over long distances





Horizontal





24" x 36" Mesh Grid Antenna (21 dBi)

# Other Antennas

#### Cantennas








#### DEFCON WiFi Shootout 2005


- Team iFiber Redwire established an unamplified 802.11b link at 124.9 miles for 3 hours!
  - Used 12' dish on Mt. Potosi near Las Vegas and a 10' dish on a mountain near St. George Utah.
  - Used 300 mW PCMCIA cards
  - All team members were licensed amateur radio operators
    - Allowed higher power
  - Made 11,000 pings and set up a VNC connection



#### Wireless Network Characteristics

 Multiple wireless senders and receivers create additional problems (beyond multiple access):





#### Hidden terminal problem

- □ B, A hear each other
- □ B, C hear each other
- □ A, C cannot hear each other means A, C unaware of their interference at B


#### Signal attenuation:

- □ B, A hear each other
- □ B, C hear each other
- A, C cannot hear each other interfering at B

Unlike wired networks, wireless network nodes do not hear all transmissions


#### Hidden Terminal Problem

- □ Interference manifests itself at the receiver!!
- □ Node B can communicate with A and C
- □ A and C cannot hear each other
- □ When A transmits to B, C cannot detect the transmission using the carrier sense mechanism
- □ If C transmits to D, collision will occur at B




## Exposed Terminal Problem

- Once again, can only hear nearest neighbor
  - Node C can communicate with B and D
  - Node B can communicate with A and C
  - Node A cannot hear C
  - Node D cannot hear B
- When C transmits to D, B detects the transmission using the carrier sense mechanism and does not transmit to A, even though the transmission will not cause collision




# Spread Spectrum

 Spread spectrum signals are distributed over a wide range of frequencies and then collected back at the receiver




- These wideband signals are noise-like and hence difficult to detect or interfere with
- Initially adopted in military applications
  - Resistance to jamming
  - Difficulty of interception
- More recently adopted in commercial wireless communications
- Two types
  - Frequency hopping (FHSS)
  - Direct sequence (DSSS)



# Frequency Hopping

 Transmitter and receiver "hop" among different frequency channels according




to a pre-established hopping sequence

- \* Time at each channel is the dwell time, t<sub>D</sub>
- Total available bandwidth divided into smaller bandwidth channels (plus guard bands)
- Examples:
  - GSM (Global System for Mobile Communications)
  - Bluetooth
  - 802.11 Frequency Hopping PHY uses 79 non-overlapping frequency channels with 1 MHz channel spacing with hop times ~ 400 ms

# Frequency Hopping Genesis

 Australian actress Hedy Lamarr (born Hedwig Eva Maria Kiesler and aka H. K. Markey) holds a patent for Frequency Hopping along with composer George Antheil






# Direct Sequence Code Division Multiple Access (CDMA)


- Used in several wireless broadcast channel standards
  - Cellular, satellite, WLAN
- $\square$  Unique "code" assigned to each set of users  $\rightarrow$  code set partitioning
  - ❖ Code is a pseudo-random sequence of 1 and -1 values
    - Code resembles white noise → pseudo-noise (PN) code
  - All users share same frequency, but each user set has own "chipping" sequence (i.e., code) to encode data
  - Allows multiple user sets to "coexist" and transmit simultaneously with minimal interference (if codes are "orthogonal")
- Examples
  - \* GPS
  - \* IEEE 802.11b but only uses one pre-defined PN code
  - Cordless phones
  - \* Radio-controlled models

### CDMA Encode/Decode

- These two slides demonstrate basic operation
- Actual implementation is slightly different than shown




### CDMA: Two-sender Interference



# Direct Sequence Spread Spectrum (DSSS)

- Actual implementation uses XOR operation instead of multiplication
- User bit stream is XORed with a chipping sequence



# DSSS Spreading Factor

- Spreading factor determines the bandwidth of the signal to be transmitted
  - Order of 10 to 100 for commercial applications
  - Up to 10,000 for military applications
- □ IEEE 802.11 uses 11 chip Barker code
  - 10110111000

### DSSS versus FHSS

- Frequency hopping spread spectrum
  - Use only a portion of the bandwidth at any given time
  - Implementation of FHSS is simpler than DSSS
- Direct sequence spread spectrum
  - More resistant to fading (attenuation) and multipath
  - Harder to detect and intercept than FHSS
  - \* Opportunities for CDMA and adaptive communication schemes

# Chapter 7 Outline

#### 7.1 Introduction

#### Wireless

- 7.2 Wireless links, characteristics
  - \* CDMA
- 7.3 IEEE 802.11 wireless LANs ("Wi-Fi")
- 7.4 Cellular Internet Access
  - \* Architecture
  - Standards (e.g., GSM)

#### Mobility

- 7.5 Principles: addressing and routing to mobile users
- 7.6 Mobile IP
- 7.7 Managing mobility in cellular networks
- 7.8 Wireless and Mobility: Impact on higher-layer protocols

### IEEE 802.11 Wireless LAN


- □ 802.11b (1999 DSSS)
  - \* 2.4 or 5 GHz
  - Up to 11 Mbps
- 802.11a (1999 OFDM)
  - ❖ 5 GHz
  - Up to 54 Mbps
- 802.11g (2003 OFDM)
  - ❖ 2.4 or 5 GHz
  - Up to 54 Mbps

- 802.11n (2009 OFDM)
  - MIMO 4 data streams
  - ❖ 2.4 or 5 GHz
  - Up to 200 Mbps
- □ 802.11ac (2013 OFDM)
  - MIMO 8 data streams
  - ❖ 5 GHz
  - Up to 866 Mbps

- □ IEEE Std 802.11<sup>TM</sup>-2012  $\rightarrow$  2,793 pages  $\odot$
- □ All use CSMA/CA for multiple access
- All have base-station and ad-hoc network versions

### IEEE 802.11 Architecture

- 802.11 networks consist of four major physical components
  - Access Points
  - \* Wireless Medium
  - Stations
  - Distribution System



# Distribution System (DS)


□ Logical component of 802.11 used to forward frames to destination

Combination of bridging engine and DS medium

(e.g., backbone network)


802.11 does not specify a particular technology for DS

- Typically Ethernet
- Could also let APs communicate wirelessly to form a DS
  - Wireless DS (WDS)




## Basic Service Set (BSS)

- Basic building block of 802.11 network
  - Each AP has a service set identifier (BSSID)
    - Typically MAC address of AP's wireless interface
- Stations associate themselves with an AP
  - AP + associated stations form a BSS
- □ BSSs come in two flavors
  - Infrastructure BSS
    - Wireless hosts communicate only with AP
  - Independent BSS (IBSS)
    - Ad hoc mode: hosts only




### Infrastructure Mode

- Requires some infrastructure (access points)
- Access point is responsible for forwarding messages, control and management functions
- Access point acts as a bridge between wireline and wireless networks
- No direct communication between hosts
- Applications
  - \* Office-wide WLANs
  - Hotspots



## Extended Service Set (ESS)


- Created by chaining several BSSs together with a backbone network (distribution system)
- □ ESSs are highest-level abstraction supported by 802.11 networks



# ESS and Distribution Systems

- □ ESS has its own identifier → SSID: Service Set ID
  - Commonly known as the network name—human-readable name
  - "ESSID" is sometimes used to refer to the SSID used in the context of an ESS
  - Transparent to the end user
    - Traffic in ESS may use several different BSSIDs (APs)
- □ DSs enable mobile device support
  - Address-to-destination mapping
  - Seamless integration of several BSSs
  - In practice, an access point implements DS services

# Independent Basic Service Set



- Also known as ad hoc or peer-to-peer
- □ IBSSs are formed by stations communicating directly with one another (no AP)
- Multiple IBSSs can coexist in same geographic area by operating on different frequencies
- Ad hoc networks can coexist with infrastructure-based networks
- Stations use a random number as BSSID
  - \* First station selects BSSID and the others use it


### 802.11 Authentication and Association

Host must associate with an AP before data can be sent / received

#### Host


- 1. Scans channels listening for beacon frames containing AP's name Service Set ID (SSID) and MAC address
- 2. Selects an AP
- 3. If required, perform authentication
  - · Client proves knowledge of a given password
- 4. Performs association
  - Exchange info about stations and BSS capabilities
  - Creates a virtual wire between station and AP

# 802.11 Passive/Active Scanning



#### <u>Passive Scanning:</u>

- APs send beacon frames
- Association Request frame sent: H1 to selected AP
- 3. Association Response frame sent: AP to H1




#### Active Scanning:

- 1. Probe Request frame broadcast from H1
- 2. Probe Response frames sent from APs
  - H1 selects strongest AP
- 3. Association Request frame sent from H1 to selected AP
- 4. Association Response frame sent from AP to H1

### 802.11 Authentication and Association


 Prior to communicating data, access point requires client to authenticate and associate




Association enables data transfer between STA and AP

# 802.11 Multiple Access - CSMA/CA

- Avoid collisions: 2+ nodes transmitting at same time
- 802.11: CSMA sense before transmitting
  - Don't collide with ongoing transmission by other node
- 802.11: no collision detection!
  - Difficult to receive (sense collisions) when transmitting due to weak received signals (fading)
  - \* Can't sense all collisions in any case: hidden terminal, fading
  - Goal: avoid collisions: CSMA/C(ollision)A(voidance)





# Inter-frame Spacing

Immediate access when medium is free >= DIFS

DIFS

Contention Window

Next Frame

Slot Time Slot time = 20 µs for DS PHY


Defer Access

Select slot and decrement backoff as long

- Implement 3 levels of priority using Inter-frame Space (IFS)
  - DIFS (DCF IFS) Used for asynchronous data service
  - PIFS (PCF IFS) Used during the contention free period time-bounded service

as medium is idle

- \* SIFS (Short IFS) Used to send ACK, RTS/CTS, and other management frames  $\rightarrow$  10  $\mu$ s for DS PHY
- □ There are actually 6 IFSs!



- Destination returns ACK to indicate successful (correct CRC) reception of data
- □ If ACK never arrives, the source retransmits the frame after backoff time


### 802.11 MAC Protocol: CSMA/CA

#### 802.11 sender

- 1. If sense channel idle for **DIFS** then transmit entire frame (no CD)
- 2. If sense channel busy then start random backoff time; timer only counts down while channel idle
- 3. Transmit when timer expires and wait for ACK
- 4. If ACK received and more frames to send - goto 2 (backoff) If no ACK, increase random backoff interval and goto step 2

#### 802.11 receiver


If frame received OK return ACK after SIFS (ACK needed due to hidden terminal problem)




## Collision Avoidance (CA)

- □ Idea: Allow sender to "reserve" channel rather than random access of data frames: avoid collisions of long data frames
- Sender first transmits a small request-to-send (RTS) packet to AP using CSMA
  - \* RTSs contain the amount of time required by the station
  - RTSs may still collide with each other (but they're short)
- □ AP broadcasts clear-to-send (CTS) in response to RTS
- CTS heard by all associated nodes
  - Sender transmits data frame
  - Other stations defer transmissions

# Collision Avoidance: RTS-CTS Exchange



# Collision Avoidance: RTS-CTS Exchange



# Collision Avoidance (CA)

- RTS/CTS optional and is set by RTS threshold in sender
- Source can be Station or Access Point
  - ❖ Range = 0 2347
  - Most vendors recommend using a threshold of around 500
  - Threshold of 2347 bytes effectively disables RTS/CTS

DW1501 Wireless-N WLAN Half-Mini Card Properties General Advanced Driver Details Power Management The following properties are available for this network adapter. Click the property you want to change on the left, and then select its value on the right. Property: Value: IBSS 54g(tm) Protection Mode 2347 Locally Administered MAC Address Minimum Power Consumption PLCP Header Priority & VLAN Rate (802.11b/g) Roam Tendency Roaming Decision RTS Threshold Wake-Up Mode WMM WZC IBSS Channel Number XPress (TM) Technology

Client


**Access Point** 

Authentication Type:	Auto	(Default: Auto)
Basic Rate:	Default	(Default: Default)
Transmission Rate:	Auto	(Default: Auto)
CTS Protection Mode:	Disable	(Default: Disable)
Frame Burst:	Disable	✓ (Default: Disable)
Beacon Interval:	100	(Default: 100, Milliseconds, Range: 1 - 65535)
DTIM Interval:	1	(Default: 1, Range: 1 - 255)
Fragmentation Threshold:	2346	(Default: 2346, Range: 256 - 2346)
RTS Threshold:	2347	(Default: 2347, Range: 0 - 2347)
AP Isolation:	Off 🗸	Default: Off)

### Control Frames

Equal to 0 for final fragment or lone data frame

**RTS** 



bytes 2 2 6 4

ACK frame control duration receiver address CRC

Duration of upcoming data frame + CTS + ACK + (3 x SIFS)

bytes 2 2 6 6 4


frame control duration receiver address address CRC

bytes 2 2 6 4

frame duration receiver address CRC


frame – CTS – SIFS

**Duration field in RTS** 



# DCF Backoff (Contention window)

- System adaptively sets the contention window
  - Too low: high probability of collisions
  - Too high: unnecessary delays
- Exponential backoff
  - Each time
     a collision
     occurs,
     the
     contention
     window
     doubles up
     to a
     maximum
     CW<sub>max</sub>




### Backoff Timer


- Stations choose a random waiting time/slots w/i contention window
- □ If the station does not gain access to the medium in its first cycle,
  - it stops its backoff timer,
  - waits for the medium to be free for DIFS and then
  - starts the timer again
- A deferred station has a better chance to get access to the medium in the next cycle
  - Note: if a collision occurs the next time, a new random backoff timer will be chosen (retransmissions are not privileged)
- A station that completes a frame transmission is not allowed to transmit immediately
  - Must first perform a backoff procedure

### Contention Resolution

Backoff timer decrements only after DIFS has been detected



# 802.11 Data Frame: Addressing



### Address Fields

Wireless host or AP to receive this frame


Wireless host or AP transmitting this frame

Router interface to which AP is attached


_	To DS	From DS	Addr 1	Addr 2	Addr 3	Addr 4
ad hoc network  All management and control frames  Data frames within an IBSS (never infrastructure data frames)	0	0	DA	SA	BSSID	-
Infrastructure network, from AP  Data frames received for a wireless station in an infrastructure network	0	1	DA	BSSID	SA	1
Infrastructure network, to AP  Data frames transmitted from a wireless station in an infrastructure network	1	0	BSSID	SA	DA	-
Infrastructure network, within DS Transmission between two APs Data frames on a wireless bridge – Wireless Distribution System	1	1	RA	TA	DA	SA

"Destination" will process network-layer packet within frame "Receiver" will attempt to decode radio waves to form a frame

# 802.11 Frame: Addressing



## 802.11 Frame Format - MAC Layer



### MAC Frames

- Duration
  - \* Period of time the medium is expected to be occupied, in µs
  - Used to set NAV (Network Allocation Vector)
    - A virtual carrier sensing mechanism
  - Values above 32,768 are reserved
- Sequence control
  - Sequence numbers to filter out duplicates
  - \* First 4 bits for fragment number; last 12 for sequence number
- □ CRC
  - 32-bit checksum

### Frame Control

- □ Type:
  - Management (00)
  - Control (01)
  - Data (10)
  - \* Reserved (11)
- Subtype
  - \* Assoc request (0000)
  - \* Beacon (1000)
  - \* RTS (1011)
  - \* CTS (1100)

Type value (b3 b2)	Subtype value (b7 b6 b5 b4)	Frame Function
Management		
Туре	0000	Association request
('00)	0001	Association response
	0010	Reassociation request
	0011	Reassociation response
	0100	Probe request
	0101	Probe response
	0110–0111	Reserved
	1000	Beacon
	1001	ATIM
	1010	Disassociation
	1011	Authentication
	1100	Deauthentication
	1101	Action
	1110–1111	Reserved
Control Type	0000–0111	Reserved
		Block Ack Request
(01)	1000	(BlockAckReq)
)	1001	Block Ack (BlockAck)
	1010	PS-Poll
	1011	RTS
	1100	CTS
	1101	ACK
	1110	CF-End
	1111	CF-End + CF-Ack
Data Type	0000	Data
(10)	0001	Data + CF-Ack
	0010	Data + CF-Poll
	0011	Data + CF-Ack + CF-Poll
	0100	Null (no data)
	0101	CF-Ack (no data)
	110	CF-Poll (no data)
	0111	CF-Ack + CF-Poll (no data)
Reserved (11)	0000–1111	Reserved


### Frame Control

- More fragments: more fragments of the same MAC service data unit (MSDU) follow
- Retry: flag is set if this is a retransmission
- □ Power management: indicates whether station will stay active (0) or go into power-save mode (1) after transmission
- More data: AP has buffered data to transmit to host in power save mode (sleeping) - tells host to not go to sleep
- Protected Frame: information has been processed by a cryptographic encapsulation algorithm
- Order: if flag is set, received frames must be processed in order

# Synchronization

- Purpose is to find a WLAN and synchronize internal clocks
- All stations synchronize their internal clocks by listening to (quasi) periodic beacon signals
  - In infrastructure mode, APs transmit beacon signals
  - In ad hoc mode, any station may transmit a beacon signal
  - They may have to defer a scheduled transmission of the beacon signal when the medium is busy
- Beacon signals contain
  - Timestamp
  - Roaming information (identification of the BSS)

### Beacon Frames: Infrastructure Mode




### 802.11b Channels

- 802.11b: 2.4 GHz 2.4835 GHz spectrum divided into 11 channels at different frequencies
  - Administrator chooses frequency for AP
  - Interference possible: channel can be same as that chosen by neighboring AP!

Channel	Freq. (MHz)	US / Can	Eur.	Japan
1	2412	•	•	•
2	2417	•	•	•
3	2422	•	•	•
4	2427	•	•	•
5	2432	•	•	•
6	2437	•	•	•
7	2442	•	•	•

Channel	Freq.	US / Can	Eur.	Japan
8	2447	•	•	•
9	2452	•	•	•
10	2457	•	•	•
11	2462	•	•	•
12	2467		•	•
13	2472		•	•
14	2484			•

# 802.11b/g Channels



# 802.11a/b/g are Multi-rate Devices

- Typical transmission range
  - \* 802.11a
    - 120 m outdoor, 35 m indoor
      - 54 Mbit/s up to 5 m
      - 48 up to 12 m
      - 36 up to 25 m
      - 24 up to 30 m
      - 18 up to 40 m
      - 12 up to 60 m
      - and so on
  - \* 802.11b/g
    - 140 m outdoor, 38 m indoor
    - Max. data rate ~10 m indoor

