Microprocessors & Interfacing

Parallel Input/Output


Lecturer: Annie Guo

COMP9032 Week5

Lecture Overview

- I/O Addressing
 - Memory mapped I/O
 - Separate I/O
- Parallel Input/Output
 - AVR examples

COMP9032 Week5



I/O Addressing

- If the same address bus is used for both memory and I/O, how does hardware distinguish between memory reads/writes and I/O reads/writes?
 - Two approaches:
 - Memory-mapped I/O
 - Separate I/O
 - Both adopted in AVR

COMP9032 Week5

Memory Mapped I/O

 The entire memory address space contains a section for I/O registers.

Memory

I/O

COMP9032 Week5

AVR Memory Mapped I/O


- In AVR, 64+ I/O registers are mapped into memory space \$0020 ~ \$01FF
 - with 2-byte address
- With such memory addresses, the access to the I/O's uses memory-access type of instructions
 - E.g. st and Id

COMP9032 Week5

Memory Mapped I/O (cont.)

- Advantages:
 - Simple CPU design
 - No special instructions for I/O accesses
 - Scalable
- · Disadvantages:
 - I/O devices reduce the amount of memory space available for application programs.
 - The address decoder needs to decode the full address bus to avoid conflict with memory addresses.

COMP9032 Week5



Separate I/O

- Two separate spaces for memory and I/O.
 - Less expensive address decoders than those needed for memory-mapped I/O
- Special I/O instructions are required.

COMP9032 Week5

Separate I/O (cont.)

- In AVR, the first 64 I/O registers can be addressed with the separate I/O addresses: \$00 ~ \$3F
 - 1 byte address
- With such separate addresses, the access to the I/O's uses I/O specific instructions.
 - IN and OUT

COMP9032 Week5

I/O Synchronization

- CPU is typically much faster than I/O devices.
- Therefore, synchronization between CPU and I/O devices is required.
- Two synchronization approaches:
 - Software
 - Hardware
 - · To be covered later

COMP9032 Week5

Software Synchronization


- Two basic methods:
 - Real-time synchronization
 - Uses a software delay to match CPU to the timing requirement of the I/O device.
 - The timing requirement must be known
 - Sensitive to CPU clock frequency
 - Consumes CPU time.
 - Polling I/O
 - A status register, with a DATA_READY bit, is added to the device. The software keeps reading the status register until the DATA_READY bit is set.
 - Not sensitive to CPU clock frequency
 - Still consumes CPU time, but CPU can do other tasks at the same time.
- Examples will be given later


COMP9032 Week5

Parallel Input/Output in AVR

- Communication through parallel port
- Two special instructions designed for parallel input/output operations
 - IN
 - OUT

COMP9032 Week5





AVR PORTs

- Can be configured to receive or send data
- Include physical pins and related circuitry to enable input/output operations.
- Different AVR microcontroller devices have different port design
 - ATmega2560 has 100 pins, most of them form 11 ports for parallel input/output.
 - · Port A to Port G
 - Having separate I/O addresses
 - » using in or out instructions
 - Port H to Port L
 - Only having memory-mapped addresses
 - Three I/O addresses are allocated for each port. For example, for Port *x*, the related three registers are:
 - PORTx: data register
 - DDRx: data direction register
 - PINx: input pin register

COMP9032 Week5

Load I/O Data to Register

• Syntax: in Rd, A

• Operands: $0 \le d \le 31, 0 \le A \le 63$

• Operation: $Rd \leftarrow I/O(A)$

Words: 1

• Cycles: 1

• Example:

in r25, 0x03 ; read port B

•The names of the I/O ports are given in the device definition file, <u>m2560def.inc</u>.
•0x03 is an I/O register address of port B

COMP9032 Week5

Store Register Data to I/O Location

• Syntax: out A, Rr

• Operands: $0 \le r \le 31, 0 \le A \le 63$

Operation: I/O(A) ← Rr


Words: 1

• Cycles: 1

• Example:

out 0x05, r16; write to port B

COMP9032 Week5



How does it work?

- Each one-bit port circuit consists of three register bits. E.g. for pin n of port x, we have
 - DDRxn, PORTxn, and PINxn.
- The DDRxn bit in the DDRx Register selects the direction of this pin.
 - If DDxn is written logic one, the pin is configured as an output pin. If DDxn is written logic zero, the pin is configured as an input pin.

COMP9032 Week5

How does it work? (cont.)

- When the pin is configured as an input pin, the pull-up resistor can be activated/deactivated.
- To active pull-up resistor for input pin, PORTxn needs to be written logic one.

COMP9032 Week5

Sample Code for Output

```
.include "m2560def.inc"
                                 ; clear r16
        clr
                r16
                r17
        ser
                                 ; set r17
                DDRA, r17
                                 ; set Port A for output operation
        out
                PORTA, r16
                                 ; write zeros to Port A
        out
                                 ; wait (do nothing)
        nop
                                 ; write ones to Port A
                PORTA, r17
        out
```

COMP9032 Week5


Sample Code for Input

```
.include "m2560def.inc"
        clr
                r15
                                ; set Port A for input operation
        out
                DDRA, r15
                r25, PINA
                                ; read Port A
        in
                r25, 4
                                ; compare read value with constant
        cpi
                                ; branch if r25=4
        breq
                exit
                                ; branch destination (do nothing)
exit:
        nop
```

COMP9032 Week5

Example 1

 Design a simple control system that can control a set of LEDs to display a fixed pattern.






COMP9032 Week5

LED and Its Operation

For each LED, when its V+ > V-, it will emit light.



Example 1 (solution)

- The design consists of a number of steps:
 - Set a port for the output operation, one pin of the port is connected to one LED.
 - Write the pattern value to the port so that it drives the LEDs to display the related pattern.


```
.include "m2560def.inc"
ser r16
out DDRB, r16 ; set Port B for output

Idi r16, 0xAA ; write the pattern
out PORTB, r16
end:
rjmp end
```

COMP9032 Week5

Example 2

 Design a simple control system that can control a set of LEDs to display a fixed pattern for one second and then turn the LEDs off.



COMP9032 Week5

Example 2 (solution)

- The design consists of a number of steps:
 - Set a port for the output operation, one pin of the port is connected to one LED
 - Write the pattern value to the port so that it drives the display of LEDs
 - Wait for one second
 - Write a pattern to set all LEDs off.

COMP9032 Week5

Counting One Second

- · Basic idea:
 - Assume the clock cycle period is 1 ms (very very slow, not a real value). Then we can write a program that executes

$$\frac{1}{10^{-3}} = 1 \times 10^3$$

single cycle instructions.

- Execution of the code will take 1 second if each instruction in the code takes one clock cycle.
- An AVR implementation example is given in the next slide, where the 1 ms clock cycle time is assumed.

COMP9032 Week5

Code for One Second Delay (T_{clock}=1ms)

```
.include "m2560def.inc"
.equ loop_count = 124
.defiH = r25
.defiL = r24
.def countH = r17
.def countL = r16
.macro oneSecondDelay
         Idi countL, low(loop_count)
                                                ; 1 cycle
         Idi countH, high(loop_count)
         clr iH
                                                ; 1
         clr iL
  loop: cp iL, countL
                                                ; 1
         cpc iH, countH
                                                ; 1, 2 (if branch)
         brsh done
         adiw iH:iL, 1
                                                ; 2
         nop
         rjmp loop
                                                ; 2
  done:
.endmacro
```

COMP9032 Week5

Code for Example 2


```
ser r15
out DDRB, r15 ; set Port B for output

ldi r15, 0xAA ; write the pattern
out PORTB, r15
oneSecondDelay ; 1 second delay
ldi r15, 0x00
out PORTB, r15 ; turn off the LEDs
end:
rjmp end
```

COMP9032 Week5

Example 3

- Design a simple control system that can control a set of LEDs to display a fixed pattern that is specified by the user.
 - Assume there are switches. Each switch can provide two possible values (switch-on for logic one and switch-off for logic 0)



COMP9032 Week5

Example 3 (solution)

Design

- Connect the switches to the pins of a port
- Set the port for input
- Read the input
- Set another port for the output operation, each pin of the ports is connected to one LED
- Write the pattern value provided by the input switches to the port so that it drives the display of LEDs

Execution

- Set the switches for a desired input value
- Start the control system

COMP9032 Week5

Code for Example 3

```
.include "m2560def.inc"
        clr r17
        out DDRC, r17
                              ; set Port C for input
        ser r17
                                 ; activate the pull up
        out PORTC, r17
        in r17, PINC
                                 ; read the pattern set by the user
                                 ; from the switches
        ser r16
        out DDRB, r16
                                 ; set Port B for output
        out PORTB, r17
                                 ; write the input pattern
end:
        rjmp end
```

COMP9032 Week5

Example 4

 Design a simple control system that can control a set of LEDs to display a pattern specified by the user during the execution.


COMP9032 Week5

Example 4 (solution)

- Using polling to handle dynamic input
 - The processor continues checking if there is an input for read. If there is, the processor reads the input and goes to next task, otherwise the processor is in a waiting state for the input.

COMP9032 Week5

Example 4 (solution)



Design

- Set one port for input and connect each pin of the port to one switch
- Set another port for the output operation, each pin of the ports is connected to one LED
- Set a pin for input and connect the pin to the push-button,
 - · When the button is pressed, it signals "Input Pattern is ready"
- Poll the pin until "Input Pattern is ready"
- Read the input pattern
- Write the pattern to the port so that it drives the display of LEDs

During execution

- Set the switches for the input value
- Push the button
- The LEDs show the pattern as specified by the user.

COMP9032 Week5

Code for Example 4

 Set an extra input bit for signal from user when the input is ready.

```
.include "m2560def.inc"
           cbi DDRD, 7
                                            ; set Port D bit 7 for input
           clr r17
           out DDRC, r17
                                            ; set Port C for input
           ser r17
           out PORTC, r17
                                            ; activate the pull up
           ;ser r17
           out DDRB, r17
                                            ; set Port B for output
                                            ; check if that bit is clear
waiting:
                                            ; if yes skip the next instruction
           sbic PIND, 7
           rjmp waiting
                                            ; waiting
           in r17, PINC
                                            ; read pattern set by the user
                                            ; from the switches
           out PORTB, r17
           rjmp waiting
```

Announcements

- Lab boards available for loan this week
 - Please go to the course website. Read "Lab Board Instruction" available on the Labs page.
- Please use the board with great care.
 - Replacement is hardly possible due to limited number of boards available.
- One board per group
 - You need share the board with your group member.

COMP9032 Week5

Announcements

- Quiz next week (Week 6)
 - Location: Physics Theatre, K-K14-19
 - · See map below
 - Time: 18:10-19:10pm, Monday
 - Cover materials wk1-4
 - · AVR instruction set sheet provided
 - · The questions are of two types
 - Analysing code
 - Writing code



Figure 1 is a snapshot from the AVR studio simulation.

```
.include "m2560def.inc"
.macro store
ldi r16, @0
sts @1, r16
.endmacro
store 0xf0, 0x0021
store 0x01, 0x0022
store 0x53, 0x24
store 0x2c, 0x25
lds r30, 0x21
lds r31, 0x22
adiw z, 0x15
out SPL, r30
out SPH, r31
in r29, 0x04
push r29
end: rjmp end
```

Figure 1

- (a) What changes will be made to the data memory when the execution comes to the breakpoint? Draw the memory map (addresses and contents) of the affected area and show the changes.
- (b) When the execution comes to the end of the program from the breakpoint, what are stored in the address pointer and stack pointer? Are there any further changes to the data memory? If there are any, show the memory location(s) and the related contents.

COMP9032 Week5

Reading Materials

- Chapter 9: Computer Buses and Parallel Input and Output. Microcontrollers and Microcomputers by Fredrick M. Cady.
- Mega2560 Data Sheet
 - Ports

COMP9032 Week5

Homework

- 1. Refer to the AVR Instruction Set manual, study the following instructions:
 - Arithmetic and logic instructions
 - ser
 - Data transfer instructions
 - in, out
 - Bit operations
 - sbi, cbi
 - Program control instructions
 - sbic, sbis
 - MCU control instructions
 - nop

COMP9032 Week5

Homework

2. Study the following code. What is the function?

```
.include "m2560def.inc"
.def temp =r16
.equ PATTERN1 = 0x5B
.equ PATTERN2 = 0xAA
           ser temp
           out PORTC, temp
                                             ; Write ones to all the LEDs
                                             ; PORTC is output
           out DDRC, temp
                                             ; Enable pull-up resistors on PORTA
           out PORTA, temp
           cir temp
                                             ; PORTA is input
           out DDRA, temp
switch0:
           sbic PINA, 0
                                             ; Skip the next instruction
                                             ; if switch0 is pushed
                                             ; If not pushed, check the other switch
           rjmp switch1
           Idi temp, PATTERN1
                                             ; Store PATTERN1 to the LEDs
           out PORTC, temp
                                             ; if the switch was pushed
switch1:
           sbic PINA, 1
                                             ; Skip the next instruction
                                             ; if switch 1 is pushed
           rjmp switch0
                                             ; If not pushed, check the other switch
           Idi temp, PATTERN2
                                             ; Store PATTERN2 to the LEDs
           out PORTC, temp
                                             ; if the switch was pushed
           rjmp switch0
                                             ; Now check switch 0 again
```

Homework

- 3. Refer to "Introduction to Lab Board". Study the lab board. Write the assembly code to display pattern 10110111 on the LED bar through each of the following I/O ports:
 - (a) port C
 - (b) port F
 - (c) port L

COMP9032 Week5