

Solar[®] Turbines

A Caterpillar Company

Wire List

Wire List

PD/Unit Number:

ANG06

Project Name:

STOCK 6

Sheet Name:

JB71 B,PNL DC PWR

Revision:

A.6_M.2

PERSONNEL / SWS SIGN-IN

BADGE #	DATE	TIME	WIRER	IPV
-----	--/--/----	--:--	☐	☐
-----	--/--/----	--:--	☐	☐
-----	--/--/----	--:--	☐	☐
-----	--/--/----	--:--	☐	☐
-----	--/--/----	--:--	☐	☐
-----	--/--/----	--:--	☐	☐

Table of Contents

#	SECTION	ROWS	PAGE
INTERNAL			
JB71 B,PNL DC PWR			
1	Grounds	6	3
2	Clips	20	3
3	FU Jumpers	5	3
	FU		
	<i>L FU0016-FU0012</i>	4	3
4	Single Connections	12	4
	FU		
	<i>L FU0004</i>	2	4
	<i>L FU0005</i>	2	4
	XT		
	<i>L XT - XT</i>	2	4
	FU		
	<i>L FU0011</i>	2	4
	UJ		
	<i>L UJ0131</i>	2	4
	FU		
	<i>L FU0136</i>	2	4
EXTERNAL			
JB71 B,BOX CONTROL			
1	Single Connections	4	4
	XT		
	<i>L XT0005</i>	4	4
EXTERNAL			
JB71 B,PNL CTRL1			
1	Grounds	1	4
2	Single Connections	2	4
	XT		
	<i>L XT - XT</i>	2	4
EXTERNAL			
JB71 B,PNL CTRL2			
1	Grounds	3	4
2	Single Connections	6	4
	UJ		
	<i>L UJ0131</i>	4	4
	XT		
	<i>L XT - FU</i>	1	4
	<i>L XT - XT</i>	1	4
EXTERNAL			
JB71 B,PNL CUSTOMER			
1	Grounds	2	4

#	SECTION	ROWS	PAGE
2	Single Connections	2	5
	XT		
	L_{XT-FU}	1	5
	L_{XT-XT}	1	5
EXTERNAL JB71 B,PNL GEN CTRL			
1	Grounds	5	5
2	Single Connections	2	5
	XT		
	L_{XT-FU}	1	5
	L_{XT-XT}	1	5
EXTERNAL JB71 B,PNL VIBRATION			
1	Grounds	1	5
2	Single Connections	2	5
	XT		
	L_{XT-FU}	1	5
	L_{XT-XT}	1	5
EXTERNAL JB71 C,PNL EQP PWR			
1	Single Connections	2	5
	XT		
	L_{XT-FU}	1	5
	L_{XT-XT}	1	5

Locations: 8

Sections: 36

Rows: 75

Pages: 5

ANG06 STOCK 6 - Wire List

Rev: A.6_M.2 Rows: 75

INTERNAL
JB71 B,PNL DC PWR

Grounds (6)

FROM					TO			
COMPLETE	DEVICE ID	NO.	WIRE ID	SIZE	COMPLETE	DEVICE ID	IPV	NOTES
☐	GR0130	GR0130	GRN/YEL	14	☐	FRAME	☐	
☐	GR0131	GR0131	GRN/YEL	14	☐	FRAME	☐	
☐	GR0132	GR0132	GRN/YEL	14	☐	FRAME	☐	
☐	GR0133	GR0133	GRN/YEL	14	☐	FRAME	☐	
☐	PEG0130:1	-0V	GRN/YEL	8	☐	XT0003:6	☐	
☐	UJ0131:G	UJ0131G	GRN/YEL	12	☐	FRAME	☐	

INTERNAL
JB71 B,PNL DC PWR

Clips (20)

FROM			TO			
COMPLETE	DEVICE ID	WIRE ID	COMPLETE	DEVICE ID	IPV	NOTES
☐	XT0002:1	CLIP	☐	XT0002:2	☐	
☐	XT0002:2	CLIP	☐	XT0002:3	☐	
☐	XT0002:3	CLIP	☐	XT0002:4	☐	
☐	XT0002:4	CLIP	☐	XT0002:5	☐	
☐	XT0002:5	CLIP	☐	XT0002:6	☐	
☐	XT0002:6	CLIP	☐	XT0002:7	☐	
☐	XT0003:1	CLIP	☐	XT0003:2	☐	
☐	XT0003:2	CLIP	☐	XT0003:3	☐	
☐	XT0003:3	CLIP	☐	XT0003:4	☐	
☐	XT0003:4	CLIP	☐	XT0003:5	☐	
☐	XT0003:5	CLIP	☐	XT0003:6	☐	
☐	XT0003:6	CLIP	☐	XT0003:7	☐	
☐	XT0011:3	CLIP	☐	XT0011:4	☐	
☐	XT0011:4	CLIP	☐	XT0011:5	☐	
☐	XT0011:5	CLIP	☐	XT0011:6	☐	
☐	XT0011:6	CLIP	☐	XT0011:7	☐	

FROM			TO			
COMPLETE	DEVICE ID	WIRE ID	COMPLETE	DEVICE ID	IPV	NOTES
☐	XT0004:1	CLIP	☐	XT0004:2	☐	
☐	XT0004:3	CLIP	☐	XT0004:4	☐	
☐	XT0005:1	CLIP	☐	XT0005:2	☐	
☐	XT0005:3	CLIP	☐	XT0005:4	☐	

INTERNAL
JB71 B,PNL DC PWR

FU Jumpers (5)

FROM					TO			
COMPLETE	DEVICE ID	NO.	WIRE ID	SIZE	COMPLETE	DEVICE ID	IPV	NOTES
FU0016-FU0012								
☐	FU0012:LI	QF7753POS	---	BUS	☐	FU0013:LI	☐	
☐	FU0013:LI	QF7753POS	---	BUS	☐	FU0014:LI	☐	
☐	FU0014:LI	QF7753POS	---	BUS	☐	FU0015:LI	☐	
☐	FU0015:LI	QF7753POS	---	BUS	☐	FU0016:LI	☐	
☐	FU0012:LI	QF7753POS	---	BUS	☐	XT0012:1	☐	

INTERNAL
JB71 B,PNL DC PWR

Single Connections (12)

FROM					TO			
COMPLETE	DEVICE ID	NO.	WIRE ID	SIZE	COMPLETE	DEVICE ID	IPV	NOTES
FU0011								
☐	FU0011:LD	FU0011	WHT	12	☐	UJ0131:+	☐	
☐	FU0011:LI	QF7752POS	WHT	12	☐	XT0011:1	☐	
FU0136								
☐	FU0136:LI	-24V	WHT	10	☐	UJ0131:OUT(+)	☐	
☐	FU0136:LD	FU0136	WHT	10	☐	XT0002:1	☐	
FU0004								
☐	FU0004:LD	FU0004	WHT	14	☐	XT0004:1	☐	
☐	FU0004:LI	FU0136	WHT	14	☐	XT0002:7	☐	
FU0005								
☐	FU0005:LD	FU0005	WHT	14	☐	XT0005:1	☐	
☐	FU0005:LI	FU0136	WHT	14	☐	XT0002:7	☐	
UJ0131								

FROM					TO			
COMPLETE	DEVICE ID	NO.	WIRE ID	SIZE	COMPLETE	DEVICE ID	IPV	NOTES
☐	UJ0131:-	QF7752NEG	WHT	12	☐	XT0011:2	☐	
☐	UJ0131:OUT(-)	-0V	WHT	10	☐	XT0003:1	☐	
XT - XT								
☐	XT0003:7	-0V	WHT	14	☐	XT0004:3	☐	
☐	XT0005:3	-0V	WHT	14	☐	XT0003:7	☐	

EXTERNAL
JB71 B,BOX CONTROL

Single Connections (4)

FROM					TO			
COMPLETE	DEVICE ID	NO.	WIRE ID	SIZE	COMPLETE	DEVICE ID	IPV	NOTES
XT0005								
☐	XT0005:1	FU0005	WHT	16	☐	EL0101:1+	☐	
☐	XT0005:2	FU0005	WHT	16	☐	EL0100:1+	☐	
☐	XT0005:3	-0V	WHT	16	☐	EL0101:2-	☐	
☐	XT0005:4	-0V	WHT	16	☐	EL0100:2-	☐	

EXTERNAL
JB71 B,PNL CTRL1

Grounds (1)

FROM					TO			
COMPLETE	DEVICE ID	NO.	WIRE ID	SIZE	COMPLETE	DEVICE ID	IPV	NOTES
☐	IEG0010:00	IEG0011G	GRN	8	☐	IEG0011:0	☐	

EXTERNAL
JB71 B,PNL CTRL1

Single Connections (2)

FROM					TO			
COMPLETE	DEVICE ID	NO.	WIRE ID	SIZE	COMPLETE	DEVICE ID	IPV	NOTES
XT - XT								
☐	XT0002:2	FU0136	WHT	14	☐	XT0070:1	☐	
☐	XT0003:2	-0V	WHT	12	☐	XT0070:2	☐	

EXTERNAL

JB71 B,PNL CTRL2

Grounds (3)

FROM					TO			
COMPLETE	DEVICE ID	NO.	WIRE ID	SIZE	COMPLETE	DEVICE ID	IPV	NOTES
☐	IEG0010:8	IEG00108	GRN	14	☐	AF0065:SH	☐	
☐	IEG0010:14	GR0060	GRN	14	☐	GR0060	☐	
☐	IEG0010:1	IEG00101	GRN	14	☐	XT1200:18	☐	

EXTERNAL
JB71 B,PNL CTRL2

Single Connections (6)

FROM					TO			
COMPLETE	DEVICE ID	NO.	WIRE ID	SIZE	COMPLETE	DEVICE ID	IPV	NOTES
UJ0131								
☐	UJ0131:IOUT	UJ0131IOUT	WHT	20	☐	AF0385:09	☐	
☐	UJ0131:OK1	UJ0131OK1	WHT	20	☐	AF0061:41	☐	
☐	UJ0131:OK2	UJ0131OK2	WHT	20	☐	AF0061:09	☐	
☐	UJ0131:VIN	UJ0131VIN	WHT	20	☐	AF0385:07	☐	
XT - FU								
☐	XT0002:2	FU0136	WHT	12	☐	FU0060:LI	☐	
XT - XT								
☐	XT0003:2	-0V	WHT	12	☐	XT0060:1	☐	

EXTERNAL
JB71 B,PNL CUSTOMER

Grounds (2)

FROM					TO			
COMPLETE	DEVICE ID	NO.	WIRE ID	SIZE	COMPLETE	DEVICE ID	IPV	NOTES
☐	IEG0010:3	GR0180	GRN	14	☐	GR0180	☐	
☐	IEG0010:4	GR0650	GRN	14	☐	GR0650	☐	

EXTERNAL

JB71 B,PNL CUSTOMER

Single Connections (2)

FROM					TO			
COMPLETE	DEVICE ID	NO.	WIRE ID	SIZE	COMPLETE	DEVICE ID	IPV	NOTES
XT - FU								
☐	XT0002:4	FU0136	WHT	12	☐	FU0180:LI	☐	
XT - XT								
☐	XT0003:4	-0V	WHT	12	☐	XT0180:1	☐	

EXTERNAL
JB71 B,PNL GEN CTRL

Grounds (5)

FROM					TO			
COMPLETE	DEVICE ID	NO.	WIRE ID	SIZE	COMPLETE	DEVICE ID	IPV	NOTES
☐	IEG0010:11	IEG001011	GRN	14	☐	AF0124:SH	☐	
☐	IEG0010:12	GR0120	GRN	14	☐	GR0120	☐	
☐	IEG0010:9	XT01403	GRN	14	☐	XT0140:3	☐	
☐	PEG0130:2	EXCS	GRN/YEL	12	☐	XT0142:3	☐	
☐	PEG0130:3	PMGS	GRN/YEL	12	☐	XT0313:2	☐	

EXTERNAL
JB71 B,PNL GEN CTRL

Single Connections (2)

FROM					TO			
COMPLETE	DEVICE ID	NO.	WIRE ID	SIZE	COMPLETE	DEVICE ID	IPV	NOTES
XT - FU								
☐	XT0002:4	FU0136	WHT	12	☐	FU0120:LI	☐	
XT - XT								
☐	XT0003:4	-0V	WHT	12	☐	XT0120:1	☐	

EXTERNAL
JB71 B,PNL VIBRATION

Grounds (1)

FROM					TO			
COMPLETE	DEVICE ID	NO.	WIRE ID	SIZE	COMPLETE	DEVICE ID	IPV	NOTES
☐	IEG0010:2	XT04002	GRN	14	☐	XT0400:2	☐	

EXTERNAL
JB71 B,PNL VIBRATION

Single Connections (2)

FROM					TO			
COMPLETE	DEVICE ID	NO.	WIRE ID	SIZE	COMPLETE	DEVICE ID	IPV	NOTES
XT - FU								
☐	XT0002:3	FU0136	WHT	14	☐	FU0400:LI	☐	
XT - XT								
☐	XT0003:3	-0V	WHT	12	☐	XT0401:1	☐	

EXTERNAL
JB71 C,PNL EQP PWR

Single Connections (2)

FROM					TO			
COMPLETE	DEVICE ID	NO.	WIRE ID	SIZE	COMPLETE	DEVICE ID	IPV	NOTES
XT - FU								
☐	XT0002:3	FU0136	WHT	12	☐	FU0170:LI	☐	
XT - XT								
☐	XT0003:3	-0V	WHT	12	☐	XT0175:1	☐	