

Solar[®] Turbines

A Caterpillar Company

Wire List

PD/Unit Number:

4M231 / 1

Project Name:

PROP-92

Sheet Name:

PWR DST,DR,SMT130

Revision:

0.1

PERSONNEL / SWS SIGN-IN

BADGE #	DATE	TIME	WIRER	IPV
-----	--/--/----	--:-- --	☐	☐
-----	--/--/----	--:-- --	☐	☐
-----	--/--/----	--:-- --	☐	☐
-----	--/--/----	--:-- --	☐	☐
-----	--/--/----	--:-- --	☐	☐
-----	--/--/----	--:-- --	☐	☐

Table of Contents

#	SECTION	ROWS	PAGE
LOCATION: PWR DST DR SMT130			
1	Clips	5	3
2	FU Jumpers	5	3
	<i>L-FU0200-FU6500</i>	5	3
3	Single Connections	26	3
	<i>L-XT2930</i>	2	3
	<i>L-XT0563</i>	10	3
	<i>L-FU0560</i>	1	3
	<i>L-FU0200</i>	2	3
	<i>L-FU0201</i>	1	3
	<i>L-FU0273</i>	1	3
	<i>L-FU0190</i>	1	3
	<i>L-FU0701</i>	1	3
	<i>L-FU6500</i>	1	3
	<i>L-XT0562</i>	6	3

4M231 PROP-92 - Wire List

Unit: 1 Rev: 0.1 Rows: 36

LOCATION:
PWR DST,DR,SMT130

Clips (5)

FROM			TO				IPV	NOTES
✓	DEVICE ID	WIRE ID	✓	DEVICE ID	LOCATION			
☐	XT0562:1	CLIP	☐	XT0562:2	PWR DIST DOOR	☐		
☐	XT0562:2	CLIP	☐	XT0562:3	PWR DIST DOOR	☐		
☐	XT0562:3	CLIP	☐	XT0562:4	PWR DIST DOOR	☐		
☐	XT2930:1	CLIP	☐	XT2930:2	PWR DIST DOOR	☐		
☐	XT2930:3	CLIP	☐	XT2930:4	PWR DIST DOOR	☐		

FU Jumpers (5)

FROM					TO				
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
FU0200-FU6500									
☐	FU0190:LI	FU0560	WHT	12	☐	FU0701:LI	PWR DIST DOOR	☐	
☐	FU0190:LI	FU0560	WHT	12	☐	FU0273:LI	PWR DIST DOOR	☐	
☐	FU0200:LI	FU0560	WHT	12	☐	FU0201:LI	PWR DIST DOOR	☐	
☐	FU0201:LI	FU0560	WHT	12	☐	FU0273:LI	PWR DIST DOOR	☐	
☐	FU0701:LI	FU0560	WHT	12	☐	FU6500:LI	PWR DIST DOOR	☐	

Single Connections (26)

FROM					TO				
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
HL0410									
☐	HL0410:A	-0V	WHT	20	☐	XT0563:4	PWR DST DR SMT130	☐	
SA0401									
☐	SA0401:1	KA0241A1	WHT	20	☐	XT0563:5	PWR DST DR SMT130	☐	
☐	SA0401:2	FU0139	WHT	20	☐	XT0563:6	PWR DST DR SMT130	☐	
SB0400									
☐	SB0400:B1-11	ESTOPD	WHT	20	☐	XT0563:1	PWR DST DR SMT130	☐	
☐	SB0400:B1-12	ESTOPC	WHT	20	☐	XT0563:2	PWR DST DR SMT130	☐	
SB6500									
☐	SB6500:11	SB650011	WHT	20	☐	XT2930:2	PWR DST DR SMT130	☐	
☐	SB6500:12	FU6500	WHT	16	☐	FU6500:LD	PWR DST DR SMT130	☐	
SH0400									
☐	SH0400:B	-0V	WHT	20	☐	XT0563:4	PWR DST DR SMT130	☐	
XT/FU - XT									
☐	XT2930:3	-0V	WHT	20	☐	XT0562:4	PWR DIST DOOR	☐	

FROM					TO				
✓	DEVICE ID	NO.	WIRE ID	SIZE	✓	DEVICE ID	LOCATION	IPV	NOTES
☐	FU0560:LI	FU0136	WHT	14	☐	XT0102:2	PANEL A	☐	
XT0563									
☐	XT0563:3	KA033412	WHT	20	☐	KA0334:12	GEN CMPNT	☐	
☐	XT0563:1	ESTOPD	WHT	20	☐	XT2920:4	MCC PANEL	☐	
☐	XT0563:2	ESTOPC	WHT	20	☐	XT0290:3	MCC PANEL	☐	
☐	XT0563:3	KA033412	WHT	20	☐	XT0564:1 B2	TCP	☐	
FU0200									
☐	FU0200:LI	FU0560	WHT	12	☐	FU0560:LD	PWR DIST DOOR	☐	
☐	FU0200:LD	FU0200	WHT	16	☐	AU0200:V+	TCP	☐	
FU - AF									
☐	FU0201:LD	FU0201	WHT	16	☐	AF0202:V+	TCP	☐	
FU - EL									
☐	FU0273:LD	FU0273	WHT	16	☐	EL0273:B1	CTRL	☐	
FU - AT									
☐	FU0190:LD	FU0190	WHT	14	☐	AT0190:POS	PANEL DOOR	☐	
FU - KA									
☐	FU0701:LD	FU0701	WHT	16	☐	KA0334:11	GEN CMPNT	☐	
XT0562									
☐	XT0562:3	-0V	WHT	20	☐	XT0563:4	PWR DIST DOOR	☐	
☐	XT0562:2	-0V	WHT	16	☐	EL0273:W1	CTRL	☐	
☐	XT0562:3	-0V	WHT	14	☐	AT0190:NEG	PANEL DOOR	☐	
☐	XT0562:1	-0V	WHT	14	☐	XT0104:2	PANEL A	☐	
☐	XT0562:1	-0V	WHT	16	☐	AF0202:COM	TCP	☐	
☐	XT0562:1	-0V	WHT	16	☐	AU0200:COM	TCP	☐	