

# Solar<sup>®</sup> Turbines

A Caterpillar Company

Wire List

Wire List

PD/Unit Number:

ANG01 / 1

Project Name:

STOCK

Sheet Name:

JB71 B,PNL CTRL2

Revision:

A.6\_M.2

PERSONNEL / SWS SIGN-IN

| BADGE # | DATE       | TIME  | WIRER                    | IPV                      |
|---------|------------|-------|--------------------------|--------------------------|
| -----   | --/--/---- | --:-- | <input type="checkbox"/> | <input type="checkbox"/> |
| -----   | --/--/---- | --:-- | <input type="checkbox"/> | <input type="checkbox"/> |
| -----   | --/--/---- | --:-- | <input type="checkbox"/> | <input type="checkbox"/> |
| -----   | --/--/---- | --:-- | <input type="checkbox"/> | <input type="checkbox"/> |
| -----   | --/--/---- | --:-- | <input type="checkbox"/> | <input type="checkbox"/> |
| -----   | --/--/---- | --:-- | <input type="checkbox"/> | <input type="checkbox"/> |

# Table of Contents

| #                       | SECTION                                | ROWS | PAGE |
|-------------------------|----------------------------------------|------|------|
| INTERNAL                |                                        |      |      |
| <b>JB71 B,PNL CTRL2</b> |                                        |      |      |
| 1                       | Grounds                                | 14   | 3    |
| 2                       | Clips                                  | 18   | 3    |
| 3                       | VIO Jumpers                            | 2    | 4    |
|                         | $\angle XT0089$                        | 2    | 4    |
| 4                       | Resistors                              | 4    | 4    |
|                         | $\angle RR0812$                        | 2    | 4    |
|                         | $\angle RR0811$                        | 2    | 4    |
| 5                       | FU Jumpers                             | 8    | 4    |
|                         | $\angle FU0061-FU2108$                 | 8    | 4    |
| 6                       | Relay Mechanical Jumpers               | 14   | 4    |
|                         | $\angle A1: KA0061 \rightarrow KA0062$ | 1    | 4    |
|                         | $\angle A1: KA0131 \rightarrow KA0132$ | 1    | 4    |
|                         | $\angle A1: KA0176 \rightarrow KA0177$ | 1    | 4    |
|                         | $\angle A1: KA0231 \rightarrow KA0232$ | 1    | 4    |
|                         | $\angle A1: KA0238 \rightarrow KA0240$ | 2    | 4    |
|                         | $\angle A1: KA0241 \rightarrow KA0242$ | 1    | 4    |
|                         | $\angle A2: KA0061 \rightarrow KA0062$ | 1    | 4    |
|                         | $\angle A2: KA0131 \rightarrow KA0132$ | 1    | 4    |
|                         | $\angle A2: KA0176 \rightarrow KA0177$ | 1    | 4    |
|                         | $\angle A2: KA0231 \rightarrow KA0232$ | 1    | 4    |
|                         | $\angle A2: KA0238 \rightarrow KA0240$ | 2    | 4    |
|                         | $\angle A2: KA0241 \rightarrow KA0242$ | 1    | 4    |
| 7                       | KA Jumpers                             | 2    | 5    |
|                         | $\angle KA0132 \rightarrow KA0133$     | 1    | 5    |
|                         | $\angle KA0132 \rightarrow KA0133$     | 1    | 5    |
| 8                       | KA Twin Ferrules                       | 36   | 5    |
|                         | $\angle KA0060:A2 / -OV$               | 2    | 5    |
|                         | $\angle KA0131:21 / KT0146A1$          | 2    | 5    |
|                         | $\angle KA0132:11 / FU0387$            | 1    | 5    |
|                         | $\angle KA0132:12 / KT014315$          | 1    | 5    |
|                         | $\angle KA0133:A2 / -OV$               | 2    | 5    |
|                         | $\angle KA0134:11 / FU0387$            | 2    | 5    |
|                         | $\angle KA0135:21 / KA024911$          | 2    | 5    |
|                         | $\angle KA0135:22 / KA0177A1$          | 2    | 5    |
|                         | $\angle KA0135:A2 / -OV$               | 2    | 5    |
|                         | $\angle KA0137:11 / FU0387$            | 2    | 5    |
|                         | $\angle KA0137:14 / KA013222$          | 2    | 5    |
|                         | $\angle KA0137:21 / FU0387$            | 2    | 5    |
|                         | $\angle KA0235:A2 / -OV$               | 2    | 5    |

| #  | SECTION                        | ROWS | PAGE |
|----|--------------------------------|------|------|
|    | <i>L KA0241:11 / UA1200J21</i> | 2    | 5    |
|    | <i>L KA0242:11 / KT014618</i>  | 2    | 5    |
|    | <i>L KA0243:A1 / KA0243A1</i>  | 2    | 5    |
|    | <i>L KA0243:A2 / -OV</i>       | 2    | 5    |
|    | <i>L KA0244:A2 / -OV</i>       | 2    | 5    |
|    | <i>L KA0245:A1 / KA0245A1</i>  | 2    | 5    |
| 9  | KT Jumpers                     | 3    | 6    |
|    | <i>L KT0140 → KT0142</i>       | 2    | 6    |
|    | <i>L KT0141 → KT0142</i>       | 1    | 6    |
| 10 | AF/AU Jumpers                  | 15   | 6    |
| 11 | Single Connections             | 199  | 6    |
|    | <i>L KA0060</i>                | 3    | 6    |
|    | <i>L KA0380</i>                | 1    | 6    |
|    | <i>L KA0382</i>                | 1    | 6    |
|    | <i>L KA0061</i>                | 1    | 6    |
|    | <i>L KA0062</i>                | 3    | 6    |
|    | <i>L KA0070</i>                | 2    | 6    |
|    | <i>L XT0069</i>                | 2    | 6    |
|    | <i>L KA0130</i>                | 2    | 6    |
|    | <i>L KA0131</i>                | 5    | 6    |
|    | <i>L KA0132</i>                | 5    | 6    |
|    | <i>L KA0133</i>                | 2    | 6    |
|    | <i>L KA0134</i>                | 3    | 6    |
|    | <i>L KA0135</i>                | 2    | 6    |
|    | <i>L KA0136</i>                | 6    | 6    |
|    | <i>L KA0137</i>                | 2    | 6    |
|    | <i>L KA0138</i>                | 4    | 6    |
|    | <i>L KA0141</i>                | 4    | 6    |
|    | <i>L KA0176</i>                | 3    | 6    |
|    | <i>L KA0177</i>                | 2    | 6    |
|    | <i>L KA0231</i>                | 1    | 6    |
|    | <i>L KA0232</i>                | 3    | 6    |
|    | <i>L KA0235</i>                | 6    | 6    |
|    | <i>L KA0238</i>                | 4    | 6    |
|    | <i>L KA0239</i>                | 1    | 6    |
|    | <i>L KA0240</i>                | 4    | 6    |
|    | <i>L KA0241</i>                | 4    | 6    |
|    | <i>L KA0242</i>                | 3    | 6    |
|    | <i>L KA0244</i>                | 3    | 6    |
|    | <i>L KA0248</i>                | 2    | 6    |
|    | <i>L KA0243</i>                | 2    | 6    |
|    | <i>L KA0245</i>                | 1    | 6    |
|    | <i>L KA0246</i>                | 2    | 6    |
|    | <i>L KT0140</i>                | 4    | 6    |
|    | <i>L KT0141</i>                | 1    | 6    |

| #  | SECTION | ROWS | PAGE |
|----|---------|------|------|
|    | LKT0142 | 2    | 6    |
|    | LKT0145 | 2    | 6    |
|    | LKT0146 | 3    | 6    |
|    | LXT0087 | 1    | 6    |
|    | LXT0089 | 18   | 6    |
|    | LXT1200 | 8    | 6    |
|    | LXT0237 | 1    | 6    |
|    | LFU0060 | 1    | 6    |
|    | LFU0061 | 2    | 6    |
|    | LFU0062 | 1    | 6    |
|    | LFU0387 | 1    | 6    |
|    | LFU0388 | 1    | 6    |
|    | LFU0389 | 2    | 6    |
|    | LFU2108 | 1    | 6    |
|    | LXT0060 | 5    | 6    |
|    | LXT0080 | 1    | 6    |
|    | LXT0081 | 2    | 6    |
|    | LAFO385 | 6    | 6    |
|    | LAFO384 | 5    | 6    |
|    | LAFO383 | 15   | 6    |
|    | LAFO382 | 2    | 6    |
|    | LAFO381 | 17   | 6    |
|    | LAU0380 | 2    | 6    |
|    | LSA0472 | 3    | 6    |
|    | LUAI200 | 1    | 6    |
|    | LAFO061 | 2    | 6    |
| 12 | Cables  | 12   | 13   |

ANG01 STOCK - Wire List

Unit: 1    Rev: A.6\_M.2    Rows: 327

INTERNAL  
JB71 B,PNL CTRL2

Grounds (14)

| FROM                  |             |          |         |      | TO                    |            |                       |       |
|-----------------------|-------------|----------|---------|------|-----------------------|------------|-----------------------|-------|
| COMPLETE              | DEVICE ID   | NO.      | WIRE ID | SIZE | COMPLETE              | DEVICE ID  | IPV                   | NOTES |
| <input type="radio"/> | AF0062:SH   | AF0062G  | GRN     | 14   | <input type="radio"/> | AF0063:SH  | <input type="radio"/> |       |
| <input type="radio"/> | AF0063:SH   | AF0063G  | GRN     | 14   | <input type="radio"/> | AF0064:SH  | <input type="radio"/> |       |
| <input type="radio"/> | AF0064:SH   | AF0064G  | GRN     | 14   | <input type="radio"/> | AF0065:SH  | <input type="radio"/> |       |
| <input type="radio"/> | AF0382:SH   | AF0382G  | GRN     | 14   | <input type="radio"/> | AF0385:SH  | <input type="radio"/> |       |
| <input type="radio"/> | AF0062:SH   | AU0060G  | GRN     | 16   | <input type="radio"/> | AU0060:GND | <input type="radio"/> |       |
| <input type="radio"/> | AF0382:SH   | AU0380G  | GRN     | 16   | <input type="radio"/> | AU0380:GND | <input type="radio"/> |       |
| <input type="radio"/> | AF0065:SH   | IEG00108 | GRN     | 14   | <input type="radio"/> | IEG0010:8  | <input type="radio"/> |       |
| <input type="radio"/> | AF0385:SH   | IEG00115 | GRN     | 14   | <input type="radio"/> | IEG0011:5  | <input type="radio"/> |       |
| <input type="radio"/> | GR0060      | GR0060   | GRN     | 14   | <input type="radio"/> | IEG0010:14 | <input type="radio"/> |       |
| <input type="radio"/> | GR0381      | GR0381   | GRN/YEL | 14   | <input type="radio"/> | FRAME      | <input type="radio"/> |       |
| <input type="radio"/> | GR0382      | GR0382   | GRN/YEL | 14   | <input type="radio"/> | FRAME      | <input type="radio"/> |       |
| <input type="radio"/> | GR0383      | GR0383   | GRN/YEL | 14   | <input type="radio"/> | FRAME      | <input type="radio"/> |       |
| <input type="radio"/> | UA1200:J3-4 | IEG00101 | GRN     | 16   | <input type="radio"/> | XT1200:18  | <input type="radio"/> |       |
| <input type="radio"/> | XT1200:18   | IEG00101 | GRN     | 14   | <input type="radio"/> | IEG0010:1  | <input type="radio"/> |       |

INTERNAL  
JB71 B,PNL CTRL2

Clips (18)

| FROM                  |           |         | TO                    |           |                       |       |
|-----------------------|-----------|---------|-----------------------|-----------|-----------------------|-------|
| COMPLETE              | DEVICE ID | WIRE ID | COMPLETE              | DEVICE ID | IPV                   | NOTES |
| <input type="radio"/> | XT0060:1  | CLIP    | <input type="radio"/> | XT0060:2  | <input type="radio"/> |       |
| <input type="radio"/> | XT0060:2  | CLIP    | <input type="radio"/> | XT0060:3  | <input type="radio"/> |       |
| <input type="radio"/> | XT0060:3  | CLIP    | <input type="radio"/> | XT0060:4  | <input type="radio"/> |       |
| <input type="radio"/> | XT0060:4  | CLIP    | <input type="radio"/> | XT0060:5  | <input type="radio"/> |       |
| <input type="radio"/> | XT0060:5  | CLIP    | <input type="radio"/> | XT0060:6  | <input type="radio"/> |       |
| <input type="radio"/> | XT0060:6  | CLIP    | <input type="radio"/> | XT0060:7  | <input type="radio"/> |       |
| <input type="radio"/> | XT0060:7  | CLIP    | <input type="radio"/> | XT0060:8  | <input type="radio"/> |       |
| <input type="radio"/> | XT0060:8  | CLIP    | <input type="radio"/> | XT0060:9  | <input type="radio"/> |       |

| FROM                  |           |         | TO                    |           |                       |       |
|-----------------------|-----------|---------|-----------------------|-----------|-----------------------|-------|
| COMPLETE              | DEVICE ID | WIRE ID | COMPLETE              | DEVICE ID | IPV                   | NOTES |
| <input type="radio"/> | XT0060:9  | CLIP    | <input type="radio"/> | XT0060:10 | <input type="radio"/> |       |
| <input type="radio"/> | XT0080:1  | CLIP    | <input type="radio"/> | XT0080:2  | <input type="radio"/> |       |
| <input type="radio"/> | XT0080:3  | CLIP    | <input type="radio"/> | XT0080:2  | <input type="radio"/> |       |
| <input type="radio"/> | XT0080:3  | CLIP    | <input type="radio"/> | XT0080:4  | <input type="radio"/> |       |
| <input type="radio"/> | XT0080:4  | CLIP    | <input type="radio"/> | XT0080:5  | <input type="radio"/> |       |
| <input type="radio"/> | XT0080:6  | CLIP    | <input type="radio"/> | XT0080:5  | <input type="radio"/> |       |
| <input type="radio"/> | XT0081:1  | CLIP    | <input type="radio"/> | XT0081:2  | <input type="radio"/> |       |
| <input type="radio"/> | XT0081:3  | CLIP    | <input type="radio"/> | XT0081:2  | <input type="radio"/> |       |
| <input type="radio"/> | XT0081:3  | CLIP    | <input type="radio"/> | XT0081:4  | <input type="radio"/> |       |
| <input type="radio"/> | XT0081:4  | CLIP    | <input type="radio"/> | XT0081:5  | <input type="radio"/> |       |

INTERNAL

## JB71 B,PNL CTRL2

### VIO Jumpers (2)

| FROM                  |           |      |         |      | TO                    |           |                       |       |
|-----------------------|-----------|------|---------|------|-----------------------|-----------|-----------------------|-------|
| COMPLETE              | DEVICE ID | NO.  | WIRE ID | SIZE | COMPLETE              | DEVICE ID | IPV                   | NOTES |
| XT0089                |           |      |         |      |                       |           |                       |       |
| <input type="radio"/> | XT0089:13 | JP11 | VIO     | 20   | <input type="radio"/> | XT0089:12 | <input type="radio"/> |       |
| <input type="radio"/> | XT0089:15 | JP12 | VIO     | 20   | <input type="radio"/> | XT0089:14 | <input type="radio"/> |       |

INTERNAL

## JB71 B,PNL CTRL2

### Resistors (4)

| FROM                  |                    |         |         |      | TO                    |           |                       |       |
|-----------------------|--------------------|---------|---------|------|-----------------------|-----------|-----------------------|-------|
| COMPLETE              | DEVICE ID          | NO.     | WIRE ID | SIZE | COMPLETE              | DEVICE ID | IPV                   | NOTES |
| RR0812                |                    |         |         |      |                       |           |                       |       |
| <input type="radio"/> | RR0812: -1.0K OHM  | -0V     | LEAD    | ---  | <input type="radio"/> | XT0087:3  | <input type="radio"/> |       |
| <input type="radio"/> | RR0812: -1.0K OHM  | -038505 | LEAD    | ---  | <input type="radio"/> | XT0087:2  | <input type="radio"/> |       |
| RR0811                |                    |         |         |      |                       |           |                       |       |
| <input type="radio"/> | RR0811: -3.01K OHM | -038505 | LEAD    | ---  | <input type="radio"/> | XT0087:2  | <input type="radio"/> |       |
| <input type="radio"/> | RR0811: -3.01K OHM | FU0387  | LEAD    | ---  | <input type="radio"/> | XT0087:1  | <input type="radio"/> |       |

INTERNAL

## JB71 B,PNL CTRL2

### FU Jumpers (8)

| FROM                  |           |        |         |      | TO                    |           |                       |       |
|-----------------------|-----------|--------|---------|------|-----------------------|-----------|-----------------------|-------|
| COMPLETE              | DEVICE ID | NO.    | WIRE ID | SIZE | COMPLETE              | DEVICE ID | IPV                   | NOTES |
| FU0061-FU2108         |           |        |         |      |                       |           |                       |       |
| <input type="radio"/> | FU0061:LI | FU0060 | WHT     | 14   | <input type="radio"/> | FU0062:LI | <input type="radio"/> |       |
| <input type="radio"/> | FU0062:LI | FU0060 | WHT     | 14   | <input type="radio"/> | FU0380:LI | <input type="radio"/> |       |
| <input type="radio"/> | FU0380:LI | FU0060 | WHT     | 14   | <input type="radio"/> | FU0381:LI | <input type="radio"/> |       |
| <input type="radio"/> | FU0381:LI | FU0060 | WHT     | 14   | <input type="radio"/> | FU0382:LI | <input type="radio"/> |       |
| <input type="radio"/> | FU0382:LI | FU0060 | WHT     | 14   | <input type="radio"/> | FU0387:LI | <input type="radio"/> |       |
| <input type="radio"/> | FU0387:LI | FU0060 | WHT     | 14   | <input type="radio"/> | FU0388:LI | <input type="radio"/> |       |
| <input type="radio"/> | FU0388:LI | FU0060 | WHT     | 14   | <input type="radio"/> | FU0389:LI | <input type="radio"/> |       |
| <input type="radio"/> | FU0389:LI | FU0060 | WHT     | 14   | <input type="radio"/> | FU2108:LI | <input type="radio"/> |       |

INTERNAL

## JB71 B,PNL CTRL2

### Relay Mechanical Jumpers (14)

| FROM                  |           |         | TO                    |           |                       |       |
|-----------------------|-----------|---------|-----------------------|-----------|-----------------------|-------|
| COMPLETE              | DEVICE ID | WIRE ID | COMPLETE              | DEVICE ID | IPV                   | NOTES |
| A1: KA0061 -> KA0062  |           |         |                       |           |                       |       |
| <input type="radio"/> | KA0061:A1 | WHT     | <input type="radio"/> | KA0062:A1 | <input type="radio"/> |       |
| A1: KA0131 -> KA0132  |           |         |                       |           |                       |       |
| <input type="radio"/> | KA0131:A1 | WHT     | <input type="radio"/> | KA0132:A1 | <input type="radio"/> |       |
| A1: KA0176 -> KA0177  |           |         |                       |           |                       |       |
| <input type="radio"/> | KA0176:A1 | WHT     | <input type="radio"/> | KA0177:A1 | <input type="radio"/> |       |
| A1: KA0231 -> KA0232  |           |         |                       |           |                       |       |
| <input type="radio"/> | KA0231:A1 | WHT     | <input type="radio"/> | KA0232:A1 | <input type="radio"/> |       |
| A1: KA0238 -> KA0240  |           |         |                       |           |                       |       |
| <input type="radio"/> | KA0238:A1 | WHT     | <input type="radio"/> | KA0239:A1 | <input type="radio"/> |       |
| <input type="radio"/> | KA0239:A1 | WHT     | <input type="radio"/> | KA0240:A1 | <input type="radio"/> |       |
| A1: KA0241 -> KA0242  |           |         |                       |           |                       |       |
| <input type="radio"/> | KA0241:A1 | WHT     | <input type="radio"/> | KA0242:A1 | <input type="radio"/> |       |
| A2: KA0061 -> KA0062  |           |         |                       |           |                       |       |
| <input type="radio"/> | KA0061:A2 | WHT     | <input type="radio"/> | KA0062:A2 | <input type="radio"/> |       |
| A2: KA0131 -> KA0132  |           |         |                       |           |                       |       |
| <input type="radio"/> | KA0131:A2 | WHT     | <input type="radio"/> | KA0132:A2 | <input type="radio"/> |       |
| A2: KA0176 -> KA0177  |           |         |                       |           |                       |       |
| <input type="radio"/> | KA0176:A2 | WHT     | <input type="radio"/> | KA0177:A2 | <input type="radio"/> |       |

| FROM                  |           |         | TO                    |           |                       |       |
|-----------------------|-----------|---------|-----------------------|-----------|-----------------------|-------|
| COMPLETE              | DEVICE ID | WIRE ID | COMPLETE              | DEVICE ID | IPV                   | NOTES |
| A2: KAO231 -> KAO232  |           |         |                       |           |                       |       |
| <input type="radio"/> | KA0231:A2 | WHT     | <input type="radio"/> | KA0232:A2 | <input type="radio"/> |       |
| A2: KAO238 -> KAO240  |           |         |                       |           |                       |       |
| <input type="radio"/> | KA0238:A2 | WHT     | <input type="radio"/> | KA0239:A2 | <input type="radio"/> |       |
| <input type="radio"/> | KA0239:A2 | WHT     | <input type="radio"/> | KA0240:A2 | <input type="radio"/> |       |
| A2: KAO241 -> KAO242  |           |         |                       |           |                       |       |
| <input type="radio"/> | KA0241:A2 | WHT     | <input type="radio"/> | KA0242:A2 | <input type="radio"/> |       |

INTERNAL

**JB71 B,PNL CTRL2**

#### KA Jumpers (2)

| FROM                  |           |          |         |      | TO                    |           |                       |       |
|-----------------------|-----------|----------|---------|------|-----------------------|-----------|-----------------------|-------|
| COMPLETE              | DEVICE ID | NO.      | WIRE ID | SIZE | COMPLETE              | DEVICE ID | IPV                   | NOTES |
| KA0132 -> KA0133      |           |          |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0132:11 | FU0387   | WHT     | 20   | <input type="radio"/> | KA0133:11 | <input type="radio"/> |       |
| KA0132 -> KA0133      |           |          |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0132:12 | KT014315 | WHT     | 20   | <input type="radio"/> | KA0133:12 | <input type="radio"/> |       |

INTERNAL

**JB71 B,PNL CTRL2**

#### KA Twin Ferrules (36)

| FROM                  |           |          |         |      | TO                    |           |                       |       |
|-----------------------|-----------|----------|---------|------|-----------------------|-----------|-----------------------|-------|
| COMPLETE              | DEVICE ID | NO.      | WIRE ID | SIZE | COMPLETE              | DEVICE ID | IPV                   | NOTES |
| KA0060:A2 / -0V       |           |          |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0060:A2 | -0V      | WHT     | 20   | <input type="radio"/> | KA0061:A2 | <input type="radio"/> |       |
| <input type="radio"/> | KA0060:A2 | -0V      | WHT     | 20   | <input type="radio"/> | KA0242:A2 | <input type="radio"/> |       |
| KA0131:21 / KT0146A1  |           |          |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0131:21 | KT0146A1 | WHT     | 20   | <input type="radio"/> | KA0241:21 | <input type="radio"/> |       |
| <input type="radio"/> | KA0131:21 | KT0146A1 | WHT     | 20   | <input type="radio"/> | KT0146:A1 | <input type="radio"/> |       |
| KA0132:11 / FU0387    |           |          |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0132:11 | FU0387   | WHT     | 20   | <input type="radio"/> | XT0081:1  | <input type="radio"/> |       |
| KA0132:12 / KT014315  |           |          |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0132:12 | KT014315 | WHT     | 20   | <input type="radio"/> | KT0142:A1 | <input type="radio"/> |       |
| KA0133:A2 / -0V       |           |          |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0133:A2 | -0V      | WHT     | 20   | <input type="radio"/> | KA0136:A2 | <input type="radio"/> |       |
| <input type="radio"/> | KA0133:A2 | -0V      | WHT     | 20   | <input type="radio"/> | KT0144:A2 | <input type="radio"/> |       |

| FROM                  |           |           |         |      | TO                    |           |                       |       |
|-----------------------|-----------|-----------|---------|------|-----------------------|-----------|-----------------------|-------|
| COMPLETE              | DEVICE ID | NO.       | WIRE ID | SIZE | COMPLETE              | DEVICE ID | IPV                   | NOTES |
| KA0134:11 / FU0387    |           |           |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0134:11 | FU0387    | WHT     | 20   | <input type="radio"/> | KA0136:11 | <input type="radio"/> |       |
| <input type="radio"/> | KA0134:11 | FU0387    | WHT     | 20   | <input type="radio"/> | KT0144:15 | <input type="radio"/> |       |
| KA0135:21 / KA024911  |           |           |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0135:21 | KA024911  | WHT     | 20   | <input type="radio"/> | KA0232:12 | <input type="radio"/> |       |
| <input type="radio"/> | KA0135:21 | KA024911  | WHT     | 20   | <input type="radio"/> | KA0249:11 | <input type="radio"/> |       |
| KA0135:22 / KA0177A1  |           |           |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0135:22 | KA0177A1  | WHT     | 20   | <input type="radio"/> | KA0176:A1 | <input type="radio"/> |       |
| <input type="radio"/> | KA0135:22 | KA0177A1  | WHT     | 20   | <input type="radio"/> | KA0249:12 | <input type="radio"/> |       |
| KA0135:A2 / -0V       |           |           |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0135:A2 | -0V       | WHT     | 20   | <input type="radio"/> | KA0137:A2 | <input type="radio"/> |       |
| <input type="radio"/> | KA0135:A2 | -0V       | WHT     | 20   | <input type="radio"/> | KT0145:A2 | <input type="radio"/> |       |
| KA0137:11 / FU0387    |           |           |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0137:11 | FU0387    | WHT     | 20   | <input type="radio"/> | KT0140:15 | <input type="radio"/> |       |
| <input type="radio"/> | KA0137:11 | FU0387    | WHT     | 20   | <input type="radio"/> | KT0144:15 | <input type="radio"/> |       |
| KA0137:14 / KA013222  |           |           |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0137:14 | KA013222  | WHT     | 20   | <input type="radio"/> | KT0141:18 | <input type="radio"/> |       |
| <input type="radio"/> | KA0137:14 | KA013222  | WHT     | 20   | <input type="radio"/> | KT0144:18 | <input type="radio"/> |       |
| KA0137:21 / FU0387    |           |           |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0137:21 | FU0387    | WHT     | 20   | <input type="radio"/> | KA0244:11 | <input type="radio"/> |       |
| <input type="radio"/> | KA0137:21 | FU0387    | WHT     | 20   | <input type="radio"/> | KT0142:15 | <input type="radio"/> |       |
| KA0235:A2 / -0V       |           |           |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0235:A2 | -0V       | WHT     | 20   | <input type="radio"/> | KA0248:A2 | <input type="radio"/> |       |
| <input type="radio"/> | KA0235:A2 | -0V       | WHT     | 20   | <input type="radio"/> | XT0089:11 | <input type="radio"/> |       |
| KA0241:11 / UA1200J21 |           |           |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0241:11 | UA1200J21 | WHT     | 20   | <input type="radio"/> | KA0239:11 | <input type="radio"/> |       |
| <input type="radio"/> | KA0241:11 | UA1200J21 | WHT     | 20   | <input type="radio"/> | XT1200:15 | <input type="radio"/> |       |
| KA0242:11 / KT014618  |           |           |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0242:11 | KT014618  | WHT     | 20   | <input type="radio"/> | KA0231:11 | <input type="radio"/> |       |
| <input type="radio"/> | KA0242:11 | KT014618  | WHT     | 20   | <input type="radio"/> | KT0146:18 | <input type="radio"/> |       |
| KA0243:A1 / KA0243A1  |           |           |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0243:A1 | KA0243A1  | WHT     | 20   | <input type="radio"/> | KA0246:A1 | <input type="radio"/> |       |
| <input type="radio"/> | KA0243:A1 | KA0243A1  | WHT     | 20   | <input type="radio"/> | XT0089:3  | <input type="radio"/> |       |
| KA0243:A2 / -0V       |           |           |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0243:A2 | -0V       | WHT     | 20   | <input type="radio"/> | KA0246:A2 | <input type="radio"/> |       |
| <input type="radio"/> | KA0243:A2 | -0V       | WHT     | 20   | <input type="radio"/> | XT0080:3  | <input type="radio"/> |       |
| KA0244:A2 / -0V       |           |           |         |      |                       |           |                       |       |

| FROM                  |           |          |         |      | TO                    |           |                       |       |
|-----------------------|-----------|----------|---------|------|-----------------------|-----------|-----------------------|-------|
| COMPLETE              | DEVICE ID | NO.      | WIRE ID | SIZE | COMPLETE              | DEVICE ID | IPV                   | NOTES |
| <input type="radio"/> | KA0244:A2 | -0V      | WHT     | 20   | <input type="radio"/> | KA0245:A2 | <input type="radio"/> |       |
| <input type="radio"/> | KA0244:A2 | -0V      | WHT     | 20   | <input type="radio"/> | KA0246:A2 | <input type="radio"/> |       |
| KA0245:A1 / KA0245A1  |           |          |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0245:A1 | KA0245A1 | WHT     | 20   | <input type="radio"/> | KA0249:A1 | <input type="radio"/> |       |
| <input type="radio"/> | KA0245:A1 | KA0245A1 | WHT     | 20   | <input type="radio"/> | XT0089:4  | <input type="radio"/> |       |

INTERNAL

**JB71 B,PNL CTRL2**

**KT Jumpers (3)**

| FROM                  |           |          |         |      | TO                    |           |                       |       |
|-----------------------|-----------|----------|---------|------|-----------------------|-----------|-----------------------|-------|
| COMPLETE              | DEVICE ID | NO.      | WIRE ID | SIZE | COMPLETE              | DEVICE ID | IPV                   | NOTES |
| KT0140 -> KT0142      |           |          |         |      |                       |           |                       |       |
| <input type="radio"/> | KT0140:A2 | -0V      | WHT     | 20   | <input type="radio"/> | KT0141:A2 | <input type="radio"/> |       |
| <input type="radio"/> | KT0141:A2 | -0V      | WHT     | 20   | <input type="radio"/> | KT0142:A2 | <input type="radio"/> |       |
| KT0141 -> KT0142      |           |          |         |      |                       |           |                       |       |
| <input type="radio"/> | KT0141:A1 | KT014315 | WHT     | 20   | <input type="radio"/> | KT0142:A1 | <input type="radio"/> |       |

INTERNAL

**JB71 B,PNL CTRL2**

**AF/AU Jumpers (15)**

| FROM                  |            |         |         |      | TO                    |            |                       |       |
|-----------------------|------------|---------|---------|------|-----------------------|------------|-----------------------|-------|
| COMPLETE              | DEVICE ID  | NO.     | WIRE ID | SIZE | COMPLETE              | DEVICE ID  | IPV                   | NOTES |
| <input type="radio"/> | AF0061:V+  | AF0061P | WHT     | 16   | <input type="radio"/> | AF0062:V+  | <input type="radio"/> |       |
| <input type="radio"/> | AF0061:V+  | AU0060P | WHT     | 16   | <input type="radio"/> | AU0060:V+  | <input type="radio"/> |       |
| <input type="radio"/> | AF0061:COM | AF0061N | WHT     | 16   | <input type="radio"/> | AF0062:COM | <input type="radio"/> |       |
| <input type="radio"/> | AF0061:COM | AU0060N | WHT     | 16   | <input type="radio"/> | AU0060:COM | <input type="radio"/> |       |
| <input type="radio"/> | AF0381:V+  | AF0381P | WHT     | 16   | <input type="radio"/> | AF0382:V+  | <input type="radio"/> |       |
| <input type="radio"/> | AF0381:V+  | AU0380P | WHT     | 16   | <input type="radio"/> | AU0380:V+  | <input type="radio"/> |       |
| <input type="radio"/> | AF0381:COM | AF0381N | WHT     | 16   | <input type="radio"/> | AF0382:COM | <input type="radio"/> |       |
| <input type="radio"/> | AF0381:COM | AU0380N | WHT     | 16   | <input type="radio"/> | AU0380:COM | <input type="radio"/> |       |
| <input type="radio"/> | AF0062:V+  | AF0062P | WHT     | 16   | <input type="radio"/> | AF0063:V+  | <input type="radio"/> |       |
| <input type="radio"/> | AF0062:COM | AF0062N | WHT     | 16   | <input type="radio"/> | AF0063:COM | <input type="radio"/> |       |
| <input type="radio"/> | AF0063:V+  | AF0063P | WHT     | 16   | <input type="radio"/> | AF0064:V+  | <input type="radio"/> |       |
| <input type="radio"/> | AF0063:COM | AF0063N | WHT     | 16   | <input type="radio"/> | AF0064:COM | <input type="radio"/> |       |
| <input type="radio"/> | AF0064:V+  | AF0064P | WHT     | 16   | <input type="radio"/> | AF0065:V+  | <input type="radio"/> |       |

| FROM                  |            |         |         |      | TO                    |            |                       |       |
|-----------------------|------------|---------|---------|------|-----------------------|------------|-----------------------|-------|
| COMPLETE              | DEVICE ID  | NO.     | WIRE ID | SIZE | COMPLETE              | DEVICE ID  | IPV                   | NOTES |
| <input type="radio"/> | AF0064:COM | AF0064N | WHT     | 16   | <input type="radio"/> | AF0065:COM | <input type="radio"/> |       |
| <input type="radio"/> | AF0385:23  | -0V     | WHT     | 20   | <input type="radio"/> | AF0385:25  | <input type="radio"/> |       |

INTERNAL

## JB71 B,PNL CTRL2

### Single Connections (199)

| FROM                  |            |          |         |      | TO                    |           |                       |       |
|-----------------------|------------|----------|---------|------|-----------------------|-----------|-----------------------|-------|
| COMPLETE              | DEVICE ID  | NO.      | WIRE ID | SIZE | COMPLETE              | DEVICE ID | IPV                   | NOTES |
| SA0472                |            |          |         |      |                       |           |                       |       |
| <input type="radio"/> | SA0472:12  | ESTOP    | WHT     | 20   | <input type="radio"/> | KA0060:A1 | <input type="radio"/> |       |
| <input type="radio"/> | SA0472:21  | SA047221 | WHT     | 20   | <input type="radio"/> | AF0061:40 | <input type="radio"/> |       |
| <input type="radio"/> | SA0472:22  | SA047222 | WHT     | 20   | <input type="radio"/> | AF0061:08 | <input type="radio"/> |       |
| <input type="radio"/> | SA0472:11  | SA047211 | WHT     | 16   | <input type="radio"/> | XT6211:24 | <input type="radio"/> |       |
| SB0472                |            |          |         |      |                       |           |                       |       |
| <input type="radio"/> | SB0472:21  | SB047221 | WHT     | 20   | <input type="radio"/> | AF0381:38 | <input type="radio"/> |       |
| <input type="radio"/> | SB0472:22  | SB047222 | WHT     | 20   | <input type="radio"/> | AF0381:06 | <input type="radio"/> |       |
| KA0060                |            |          |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0060:14  | KA03805  | WHT     | 20   | <input type="radio"/> | KA0380:5  | <input type="radio"/> |       |
| <input type="radio"/> | KA0060:A1  | ESTOP    | WHT     | 20   | <input type="radio"/> | KA0061:A1 | <input type="radio"/> |       |
| AF0066                |            |          |         |      |                       |           |                       |       |
| <input type="radio"/> | AF0066:04  | KA03809  | WHT     | 20   | <input type="radio"/> | KA0380:9  | <input type="radio"/> |       |
| <input type="radio"/> | AF0066:12  | KA038214 | WHT     | 20   | <input type="radio"/> | KA0382:14 | <input type="radio"/> |       |
| <input type="radio"/> | AF0066:28  | SV21132  | WHT     | 20   | <input type="radio"/> | XT0069:3  | <input type="radio"/> |       |
| <input type="radio"/> | AF0066:20  | SV21202  | WHT     | 20   | <input type="radio"/> | XT0069:1  | <input type="radio"/> |       |
| <input type="radio"/> | AF0066:14  | KA0133A1 | WHT     | 20   | <input type="radio"/> | KA0133:A1 | <input type="radio"/> |       |
| <input type="radio"/> | AF0066:V+  | FU0062   | WHT     | 16   | <input type="radio"/> | FU0062:LD | <input type="radio"/> |       |
| <input type="radio"/> | AF0066:COM | -0V      | WHT     | 16   | <input type="radio"/> | XT0060:3  | <input type="radio"/> |       |
| KA - KA               |            |          |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0061:24  | KA00705  | WHT     | 20   | <input type="radio"/> | KA0070:5  | <input type="radio"/> |       |
| <input type="radio"/> | KA0231:24  | KA023124 | WHT     | 20   | <input type="radio"/> | KA0245:11 | <input type="radio"/> |       |
| <input type="radio"/> | KA0239:14  | KA024114 | WHT     | 20   | <input type="radio"/> | KA0241:14 | <input type="radio"/> |       |
| KA0062                |            |          |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0062:11  | KA038211 | WHT     | 20   | <input type="radio"/> | KA0382:11 | <input type="radio"/> |       |
| <input type="radio"/> | KA0062:A1  | ESTOP    | WHT     | 20   | <input type="radio"/> | KA0238:A1 | <input type="radio"/> |       |
| <input type="radio"/> | KA0062:A2  | -0V      | WHT     | 20   | <input type="radio"/> | KA0238:A2 | <input type="radio"/> |       |
| AF0073                |            |          |         |      |                       |           |                       |       |

| FROM                  |           |           |         |      | TO                    |              |                       |       |
|-----------------------|-----------|-----------|---------|------|-----------------------|--------------|-----------------------|-------|
| COMPLETE              | DEVICE ID | NO.       | WIRE ID | SIZE | COMPLETE              | DEVICE ID    | IPV                   | NOTES |
| <input type="radio"/> | AF0073:18 | KA007013  | WHT     | 20   | <input type="radio"/> | KA0070:13(-) | <input type="radio"/> |       |
| <input type="radio"/> | AF0073:02 | KA007014  | WHT     | 20   | <input type="radio"/> | KA0070:14(+) | <input type="radio"/> |       |
| KA0130                |           |           |         |      |                       |              |                       |       |
| <input type="radio"/> | KA0130:A1 | KA0130A1  | WHT     | 20   | <input type="radio"/> | KA0130:11    | <input type="radio"/> |       |
| <input type="radio"/> | KA0130:A2 | UA1200J26 | WHT     | 20   | <input type="radio"/> | XT1200:13    | <input type="radio"/> |       |
| KA0131                |           |           |         |      |                       |              |                       |       |
| <input type="radio"/> | KA0131:11 | KA0135A1  | WHT     | 20   | <input type="radio"/> | KA0135:A1    | <input type="radio"/> |       |
| <input type="radio"/> | KA0131:12 | KA013112  | WHT     | 20   | <input type="radio"/> | KA0137:24    | <input type="radio"/> |       |
| <input type="radio"/> | KA0131:24 | FU0071    | WHT     | 20   | <input type="radio"/> | KA0241:24    | <input type="radio"/> |       |
| <input type="radio"/> | KA0131:A1 | KA0131A1  | WHT     | 20   | <input type="radio"/> | KA0242:14    | <input type="radio"/> |       |
| <input type="radio"/> | KA0131:A2 | KA0131A2  | WHT     | 20   | <input type="radio"/> | AF0072:20    | <input type="radio"/> |       |
| KA0132                |           |           |         |      |                       |              |                       |       |
| <input type="radio"/> | KA0132:21 | KA0138A1  | WHT     | 20   | <input type="radio"/> | KA0138:A1    | <input type="radio"/> |       |
| <input type="radio"/> | KA0132:22 | KA013222  | WHT     | 20   | <input type="radio"/> | KT0141:18    | <input type="radio"/> |       |
| <input type="radio"/> | KA0132:24 | KA013224  | WHT     | 20   | <input type="radio"/> | KA0134:14    | <input type="radio"/> |       |
| <input type="radio"/> | KA0132:A1 | KA0131A1  | WHT     | 20   | <input type="radio"/> | KA0141:A1    | <input type="radio"/> |       |
| <input type="radio"/> | KA0132:A2 | KA0131A2  | WHT     | 20   | <input type="radio"/> | KA0141:A2    | <input type="radio"/> |       |
| KA/KT - KT            |           |           |         |      |                       |              |                       |       |
| <input type="radio"/> | KA0133:11 | FU0387    | WHT     | 20   | <input type="radio"/> | KT0144:A1    | <input type="radio"/> |       |
| <input type="radio"/> | KT0141:A1 | KT014315  | WHT     | 20   | <input type="radio"/> | KT0143:15    | <input type="radio"/> |       |
| AF0061                |           |           |         |      |                       |              |                       |       |
| <input type="radio"/> | AF0061:12 | KA0134A1  | WHT     | 20   | <input type="radio"/> | KA0134:A1    | <input type="radio"/> |       |
| <input type="radio"/> | AF0061:38 | KA013621  | WHT     | 20   | <input type="radio"/> | KA0136:21    | <input type="radio"/> |       |
| <input type="radio"/> | AF0061:06 | KA013624  | WHT     | 20   | <input type="radio"/> | KA0136:24    | <input type="radio"/> |       |
| <input type="radio"/> | AF0061:42 | KA014111  | WHT     | 20   | <input type="radio"/> | KA0141:11    | <input type="radio"/> |       |
| <input type="radio"/> | AF0061:10 | KA014114  | WHT     | 20   | <input type="radio"/> | KA0141:14    | <input type="radio"/> |       |
| <input type="radio"/> | AF0061:41 | UJ01310K1 | WHT     | 20   | <input type="radio"/> | UJ0131:0K1   | <input type="radio"/> |       |
| <input type="radio"/> | AF0061:09 | UJ01310K2 | WHT     | 20   | <input type="radio"/> | UJ0131:0K2   | <input type="radio"/> |       |
| KA0134                |           |           |         |      |                       |              |                       |       |
| <input type="radio"/> | KA0134:A2 | -0V       | WHT     | 20   | <input type="radio"/> | KT0143:A2    | <input type="radio"/> |       |
| <input type="radio"/> | KA0134:A1 | KA0134A1  | WHT     | 20   | <input type="radio"/> | AF0092:12    | <input type="radio"/> |       |
| KA0135                |           |           |         |      |                       |              |                       |       |
| <input type="radio"/> | KA0135:11 | KA013511  | WHT     | 20   | <input type="radio"/> | XT0089:29    | <input type="radio"/> |       |
| <input type="radio"/> | KA0135:14 | KA013514  | WHT     | 20   | <input type="radio"/> | XT0089:30    | <input type="radio"/> |       |
| KA0136                |           |           |         |      |                       |              |                       |       |
| <input type="radio"/> | KA0136:11 | FU0387    | WHT     | 20   | <input type="radio"/> | KT0144:A1    | <input type="radio"/> |       |
| <input type="radio"/> | KA0136:14 | KA013821  | WHT     | 20   | <input type="radio"/> | KA0138:21    | <input type="radio"/> |       |

| FROM                  |           |          |         |      | TO                    |           |                       |       |
|-----------------------|-----------|----------|---------|------|-----------------------|-----------|-----------------------|-------|
| COMPLETE              | DEVICE ID | NO.      | WIRE ID | SIZE | COMPLETE              | DEVICE ID | IPV                   | NOTES |
| <input type="radio"/> | KA0136:A1 | PS32002  | WHT     | 20   | <input type="radio"/> | XT0089:26 | <input type="radio"/> |       |
| <input type="radio"/> | KA0136:A2 | -0V      | WHT     | 20   | <input type="radio"/> | KA0138:A2 | <input type="radio"/> |       |
| KA0137                |           |          |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0137:24 | KA013112 | WHT     | 20   | <input type="radio"/> | AF0061:07 | <input type="radio"/> |       |
| <input type="radio"/> | KA0137:A1 | KA0137A1 | WHT     | 20   | <input type="radio"/> | KT0145:18 | <input type="radio"/> |       |
| KA0138                |           |          |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0138:24 | KT0144B1 | WHT     | 20   | <input type="radio"/> | KT0144:B1 | <input type="radio"/> |       |
| <input type="radio"/> | KA0138:A2 | -0V      | WHT     | 20   | <input type="radio"/> | KT0143:A2 | <input type="radio"/> |       |
| <input type="radio"/> | KA0138:11 | KA013811 | WHT     | 16   | <input type="radio"/> | XT0089:31 | <input type="radio"/> |       |
| <input type="radio"/> | KA0138:14 | FU0388   | WHT     | 16   | <input type="radio"/> | XT0060:11 | <input type="radio"/> |       |
| KA0141                |           |          |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0141:A1 | KA0131A1 | WHT     | 20   | <input type="radio"/> | KA0231:A1 | <input type="radio"/> |       |
| <input type="radio"/> | KA0141:A2 | KA0131A2 | WHT     | 20   | <input type="radio"/> | KA0231:A2 | <input type="radio"/> |       |
| KA0176                |           |          |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0176:11 | KA017611 | WHT     | 20   | <input type="radio"/> | XT0089:7  | <input type="radio"/> |       |
| <input type="radio"/> | KA0176:14 | KA017614 | WHT     | 20   | <input type="radio"/> | XT0089:8  | <input type="radio"/> |       |
| <input type="radio"/> | KA0176:A2 | -0V      | WHT     | 20   | <input type="radio"/> | XT0080:4  | <input type="radio"/> |       |
| KA0177                |           |          |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0177:11 | -065336  | WHT     | 20   | <input type="radio"/> | XT0089:38 | <input type="radio"/> |       |
| <input type="radio"/> | KA0177:14 | KA017714 | WHT     | 20   | <input type="radio"/> | XT0089:39 | <input type="radio"/> |       |
| KA0232                |           |          |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0232:11 | FU0387   | WHT     | 20   | <input type="radio"/> | XT0081:4  | <input type="radio"/> |       |
| <input type="radio"/> | KA0232:A1 | KA0131A1 | WHT     | 20   | <input type="radio"/> | XT0089:21 | <input type="radio"/> |       |
| <input type="radio"/> | KA0232:A2 | KA0131A2 | WHT     | 20   | <input type="radio"/> | XT0089:22 | <input type="radio"/> |       |
| KA0235                |           |          |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0235:11 | SB033312 | WHT     | 20   | <input type="radio"/> | XT0089:36 | <input type="radio"/> |       |
| <input type="radio"/> | KA0235:14 | KA023514 | WHT     | 20   | <input type="radio"/> | XT0089:37 | <input type="radio"/> |       |
| <input type="radio"/> | KA0235:A1 | ESTOP    | WHT     | 20   | <input type="radio"/> | KA0248:A1 | <input type="radio"/> |       |
| <input type="radio"/> | KA0235:A1 | ESTOP    | WHT     | 20   | <input type="radio"/> | XT0089:10 | <input type="radio"/> |       |
| <input type="radio"/> | KA0235:21 | KA023521 | WHT     | 16   | <input type="radio"/> | XT6211:9  | <input type="radio"/> |       |
| <input type="radio"/> | KA0235:24 | KA023524 | WHT     | 16   | <input type="radio"/> | XT6211:10 | <input type="radio"/> |       |
| KA0238                |           |          |         |      |                       |           |                       |       |
| <input type="radio"/> | KA0238:11 | KA023811 | WHT     | 20   | <input type="radio"/> | AF0072:35 | <input type="radio"/> |       |
| <input type="radio"/> | KA0238:14 | KA023814 | WHT     | 20   | <input type="radio"/> | AF0072:03 | <input type="radio"/> |       |
| <input type="radio"/> | KA0238:21 | -009234  | WHT     | 20   | <input type="radio"/> | AF0092:34 | <input type="radio"/> |       |
| <input type="radio"/> | KA0238:22 | KA023822 | WHT     | 16   | <input type="radio"/> | XT0091:3  | <input type="radio"/> |       |
| KA0240                |           |          |         |      |                       |           |                       |       |

| FROM                  |           |          |         |      | TO                    |             |                       |       |
|-----------------------|-----------|----------|---------|------|-----------------------|-------------|-----------------------|-------|
| COMPLETE              | DEVICE ID | NO.      | WIRE ID | SIZE | COMPLETE              | DEVICE ID   | IPV                   | NOTES |
| <input type="radio"/> | KA0240:11 | KA024011 | WHT     | 20   | <input type="radio"/> | XT0089:34   | <input type="radio"/> |       |
| <input type="radio"/> | KA0240:14 | PS32004  | WHT     | 20   | <input type="radio"/> | XT0089:27   | <input type="radio"/> |       |
| <input type="radio"/> | KA0240:A1 | ESTOP    | WHT     | 20   | <input type="radio"/> | KA0248:A1   | <input type="radio"/> |       |
| <input type="radio"/> | KA0240:A2 | -0V      | WHT     | 20   | <input type="radio"/> | KA0248:A2   | <input type="radio"/> |       |
| KA0241                |           |          |         |      |                       |             |                       |       |
| <input type="radio"/> | KA0241:14 | KA024114 | WHT     | 20   | <input type="radio"/> | KA0231:21   | <input type="radio"/> |       |
| <input type="radio"/> | KA0241:A2 | -0V      | WHT     | 20   | <input type="radio"/> | XT0080:5    | <input type="radio"/> |       |
| <input type="radio"/> | KA0241:24 | FU0071   | WHT     | 20   | <input type="radio"/> | XT0070:4    | <input type="radio"/> |       |
| <input type="radio"/> | KA0241:A1 | KA0241A1 | WHT     | 20   | <input type="radio"/> | XT0091:2    | <input type="radio"/> |       |
| KA0242                |           |          |         |      |                       |             |                       |       |
| <input type="radio"/> | KA0242:14 | KA0131A1 | WHT     | 20   | <input type="radio"/> | KA0231:14   | <input type="radio"/> |       |
| <input type="radio"/> | KA0242:21 | KA024221 | WHT     | 20   | <input type="radio"/> | KA0248:12   | <input type="radio"/> |       |
| <input type="radio"/> | KA0242:24 | KA024224 | WHT     | 20   | <input type="radio"/> | XT0237:1 T2 | <input type="radio"/> |       |
| KA0244                |           |          |         |      |                       |             |                       |       |
| <input type="radio"/> | KA0244:11 | FU0387   | WHT     | 20   | <input type="radio"/> | XT0081:2    | <input type="radio"/> |       |
| <input type="radio"/> | KA0244:12 | KT0145A1 | WHT     | 20   | <input type="radio"/> | KT0145:A1   | <input type="radio"/> |       |
| <input type="radio"/> | KA0244:A1 | KA0243A1 | WHT     | 20   | <input type="radio"/> | KA0246:A1   | <input type="radio"/> |       |
| KA0248                |           |          |         |      |                       |             |                       |       |
| <input type="radio"/> | KA0248:21 | KA024821 | WHT     | 16   | <input type="radio"/> | XT6211:7    | <input type="radio"/> |       |
| <input type="radio"/> | KA0248:24 | KA024824 | WHT     | 16   | <input type="radio"/> | XT6211:8    | <input type="radio"/> |       |
| KA0243                |           |          |         |      |                       |             |                       |       |
| <input type="radio"/> | KA0243:11 | KA024514 | WHT     | 20   | <input type="radio"/> | KA0245:14   | <input type="radio"/> |       |
| <input type="radio"/> | KA0243:14 | ESTOPC   | WHT     | 20   | <input type="radio"/> | XT0089:12   | <input type="radio"/> |       |
| KA:A2 - KA            |           |          |         |      |                       |             |                       |       |
| <input type="radio"/> | KA0245:A2 | -0V      | WHT     | 20   | <input type="radio"/> | KA0249:A2   | <input type="radio"/> |       |
| KA0246                |           |          |         |      |                       |             |                       |       |
| <input type="radio"/> | KA0246:11 | KA024611 | WHT     | 20   | <input type="radio"/> | XT0089:5    | <input type="radio"/> |       |
| <input type="radio"/> | KA0246:14 | KA024614 | WHT     | 20   | <input type="radio"/> | XT0089:6    | <input type="radio"/> |       |
| KT0140                |           |          |         |      |                       |             |                       |       |
| <input type="radio"/> | KT0140:16 | KT014115 | WHT     | 20   | <input type="radio"/> | KT0141:15   | <input type="radio"/> |       |
| <input type="radio"/> | KT0140:18 | KT0143A1 | WHT     | 20   | <input type="radio"/> | KT0143:A1   | <input type="radio"/> |       |
| <input type="radio"/> | KT0140:A1 | KT0140A1 | WHT     | 20   | <input type="radio"/> | KT0143:16   | <input type="radio"/> |       |
| <input type="radio"/> | KT0140:A2 | -0V      | WHT     | 20   | <input type="radio"/> | XT0080:1    | <input type="radio"/> |       |
| KT0142                |           |          |         |      |                       |             |                       |       |
| <input type="radio"/> | KT0142:15 | FU0387   | WHT     | 20   | <input type="radio"/> | KT0145:15   | <input type="radio"/> |       |
| <input type="radio"/> | KT0142:A2 | -0V      | WHT     | 20   | <input type="radio"/> | KT0144:A2   | <input type="radio"/> |       |
| KT0145                |           |          |         |      |                       |             |                       |       |

| FROM                  |              |           |         |      | TO                    |           |                       |       |
|-----------------------|--------------|-----------|---------|------|-----------------------|-----------|-----------------------|-------|
| COMPLETE              | DEVICE ID    | NO.       | WIRE ID | SIZE | COMPLETE              | DEVICE ID | IPV                   | NOTES |
| <input type="radio"/> | KT0145:18    | KA0137A1  | WHT     | 20   | <input type="radio"/> | KT0142:18 | <input type="radio"/> |       |
| <input type="radio"/> | KT0145:A2    | -0V       | WHT     | 20   | <input type="radio"/> | XT0080:2  | <input type="radio"/> |       |
| KT0146                |              |           |         |      |                       |           |                       |       |
| <input type="radio"/> | KT0146:18    | KT014618  | WHT     | 20   | <input type="radio"/> | AF0072:04 | <input type="radio"/> |       |
| <input type="radio"/> | KT0146:A2    | KT0146A2  | WHT     | 20   | <input type="radio"/> | AF0073:20 | <input type="radio"/> |       |
| <input type="radio"/> | KT0146:B1    | KT0146B1  | WHT     | 20   | <input type="radio"/> | AF0073:04 | <input type="radio"/> |       |
| XT - XT               |              |           |         |      |                       |           |                       |       |
| <input type="radio"/> | XT0087:1     | FU0387    | WHT     | 20   | <input type="radio"/> | XT0081:1  | <input type="radio"/> |       |
| <input type="radio"/> | XT0080:6     | -0V       | WHT     | 20   | <input type="radio"/> | XT0087:3  | <input type="radio"/> |       |
| XT0089                |              |           |         |      |                       |           |                       |       |
| <input type="radio"/> | XT0089:2     | -0V       | WHT     | 20   | <input type="radio"/> | XT0080:3  | <input type="radio"/> |       |
| <input type="radio"/> | XT0089:13    | ESTOPB    | WHT     | 20   | <input type="radio"/> | XT0089:16 | <input type="radio"/> |       |
| <input type="radio"/> | XT0089:25    | FU0387    | WHT     | 20   | <input type="radio"/> | XT0081:5  | <input type="radio"/> |       |
| <input type="radio"/> | XT0089:28    | PS32005   | WHT     | 20   | <input type="radio"/> | XT0089:35 | <input type="radio"/> |       |
| <input type="radio"/> | XT0089:32    | -0V       | WHT     | 16   | <input type="radio"/> | XT0060:8  | <input type="radio"/> |       |
| <input type="radio"/> | XT0089:36    | SB033312  | WHT     | 20   | <input type="radio"/> | XT0121:1  | <input type="radio"/> |       |
| <input type="radio"/> | XT0089:37    | KA023514  | WHT     | 20   | <input type="radio"/> | XT0121:3  | <input type="radio"/> |       |
| <input type="radio"/> | XT0089:1     | FU0387    | WHT     | 20   | <input type="radio"/> | XT0170:1  | <input type="radio"/> |       |
| <input type="radio"/> | XT0089:2     | -0V       | WHT     | 20   | <input type="radio"/> | XT0170:3  | <input type="radio"/> |       |
| <input type="radio"/> | XT0089:3     | KA0243A1  | WHT     | 20   | <input type="radio"/> | XT0170:2  | <input type="radio"/> |       |
| <input type="radio"/> | XT0089:4     | KA0245A1  | WHT     | 20   | <input type="radio"/> | XT0170:4  | <input type="radio"/> |       |
| <input type="radio"/> | XT0089:17    | ESTOPA    | WHT     | 20   | <input type="radio"/> | XT0091:7  | <input type="radio"/> |       |
| <input type="radio"/> | XT0089:20    | SB047212  | WHT     | 20   | <input type="radio"/> | XT0091:8  | <input type="radio"/> |       |
| <input type="radio"/> | XT0089:21    | KA0131A1  | WHT     | 20   | <input type="radio"/> | XT0091:11 | <input type="radio"/> |       |
| <input type="radio"/> | XT0089:22    | KA0131A2  | WHT     | 20   | <input type="radio"/> | XT0091:12 | <input type="radio"/> |       |
| <input type="radio"/> | XT0089:20    | SB047212  | WHT     | 20   | <input type="radio"/> | XT6211:23 | <input type="radio"/> |       |
| <input type="radio"/> | XT0089:38    | -065336   | WHT     | 20   | <input type="radio"/> | XT0291:8  | <input type="radio"/> |       |
| <input type="radio"/> | XT0089:39    | KA017714  | WHT     | 20   | <input type="radio"/> | XT0291:7  | <input type="radio"/> |       |
| UA1200                |              |           |         |      |                       |           |                       |       |
| <input type="radio"/> | UA1200:J1-4  | UA1200J14 | WHT     | 20   | <input type="radio"/> | XT1200:11 | <input type="radio"/> |       |
| <input type="radio"/> | UA1200:J1-9  | -0V       | WHT     | 20   | <input type="radio"/> | XT1200:17 | <input type="radio"/> |       |
| <input type="radio"/> | UA1200:J1-10 | FU0389    | WHT     | 20   | <input type="radio"/> | XT1200:16 | <input type="radio"/> |       |
| <input type="radio"/> | UA1200:J2-1  | UA1200J21 | WHT     | 20   | <input type="radio"/> | XT1200:15 | <input type="radio"/> |       |
| <input type="radio"/> | UA1200:J2-2  | FU0389    | WHT     | 20   | <input type="radio"/> | XT1200:16 | <input type="radio"/> |       |
| <input type="radio"/> | UA1200:J2-6  | UA1200J26 | WHT     | 20   | <input type="radio"/> | XT1200:13 | <input type="radio"/> |       |
| <input type="radio"/> | UA1200:J2-7  | UA1200J27 | WHT     | 20   | <input type="radio"/> | XT1200:14 | <input type="radio"/> |       |

| FROM                  |             |            |         |      | TO                    |             |                       |       |
|-----------------------|-------------|------------|---------|------|-----------------------|-------------|-----------------------|-------|
| COMPLETE              | DEVICE ID   | NO.        | WIRE ID | SIZE | COMPLETE              | DEVICE ID   | IPV                   | NOTES |
| <input type="radio"/> | UA1200:J1-5 | UA1200J15  | WHT     | 20   | <input type="radio"/> | XT0237:1 B1 | <input type="radio"/> |       |
| <input type="radio"/> | UA1200:J1-8 | UA1200J    | WHT     | 20   | <input type="radio"/> | UA1200:J3-5 | <input type="radio"/> |       |
| XT - AF               |             |            |         |      |                       |             |                       |       |
| <input type="radio"/> | XT1200:15   | UA1200J21  | WHT     | 20   | <input type="radio"/> | AF0072:05   | <input type="radio"/> |       |
| FU - XT               |             |            |         |      |                       |             |                       |       |
| <input type="radio"/> | FU0060:LI   | FU0136     | WHT     | 12   | <input type="radio"/> | XT0002:2    | <input type="radio"/> |       |
| <input type="radio"/> | FU0387:LD   | FU0387     | WHT     | 16   | <input type="radio"/> | XT0081:1    | <input type="radio"/> |       |
| <input type="radio"/> | FU0388:LD   | FU0388     | WHT     | 16   | <input type="radio"/> | XT0060:11   | <input type="radio"/> |       |
| <input type="radio"/> | FU2108:LD   | FU2108     | WHT     | 16   | <input type="radio"/> | XT0060:12   | <input type="radio"/> |       |
| AU0060                |             |            |         |      |                       |             |                       |       |
| <input type="radio"/> | AU0060:V+   | FU0061     | WHT     | 16   | <input type="radio"/> | FU0061:LD   | <input type="radio"/> |       |
| <input type="radio"/> | AU0060:COM  | -0V        | WHT     | 16   | <input type="radio"/> | XT0060:2    | <input type="radio"/> |       |
| FU - FU               |             |            |         |      |                       |             |                       |       |
| <input type="radio"/> | FU0061:LI   | FU0060     | WHT     | 14   | <input type="radio"/> | FU0060:LD   | <input type="radio"/> |       |
| FU0389                |             |            |         |      |                       |             |                       |       |
| <input type="radio"/> | FU0389:LD   | FU0389     | WHT     | 14   | <input type="radio"/> | KA0248:11   | <input type="radio"/> |       |
| <input type="radio"/> | FU0389:LD   | FU0389     | WHT     | 14   | <input type="radio"/> | XT1200:16   | <input type="radio"/> |       |
| XT0060                |             |            |         |      |                       |             |                       |       |
| <input type="radio"/> | XT0060:9    | -0V        | WHT     | 20   | <input type="radio"/> | XT1200:17   | <input type="radio"/> |       |
| <input type="radio"/> | XT0060:7    | -0V        | WHT     | 16   | <input type="radio"/> | XT0080:1    | <input type="radio"/> |       |
| <input type="radio"/> | XT0060:1    | -0V        | WHT     | 12   | <input type="radio"/> | XT0003:2    | <input type="radio"/> |       |
| XT0081                |             |            |         |      |                       |             |                       |       |
| <input type="radio"/> | XT0081:3    | FU0387     | WHT     | 20   | <input type="radio"/> | XT0089:1    | <input type="radio"/> |       |
| <input type="radio"/> | XT0081:5    | FU0387     | WHT     | 20   | <input type="radio"/> | XT0091:1    | <input type="radio"/> |       |
| AF0385                |             |            |         |      |                       |             |                       |       |
| <input type="radio"/> | AF0385:28   | -0V        | WHT     | 20   | <input type="radio"/> | XT0060:10   | <input type="radio"/> |       |
| <input type="radio"/> | AF0385:25   | -0V        | WHT     | 20   | <input type="radio"/> | XT0080:6    | <input type="radio"/> |       |
| <input type="radio"/> | AF0385:21   | -0V        | WHT     | 20   | <input type="radio"/> | XT0087:3    | <input type="radio"/> |       |
| <input type="radio"/> | AF0385:05   | -038505    | WHT     | 20   | <input type="radio"/> | XT0087:2    | <input type="radio"/> |       |
| <input type="radio"/> | AF0385:09   | UJ0131IOUT | WHT     | 20   | <input type="radio"/> | UJ0131:IOUT | <input type="radio"/> |       |
| <input type="radio"/> | AF0385:07   | UJ0131VIN  | WHT     | 20   | <input type="radio"/> | UJ0131:VIN  | <input type="radio"/> |       |
| AF0384                |             |            |         |      |                       |             |                       |       |
| <input type="radio"/> | AF0384:V+   | FU0382     | WHT     | 16   | <input type="radio"/> | FU0382:LD   | <input type="radio"/> |       |
| <input type="radio"/> | AF0384:COM  | -0V        | WHT     | 16   | <input type="radio"/> | XT0060:6    | <input type="radio"/> |       |
| <input type="radio"/> | AF0384:30   | SV21242    | WHT     | 20   | <input type="radio"/> | XT0069:2    | <input type="radio"/> |       |
| <input type="radio"/> | AF0384:14   | KA00709    | WHT     | 20   | <input type="radio"/> | KA0070:9    | <input type="radio"/> |       |
| <input type="radio"/> | AF0384:00   | KA013114   | WHT     | 20   | <input type="radio"/> | KA0131:14   | <input type="radio"/> |       |

| FROM                  |            |           |         |      | TO                    |              |                       |       |
|-----------------------|------------|-----------|---------|------|-----------------------|--------------|-----------------------|-------|
| COMPLETE              | DEVICE ID  | NO.       | WIRE ID | SIZE | COMPLETE              | DEVICE ID    | IPV                   | NOTES |
| AF0383                |            |           |         |      |                       |              |                       |       |
| <input type="radio"/> | AF0383:V+  | FU0381    | WHT     | 16   | <input type="radio"/> | FU0381:LD    | <input type="radio"/> |       |
| <input type="radio"/> | AF0383:COM | -0V       | WHT     | 16   | <input type="radio"/> | XT0060:5     | <input type="radio"/> |       |
| <input type="radio"/> | AF0383:19  | KA0382A2  | WHT     | 20   | <input type="radio"/> | KA0382:A2    | <input type="radio"/> |       |
| <input type="radio"/> | AF0383:17  | KA038013  | WHT     | 20   | <input type="radio"/> | KA0380:13(-) | <input type="radio"/> |       |
| <input type="radio"/> | AF0383:10  | AF038310  | WHT     | 20   | <input type="radio"/> | XT0237:1 B2  | <input type="radio"/> |       |
| <input type="radio"/> | AF0383:09  | UA1200J14 | WHT     | 20   | <input type="radio"/> | XT1200:11    | <input type="radio"/> |       |
| <input type="radio"/> | AF0383:06  | KA006111  | WHT     | 20   | <input type="radio"/> | KA0061:11    | <input type="radio"/> |       |
| <input type="radio"/> | AF0383:05  | KA006221  | WHT     | 20   | <input type="radio"/> | KA0062:21    | <input type="radio"/> |       |
| <input type="radio"/> | AF0383:03  | KA0382A1  | WHT     | 20   | <input type="radio"/> | KA0382:A1    | <input type="radio"/> |       |
| <input type="radio"/> | AF0383:01  | KA038014  | WHT     | 20   | <input type="radio"/> | KA0380:14(+) | <input type="radio"/> |       |
| <input type="radio"/> | AF0383:00  | KT014615  | WHT     | 20   | <input type="radio"/> | KT0146:15    | <input type="radio"/> |       |
| <input type="radio"/> | AF0383:29  | KA0192A2  | WHT     | 20   | <input type="radio"/> | KA0192:A2    | <input type="radio"/> |       |
| <input type="radio"/> | AF0383:28  | KA0190A2  | WHT     | 20   | <input type="radio"/> | KA0190:A2    | <input type="radio"/> |       |
| <input type="radio"/> | AF0383:13  | KA0192A1  | WHT     | 20   | <input type="radio"/> | KA0192:A1    | <input type="radio"/> |       |
| <input type="radio"/> | AF0383:12  | KA0190A1  | WHT     | 20   | <input type="radio"/> | KA0190:A1    | <input type="radio"/> |       |
| AF0382                |            |           |         |      |                       |              |                       |       |
| <input type="radio"/> | AF0382:V+  | AF0382P   | WHT     | 16   | <input type="radio"/> | AF0385:V+    | <input type="radio"/> |       |
| <input type="radio"/> | AF0382:COM | AF0382N   | WHT     | 16   | <input type="radio"/> | AF0385:COM   | <input type="radio"/> |       |
| AF0381                |            |           |         |      |                       |              |                       |       |
| <input type="radio"/> | AF0381:36  | KA0130A1  | WHT     | 20   | <input type="radio"/> | KA0130:A1    | <input type="radio"/> |       |
| <input type="radio"/> | AF0381:35  | SB647221  | WHT     | 20   | <input type="radio"/> | XT0089:18    | <input type="radio"/> |       |
| <input type="radio"/> | AF0381:34  | -038134   | WHT     | 20   | <input type="radio"/> | KA0249:21    | <input type="radio"/> |       |
| <input type="radio"/> | AF0381:33  | -038133   | WHT     | 20   | <input type="radio"/> | KA0244:21    | <input type="radio"/> |       |
| <input type="radio"/> | AF0381:32  | SB7512C1  | WHT     | 20   | <input type="radio"/> | XT0089:14    | <input type="radio"/> |       |
| <input type="radio"/> | AF0381:20  | UA1200J27 | WHT     | 20   | <input type="radio"/> | XT1200:14    | <input type="radio"/> |       |
| <input type="radio"/> | AF0381:04  | KA013014  | WHT     | 20   | <input type="radio"/> | KA0130:14    | <input type="radio"/> |       |
| <input type="radio"/> | AF0381:03  | SB647222  | WHT     | 20   | <input type="radio"/> | XT0089:19    | <input type="radio"/> |       |
| <input type="radio"/> | AF0381:02  | -038102   | WHT     | 20   | <input type="radio"/> | KA0249:24    | <input type="radio"/> |       |
| <input type="radio"/> | AF0381:01  | -038101   | WHT     | 20   | <input type="radio"/> | KA0244:24    | <input type="radio"/> |       |
| <input type="radio"/> | AF0381:00  | SB75122   | WHT     | 20   | <input type="radio"/> | XT0089:15    | <input type="radio"/> |       |
| <input type="radio"/> | AF0381:40  | KA71711   | WHT     | 20   | <input type="radio"/> | XT0189:55    | <input type="radio"/> |       |
| <input type="radio"/> | AF0381:39  | KA71731   | WHT     | 20   | <input type="radio"/> | XT0189:61    | <input type="radio"/> |       |
| <input type="radio"/> | AF0381:08  | KA71712   | WHT     | 20   | <input type="radio"/> | XT0189:56    | <input type="radio"/> |       |
| <input type="radio"/> | AF0381:07  | KA71732   | WHT     | 20   | <input type="radio"/> | XT0189:62    | <input type="radio"/> |       |
| AU0380                |            |           |         |      |                       |              |                       |       |

| FROM                  |            |        |         |      | TO                    |           |                       |       |
|-----------------------|------------|--------|---------|------|-----------------------|-----------|-----------------------|-------|
| COMPLETE              | DEVICE ID  | NO.    | WIRE ID | SIZE | COMPLETE              | DEVICE ID | IPV                   | NOTES |
| <input type="radio"/> | AU0380:V+  | FU0380 | WHT     | 16   | <input type="radio"/> | FU0380:LD | <input type="radio"/> |       |
| <input type="radio"/> | AU0380:COM | -0V    | WHT     | 16   | <input type="radio"/> | XT0060:4  | <input type="radio"/> |       |

INTERNAL

JB71 B,PNL CTRL2

#### Cables (12)

| FROM                  |             |        |         |       | TO                    |           |                       |       |
|-----------------------|-------------|--------|---------|-------|-----------------------|-----------|-----------------------|-------|
| COMPLETE              | DEVICE ID   | TYPE   | WIRE ID | SIZE  | COMPLETE              | DEVICE ID | IPV                   | NOTES |
| Cable: WC4524         |             |        |         |       |                       |           |                       |       |
| <input type="radio"/> | UA1200:J1-3 | WC4524 | RED     | 20    | <input type="radio"/> | XT1200:8  | <input type="radio"/> |       |
| <input type="radio"/> | UA1200:J1-1 | WC4524 | BLK     | 20    | <input type="radio"/> | XT1200:9  | <input type="radio"/> |       |
| <input type="radio"/> | FLOATING    | WC4524 | SH      | 20    | <input type="radio"/> | XT1200:10 | <input type="radio"/> |       |
| Cable: WC4624         |             |        |         |       |                       |           |                       |       |
| <input type="radio"/> | AF0382:00   | WC4624 | RED     | 20    | <input type="radio"/> | XT1200:8  | <input type="radio"/> |       |
| <input type="radio"/> | AF0382:16   | WC4624 | BLK     | 20    | <input type="radio"/> | XT1200:9  | <input type="radio"/> |       |
| <input type="radio"/> | AF0382:48   | WC4624 | SH      | 20    | <input type="radio"/> | XT1200:10 | <input type="radio"/> |       |
| Cable: WC4657         |             |        |         |       |                       |           |                       |       |
| <input type="radio"/> | UA1200:J3-1 | WC4657 | RED     | 20    | <input type="radio"/> | XT1200:1  | <input type="radio"/> |       |
| <input type="radio"/> | UA1200:J3-3 | WC4657 | BLK     | 20    | <input type="radio"/> | XT1200:2  | <input type="radio"/> |       |
| <input type="radio"/> | UA1200:J3-2 | WC4657 | SH      | 20    | <input type="radio"/> | XT1200:3  | <input type="radio"/> |       |
| Cable: WC0006         |             |        |         |       |                       |           |                       |       |
| <input type="radio"/> | AU0060:L2   | WC0006 | ENET    | CABLE | <input type="radio"/> | AU0380:L1 | <input type="radio"/> |       |
| Cable: WC0038         |             |        |         |       |                       |           |                       |       |
| <input type="radio"/> | AU0380:L2   | WC0038 | ENET    | CABLE | <input type="radio"/> | AT0140:P1 | <input type="radio"/> |       |
| Cable: WC0051         |             |        |         |       |                       |           |                       |       |
| <input type="radio"/> | AU0060:L1   | WC0051 | ENET    | CABLE | <input type="radio"/> | AF0510:L2 | <input type="radio"/> |       |