FOR MKS V1.1 Firmware refresh instructions

1 Open the **lite_cfg** file with Notepad

https://github.com/my3dltd/F1-MKS-V1.1-Firmware

名称	修改日期
Firmware refresh instructions	2019/5/22 9:37
lite_cfg	2019/12/14 21:35
mksLite.bin	2019/5/22 9:35
PID	2019/8/24 15:51

> Installation instructions › Firmwae UPDATE

2
A / Copy the modified **lite_cfg** file and **mkslite.bin** to the TF card,
B / TF card plug in 3D printer Motherboard,
C / the power switch again.

> TF CARD (F:)

名称
lite_cfg
mksLite.bin

Will update automatically.

After the update, the files in the TF card are automatically invalidated (can be deleted) and can only be updated once. If you need to update again. Need to re-copy the file into the TF card.