






Item No.	Item Description	Item No.	Item Description
015	Screw		
027	Protective cap		
039	Nut		
040	Stud for cylinder cover		
052	O-ring		
064	Screw		
076	Distance pipe		
088	Nut		
111	Stud		
123	Cylinder frame		
135	Distance pipe		
147	Nut		
159	Distance pipe		
160	Stud		
172	Distance pipe		
184	Distance pipe		
196	Fitted bolt		
206	Cover		
218	Screw		
231	Cap nut		
243	Screw		
255	Protective pipe, complete		
267	O-ring		
279	Packing		
292	Nut		
302	Stud		
314	Cover		
326	O-ring		
351	Screw		
363	O-ring		
375	Cleaning cover		
399	Stud		
409	Screw		




Item No.	Item Description
010	Cooling jacket
022	Gasket
034	Piston cleaning ring*
046	Cylinder liner
058	Packing
071	Plug screw
095	Clamp
105	Screw
117	O-ring
129	O-ring
142	Stud
154	Nut
166	Cooling water connection
178	Packing
201	Sealing ring
213	Cooling water connection
225	Screw
	Note: * Two designs available: 1. Standard Cleaning ring. 2. Retrofit piston cleaning ring.

Item No.	Item Description








Item No.	Item Description
011	Non-return valve, complete
023	Head
035	Valve
047	Housing



Item No.	Item Description	Item No.	Item Description
017	Lubricator		
030	Coupling		
042	Key		
066	Screw		
078	Locking plate		
091	Shaft		
101	Flange for gear		
113	Screw		
137	Screw		
149	Fitted bolt		
150	Nut		
162	Screw		
174	Distance pipe, L=50		
186	Lubricator		
208	Guide pin		
233	Bracket		
245	Guard		
257	Screw		
269	Spring lock		
282	Gear		



Item No.	Item Description



Item No.	Item Description
019	Steel pipe
020	Pipe holder
032	Screw
044	Steel pipe
056	Pipe holder
068	Coupling
081	Steel pipe
103	Steel pipe
115	Steel pipe
127	Coupling
139	Pipe holder
140	Distributor block
152	Screw
176	Coupling
188	Coupling
211	Steel pipe
223	Steel pipe

Item No.	Item Description