




Item No.	Item Description
019	Plate
020	Screw
032	Locking wire
044	Screw
068	Crank-pin bearing shell, complete
081	Screw
093	Screw
103	Outlet pipe
115	Guide shoe, fore
139	Guide strip
140	Crosshead bearing shell, lower part
152	Connecting rod
176	Screw
188	Shim
211	Crosshead bearing cap
223	Crosshead bearing shell, upper part
235	Guide pipe
247	Crosshead
260	Crank-pin bearing cap
272	Guide pin
284	Screw
306	Distance piece
318	Bushing
331	Housing for stuffing box
343	Telescope pipe
355	Screw
379	Stud
380	Nut
402	Guide shoe, aft
414	Shim 0,25mm
426	Shim 0,50mm
438	Screw
451	Nut
463	Stud
475	Spring pin
487	Screw
509	Counterweight
510	Spring pin
558	Connecting rod, complete

Item No.	Item Description

