









Item No.	Item Description	Item No.	Item Description
017	Stud	664	Spindle
029	Nut	676	Housing
030	Disc	711	Pump barrel, complete
042	Plug	723	Pump barrel and top cover, complete
054	Gasket	747	Puncture valve, complete
066	Plug screw	759	Suction valve, complete
078	Guide pin	772	Combined puncture and suction valve, complete
091	Guide bushing		
113	Plug screw		
125	Toothed bar		
149	Shim		
150	Pump housing		
162	Guide pin		
174	Regulating guide		
198	Gasket		
208	Plug screw		
221	Steel ball		
233	Screw		
245	Screw		
257	O-ring		
269	Back-up ring		
270	Plunger		
294	Union		
304	Pointer		
316	Felt ring		
341	Top cover		
353	Guide pin		
365	O-ring		
377	Back-up ring		
389	O-ring		
390	Pump barrel		
400	Nut		
424	Restriction plug		
436	Screw		
461	Screw		
485	Sealing ring		
497	Sealing ring		
507	Spring		
519	Housing		
520	Sealing ring		
544	Screw		
556	Plug		
568	Air piston		
593	Sealing ring		
615	Housing		
627	Sealing ring		
639	Conical ring in 2/2		
640	Cone		
652	Spring		




Item No.	Item Description	Item No.	Item Description
012	Fuel pump roller guide, complete	646	Disc
024	Shaft	671	Sealing ring
036	Plug		
048	Plug		
061	Stop screw		
073	Roller		
085	Bushing		
097	Disc		
107	Shaft-pin for roller		
120	Guide pin		
144	Thrust disc		
156	Roller guide		
168	Plug		
181	Bushing		
193	Pin		
215	Link for reversing		
227	Pin		
240	Guide pin		
252	Guide block		
264	Screw		
276	Guide pin		
288	Bushing		
311	Locking wire		
323	Flange		
335	Screw		
347	Sealing bush		
359	Bushing for roller guide		
372	Cap		
384	Nut, self-locking		
396	Screw		
418	Scraper ring, axial		
431	Scraper ring		
443	Flange		
455	Holder for scraper ring		
467	Locking wire		
479	Screw		
492	Nut		
502	Pump base		
514	Pump base		
526	Packing		
538	Cover, transparent		
551	Flange		
563	Screw		
587	Disc		
599	Stud		
609	Stud		
610	Spring, internal		
622	Spring, external		
634	Disc		



Item No.	Item Description	Item No.	Item Description
019	Shaft		
020	Guide for reversing		
032	Distance pipe		
044	Self-locking nut		
056	Guard		
068	Screw		
093	Cover		
103	Screw		
115	Bolt		
127	Flange for air cylinder		
139	Reversing mechanism, complete		
152	Screw		
164	Bush		
176	Air cylinder		
211	Screw		
223	Union		
235	Reducing socket		
247	Ball valve		
259	Union		




[illegible]







Item No.	Item Description	Item No.	Item Description
	Note: D1 = Predetermined closing value for non-return valve D2 = Predetermined opening value for cut-off spindle		







Item No.	Item Description
012	High-pressure pipe, complete
024	Spring ring
036	Sleeve
048	O-ring
061	Union nipple
085	High-pressure pipe
097	Union nipple
107	O-ring
120	High-pressure pipe, complete
132	High-pressure pipe

Item No.	Item Description



Item No.	Item Description		
018	Non-return valve		
031	Coupling		
043	Steel pipe		
055	Steel pipe		
067	Coupling		
080	Steel pipe		
092	Support		
102	Screw		
114	Packing ring		
126	Screw		
138	Fuel oil pipe, inlet		
151	Ball valve		
163	Packing ring		
175	Screw		
187	Fuel oil pipe, inlet		
199	Non-return valve		



Item No.	Item Description
013	O-ring
025	Piston
037	Spring
050	Cup point screw
062	Nut
086	O-ring
108	Housing
121	Valve housing
133	Spring guide
145	Valve cover
169	Over-flow valve, complete
182	Level switch
194	Drain box
216	Drain box, complete
241	Packing
253	Screw
265	Wearing ring
277	Sealing ring
289	Packing
290	Lock washer
300	Nut
312	Stud
324	Spring guide
348	Housing
361	Piston
373	Spring
385	Stud
397	Flange
407	Spring
420	Shock absorber, complete

Item No.	Item Description