

Fig. 1




Fig. 2









Fig. 3






Item No.	Item Description	Item No.	Item Description
017	Screw		
029	Guard		
042	Screw		
054	Scavenge air receiver		
066	Crane beam		
091	Nut		
101	Distance piece		
113	Screw		
125	Guide pin		
137	Distance piece		
149	Screw		
150	O-ring		
162	Plug screw		
174	Nut		
186	Distance piece		
198	Stud		
208	Nut		
221	Cleaning pipe		
233	Spray nozzle		
245	Stud		
257	Packing		
269	Plug screw		
282	Cover		
294	Plug screw		
316	Flange		
328	Washer		
341	Flange		
365	O-ring		
377	Manhole cover, complete		
389	Stud		
390	Plate		
400	Plate		
412	Nut		
424	Sectional iron		
436	Sectional iron		
448	Stud		
461	Screw		
473	Support		




Item No.	Item Description
012	Cover plate
024	Insulation material
036	Glass fibre cloth
048	Compensator
061	Plug screw
073	Gasket
085	Charging air pipe
097	Cover plate
107	Nut
119	Washer
120	Screw
132	Plug screw
144	Screw

Item No.	Item Description




Item No.	Item Description
018	Plug screw
031	Packing
043	Gas inlet
055	*) Screw
067	Packing
079	Nut
080	Compensator
092	*) Screw
114	Blind rivet
126	Insulation material
138	Exhaust receiver
151	Packing
163	Plug screw
175	Nut
199	*) Screw
209	Insulation cover 2/2
210	Insulation cover 2/2
222	Packing
234	Grid, complete
246	Wire gauze
258	Plug screw
271	Packing
295	Plug screw
305	Packing
317	Insulation plate cover
330	Washer
342	Packing
354	Locking plate
366	Washer
378	*) Screw
391	Cover
401	Wing nut
425	*) Screw
437	*) Screw
449	Washer
450	Nut
462	Packing
474	Stud
486	Heating shield
498	Manhole cover
508	Split pin
521	Hinge rod
545	Insulation cover 2/2
557	Compensator
569	Plate
582	Packing
594	Plug screw


Item No.	Item Description
	*) The screws are special screws for hot joints, they are marked with a "T", and MUST NOT BE USED ELSE-WHERE!




Item No.	Item Description	Item No.	Item Description
001	Nut		
013	Clamp		
025	Distance pipe		
037	Nut		
049	Distance pipe		
050	Screw		
062	Spring pin		
074	Distance pipe		
086	Screw*		
098	Spring pin		
108	Nut		
121	Distance pipe		
133	Clamp		
145	Support		
157	Shim		
169	Spring plate		
170	Clamp		
182	Screw		
194	Spring pin		
204	Washer		
216	Screw*		
228	Nut		
241	Nut		
253	Distance pipe		
277	Support		
289	Screw		
Note: * These screws are special screws for hot joints, they are marked with a "T" and MUST NOT be used elsewhere !			







A - A



Item No.	Item Description




Item No.	Item Description	Item No.	Item Description
014	Screw		
026	Nut		
038	Screw		
051	Distance pipe		
075	Auxiliary blower*		
099	Screw		
122	Non-return valve		
146	Screw		
158	Spring washer		
171	Support		
183	Clamp		
195	Spring pin		
205	Shaft		
217	Holder		
229	Sealing ring		
230	Sliding bearing		
242	Valve flap		
266	Screw		
291	Auxiliary blower		
	Note:		
	* When ordering spare parts for this item, please state manufacturer's Part No.		






Item No.	Item Description
021	Screw
033	Packing
045	Shaft
057	Valve housing
069	Valve flap
082	Screw
094	Locking plate
104	Locking device
128	Cover
153	Packing
165	Cover

Item No.	Item Description



Item No.	Item Description	Item No.	Item Description
010	Screw		
022	Packing ring		
046	Nipple		
058	Ball valve		
071	Hose connection		
095	Steel pipe		
105	Coupling		
129	T-coupling		
130	Coupling		
142	Ball valve		
154	Coupling		
178	Blank flange		
191	Screw		
201	Butterfly valve		
225	Plug screw		
237	Plug screw		
250	Cooling water pipe		




Item No.	Item Description	Item No.	Item Description
016	Air cooler		
041	O-ring		
053	Frame		
065	Screw		
089	Screw		
090	Distance pipe		
100	Flat steel bar		
112	sealing plate		
136	Plug screw		
148	Packing		
173	Cover		
185	Screw		
207	Packing		
219	Cover		
220	Screw		

Arrangement of Non-return Valve

MAN B&W Diesel

Plate
P91011-0030



Item No.	Item Description	Item No.	Item Description
011	Screw		
023	Lock washer		
035	Support		
047	Clamp		
059	Spring pin		
060	Shaft		
084	Holder		
096	Sealing ring		
106	Sliding bearing		
118	Valve flap		