






Item No.	Item Description
014	Stay bolt, complete
026	Screw
038	Protective cap
051	Nut
075	Stay bolt
087	Guide bushing


Item No.	Item Description



A - A

B - B


C - C




D - D

E - E


F - F



Item No.	Item Description




Item No.	Item Description	Item No.	Item Description
010	Lubricating oil pipe		
022	Lubricating oil pipe		
034	Damper-oil pipe		
046	Damper-oil pipe		
071	Bracket		
083	Screw		
095	Bracket		
105	Lubricating oil pipe		
117	Nut		
129	Stud		
130	Screw		
142	Pipe clamp		
154	Screw		
166	Screw		
191	Pipe holder		
213	Screw		
225	Damper-oil pipe		
249	Lubricating oil pipe		
250	Lubricating oil pipe		
262	Lubricating oil pipe		
286	Distance pipe		
298	Stud		
308	Nut		




Item No.	Item Description	Item No.	Item Description
016	Frame box door		
028	O-ring		
053	Frame box		
100	Stud		
112	Nut		
136	Relief valve		
148	Packing		
161	Screw		
173	Drain pipe		
197	Cover		
207	Screw		
220	Screw		
232	Frame door, rear		
244	Stud		
256	Nut		
281	Eye bolt		
293	Cover		
303	Screw		
327	Cover		
340	Cover		
364	Fitted bolt		
376	Screw		
388	Nut		
411	Distance pipe		
435	Spring		
447	Door fastner		
459	Wing nut		
460	Distance pipe		
472	Screw		
484	Stud		
506	Face		
518	Sealing ring		
531	Screw		
543	Locking wire		
567	Face		
579	Sealing ring		
580	Face		
592	Screw		
614	Distance pipe		
638	Screw		


B-B




Item No.	Item Description	Item No.	Item Description
017	Screw		
029	Locking wire		
042	Slotted pipe		
054	Screw		
066	Self-locking nut		
078	Washer		
091	Drain pipe		
113	Sight glass		
125	Drain box		
149	Bracket		
150	Screw		
174	Clamp		
186	Self-locking nut		



Item No.	Item Description	Item No.	Item Description
012	Gasket		
024	Flange		
036	Stud		
048	Nut		
061	Chain wheel frame, upper		
073	Screw		
097	Stud		
107	Distance pipe		
119	Nut		
132	Plug		
156	Stud		
181	Cover		
203	Guide pin		
215	Cover		
227	Screw		
240	Distance pipe		
252	Screw		
276	Locking wire		
288	Screw		
323	Stud		
347	Stud		
360	Screw		
396	Gasket		
406	Cover		
418	Guide pin		
431	Screw		
455	Stud		
467	Distance pipe		
479	Nut		
492	Stud		
502	Distance pipe		
514	Nut		
538	Screw		
563	Top guard		
587	Gasket		
599	Cover		
610	Screw		
634	Screw		
646	Rail for sealing		
658	Packing rubber		
683	Distance pipe		
695	Guide pin		




Item No.	Item Description	Item No.	Item Description
013	Nut for hydraulic tightening		
025	Main bearing stud		
050	Screws with special heads		
062	Bedplate		
086	Main bearing cap		
098	Spring pin		
108	Main bearing, upper shell*		
121	Main bearing, lower shell*		
133	Screw		
157	Grate		
170	Screw		
182	Cover plate		
	Notes:		
	* To be ordered as a complete part only.		



Item No.	Item Description
019	Spring
020	Spring
044	Screw
056	Restriction for damper
081	Restriction for damper
093	Restriction for damper
103	Screw
127	Oil seal in 2/2
139	Oil seal in 2/2
140	Guide pin
164	Nut
176	Nut
188	Stud
211	Stud
235	Axial vibration damper housing, complete
259	Damper housing, upper part
260	Guide pin
272	Damper housing, lower part

Item No.	Item Description



Holding-Down Bolts and End-Chock Bolts (Epoxy Chocks)



Item No.	Item Description	Item No.	Item Description
028	Screw		
041	Washer		
053	Locking plate		
077	Liner for side chock, port side		
089	Liner for side chock, starboard		
100	Liner end chock		
112	Spherical washer		
124	Spherical washer		
136	Nut		
148	Protective cap		
173	Protectice cap		
185	Nut		
197	Distance pipe		
219	Spherical washer		
220	Spherical nut		
232	Holding-down bolt, M36 x 4		
256	Stud for end chock bolt, M60 x 5.5		