

# **GEARDÖ**

## **USER GUIDE**

Please read this guide before  
operating the devices

# Table of Contents

1. VR Set inclusions
2. VR Etiquette
3. Setting up Bluetooth and WiFi
4. Your first VR experience
5. 360 photos
6. Videos
7. Games
8. Charging & Cleaning

# Each **GEARDÖ** VR set includes:



1. Wireless Headphones with USB cable charger
2. VR Headset
3. Samsung S7 (VR CPU) with fast charger
4. Wireless Gamepad with USB cable charger
5. Lens cleaning cloth

\*serial numbers indicated in contract

\*\*any loss or damage to any of the set contents will be charged to renting party

# VR Etiquette

When using the VR set please ensure that your face is clean and dry



Computers need to rest too. VR sets must be rested for at least 10 mins. after 2 straight hrs. of use

# **VR Etiquette**

Use only in a safe environment. Be aware of your surroundings.

Ease into VR to allow your body to adjust; use for only a few minutes at first and increase usage gradually


# VR Etiquette

We recommend consulting a doctor before using the VR set if you are pregnant, suffer from heart condition, have pre-existing vision abnormalities, or suffer from a heart condition or other serious medical condition.

**GEARDÖ** will not be held responsible for any injuries that may occur

# Setting up Bluetooth and WiFi

The S7 (VR CPU) will need **Bluetooth** to connect to the gamepad and headset




Simply slide the screen down to reveal the menu then press and hold the bluetooth icon to reveal devices.

- Pair device with **PG-9033** and **DR-BTN200**

# Setting up Bluetooth and WiFi


Some apps may require an internet connection.



Simply slide down on the main screen then click and hold on the WiFi icon to reveal possible connections.

# Your first VR experience


1. First make sure the S7 screen is active unlocked



2. On the VR headgear press and slide the lock out on the left

# Your first VR experience

3. Insert the S7 face down on the micro USB connector then carefully push the opposite end of the mobile device until the lock on the opposite side holds it in place



# Your first VR experience

4. Done correctly you should see the main screen upon wearing the VR set



# Your first VR experience

## 5. Basic navigation and selection

### Using the Touchpad

The Touchpad, located at the right side of the Gear VR, is used for both selection and navigation of displayed elements.


#### *Making Selections (Tapping)*

1. Move your head to place the pointer on top of the desired item.
2. Tap the touchpad with your finger.



# Setting up VR

For those with different eye grades, the adjustor wheel on top of the headgear can be used



# VR 360° photos

## Oculus 360 Photos

This application provides 360 degree views of available panoramic images.

1. Navigate to the **HOME** screen, place the pointer on the **Library** button and tap the touchpad.
2. Swipe across your touchpad until the **Oculus 360 Photos** app displays, then select **START**.
3. Select an available category type, then open a desired image folder, and select an image.  
Turn your head and view a panorama of the image.

While viewing the image, tap the touchpad to use the following features:

- / : Navigates through images.
  - **View the previous image:** Swipe backward across the touchpad.
  - : Swipe forward across the touchpad.
- Sets the current image as your favorite image.

# VR 360° photos

- To view photos you need to select the 360° photos app from the library
- To add your own photos you will need to plug the S7 into a laptop/desktop
- Transfer your own photos into either
  - “360Photos” folder in the “Oculus” folder (for 360) or
  - “Images” in the root folder (for normal photos)

**Fact:** you need a 360 camera or image processor to create your own 360 photos

# VR Videos

## Oculus Video

Enjoy videos on a screen in your own virtual movie theater.

1. Navigate to the **HOME** screen, place the pointer on the **Library** button and tap the touchpad.
2. Swipe across your touchpad until the **Oculus Video** app displays.
3. Select **START** and choose a screen category from the top of the page. Videos are sorted based on the screen type.
  - **Shorts:** View or download free videos from Oculus that are optimized for a standard screen.
  - **Trailers:** View free movie trailers from Oculus that are optimized for a standard screen.
  - **My Videos:** View a video stored in the mobile device on a standard screen.
4. Select a video and then choose an available surrounding for your movie watching experience.

**Note:** When the video finishes, the next video automatically plays after several seconds.

**To access the playback controls:**

1. While the movie is playing, hover your pointer over the bottom area of the displayed movie and tap the touchpad.
2. Once the controls display, hover over a selection and use the touchpad to activate a function.
  -  /  : Pause and resume playback.
  -  /  : Rewind or fast-forward a video.

**Tip:** You can also swipe backward across the touchpad to rewind a video or swipe forward across it to fast-forward a video.

-  : View the list of available videos.

# VR Videos

- To view videos you need to select the [Oculus Cinema](#) app from the library
- To add your own videos you will need to plug the S7 into a laptop/desktop (Just transfer your videos into the “Videos” folder)

# Playing games

- To view the entire list of games, simply go to the library and select a game using the touchpad or gamepad



# Charging

There are two (2) ways to charge the VR

1. Charging the device directly



2. Charging while plugged into the headset



# Cleaning

The lenses and screens of VR devices are very sensitive. Only wipe using the provided cloth.



For further questions or concerns, please  
feel free to contact us at 0905-5361238

**GEARDO**

VIRTUAL REALITY+ DELIVERED TO YOU

<http://geardo.ph>